



You're home.™

2 year
guarantee

Energise Pulse

Let's get started



U86-E2e Series

vax.co.uk

Contents

Let's talk safety

Getting to know your machine

Getting started

Using your machine

Taking care of your machine

Let's talk technical

What to do if it goes wrong

Getting in touch

Accessories

Initial Setup for normal operation


1. Use the base accessories.
 - Shortest hose
 - Extension tube set to shortest practicable length.
2. Clean filters installed.
3. Dust receptacle empty.
4. All Bleeds must be closed.
5. Variable Power set to Maximum.
6. Floor heads/tools set to Carpet Mode for carpet cleaning.
7. Mechanical Agitation turned ON for carpet cleaning.
8. Floor heads/tools set to Hard Floor Mode for hard floor cleaning.
9. Mechanical Agitation turned OFF for hard floor cleaning.

Energise Pulse

Included with your machine



3 in 1 crevice, dust and upholstery tool



Pre-motor filter



Post-motor filter




Hard floor adaptor

+ Energise Pulse Pet



TurboTool



Tool connector

+ Energise Pulse Reach



Stretch hose

Getting to know your machine

Handle

TurboTool holder (hidden)

Dirt container release button

Separator

Dirt container

Hose holder

Post-motor filter cover

Floor type adjustor

Hose to machine connector

Extension tube

Handle release button

Power on/off button

Quick release cord hook

Power cord

Hose

Technical Specification


Name **Energise Pulse**
Voltage **220-240V-50Hz**
Wattage **700W**
Cord length **8m**
Weight **7kg**

Consumables


Filter Kit (Type 98)*
1-1-134233-00
Belt Kit (Type 1)*
1-1-130669-01

PLEASE READ 'LET'S TALK SAFETY' AT THE BEGINNING BEFORE USE


Assembling your upright




Insert the back panel into the floorhead




Insert the lower quick release cord hook into the hole at the bottom of the back panel




Now take the small clip and push it down between the post motor filter cover and back panel, over the quick release cord hook to lock into place




Attach hose clip to the air inlet tube




Insert the short end of the hose into the tube at the back of the machine and connect the hose end to the floorhead




Place the dirt container onto the machine and push until it clicks into place




Insert the extension tube into the handle




Push handle into the top of the machine until it clicks into place



Push turbotool holder on to the handle.



Clip turbotool into position




Plug in and switch on your machine

Before you begin cleaning


- Always switch off and unplug the vacuum cleaner before connecting or disconnecting the hose/attachments, or removing and emptying the dirt container
- The vacuum cleaner is equipped with a thermal cut-out. If for any reason the vacuum cleaner does overheat the thermostat will automatically turn the vacuum cleaner off. If this happens, switch the vacuum cleaner off and unplug from electrical socket. Remove and empty the dirt container also check the vacuum cleaner for blockages. Allow the vacuum cleaner to cool for approximately 1 hour (if you have cleaned the filters please wait 24 hours for the filters to fully dry before putting back into the vacuum)
- Filters require cleaning at least every 3 months
- If the vacuum cleaner is blocked, switch off and unplug before removing the blockage
- When using the accessories always make sure the brushbar is switched to the off position

IMPORTANT: When the vacuum cleaner is stood in the upright position or when using on stairs and the hose/tools, the brushbar height adjust dial must be set to hard floor.


How to use



Twist the quick release cord hook to release the power cord



Choose your desired carpet height or hardfloor setting




Plug in your machine and push ON/OFF button to switch on




Don't over fill the dirt container to avoid clogging your filter

Using the Hard Floor Adaptor

Apply the Hard Floor Adaptor for optimum results on hard floors. The Hard Floor Adaptor can be used on any floor setting.



Lie vacuum cleaner on its back exposing brush bar




Align Hard Floor Adaptor with base of vacuum cleaner, push until its clicks into place




To ensure the Hard Floor Adaptor is correctly fitted, the wheels should be towards the back of the floor tool when attached to vacuum cleaner.


Using accessories




Remove hose end from the floorhead



Choose an accessory




Attach accessory adapter to hose end




If required use tool connector

Extension tube



Remove extension tube from inside the handle


Turn the extension tube and attach to the handle



Attach hose to the top of the handle

Push accessory on to the extension tube

Using your machine on the stairs




Hold the machine to steady when using on the stairs. Always make sure the brushbar is overhanging the stair tread during use




WARNING

This machine has a constantly rotating brushbar. When using the machine on stairs, ensure the height adjuster dial is set to hard floor and the brushbar is overhanging the stair tread (as pictured). Always take extra care when cleaning stairs


Emptying and cleaning the dirt container



Press dirt container release button to remove the dirt container




Hold dirt container over a bin and unclip the lock on the bottom of the dirt container, allowing the dirt to fall out




Close the base of the dirt container, align the dirt container base back onto the machine and push until it clicks back into place

Cleaning the pre-motor filter




Turn the dirt container lid anti-clockwise to remove




Lift the dirt container lid to remove



Tap the filter over a bin to remove the dirt



Tap the filter over a bin to release and dirt



Wash the filter under running water (40°C max)




Leave to fully dry for a least 24 hours before placing back in the machine




Wash filters with warm water (MAX 40°C) at least every 3 months


Cleaning the shroud




Turn the dirt container lid anti-clockwise and lift to remove



Remove the pre-motor filter to allow access to the shroud




Tap the shroud over a bin to remove dirt and debris




Wash the shroud under running water and leave to fully dry before placing back into the machine

Removing debris from the brushbar




Switch off your vacuum cleaner at the main socket. Using a pair of scissors cut any hair or debris free from around the brushbar

Cleaning the post-motor filter



Twist post motor filter cover anti-clockwise and lift to remove




Remove the filter




Wash the filter under running water (40°C max)


Removing blockages from the TurboTool




Remove the rubber ring




Push both buttons to open the turbo tool



Wash the filter under running water (40°C max)





Leave to dry for 24 hours and then replace before using your vacuum



! WARNING

Always switch the machine off and unplug before carrying out any maintenance




Using a pair of scissors, cut any hair or debris free from around the brushes




! WARNING

If the air inlet, hose or telescopic tube is blocked, switch off the vacuum cleaner and remove the blockage(s) before re-starting the vacuum cleaner


Changing the belt




Switch off your vacuum cleaner at the main socket and unplug. Unclip the 2 small wheels from the base of the vacuum to enable you to remove the screws from behind. Note: The screw for the height adjuster dial is located here




Remove the 9 screws from the base of the floorhead cover




Remove the floorhead cover




Lift the brushbar from the machine to remove the belt. Note: To remove debris from the brushbar see 'Let's talk technical' on the previous page



Place the brushbar through the belt and hook the belt onto the metal spindle



Once the belt has been replaced attach the brushbar back onto the vacuum



Replace the floorhead cover, 2 small wheels and height adjuster dial by screwing back into place

Problem

Solution

There is an accessory missing

- Check the 'This pack contains' panel on the box to make sure the part is included with your machine

Why does my vacuum cleaner have no power?

- The plug may not be fully pushed into the electrical socket
- Check the fuse in the plug if this needs replacing, always replace with a British 13amp fuse
- The motor thermostat may have tripped. If this has happened, unplug the vacuum cleaner. Remove and empty the dirt container and check the hose for blockages.
- Clean the filters and allow the vacuum cleaner to cool for approximately 1 hour (if you have washed the filters you will need to wait 24 hours for the filters to fully dry before putting them back into the vacuum cleaner)

Why won't the vacuum cleaner pick up?

- There may be a blockage in the hose. Please remove the hose from the vacuum cleaner, check and clear any blockages
- Empty the dirt container and clean filters. Go to the 'Taking care of your machine'
- The brushbar may not be turning. Go to my brushbar isn't turning below
- If the accessory/tool will not pick up, check and clear any blockages

My brushbar isn't turning?

- The brushbar may be clogged, check the brushbar and clear any hair or debris Go to 'Let's talk technical'
- The belt may be broken, Go to 'Let's talk technical'

Warning: To reduce the risk of personal injury, unplug the vacuum before performing maintenance /troubleshooting checks.

Don't forget your accessories!

Order at: www.vax.co.uk/spares-and-solutions

TurboTool

Use the TurboTool for vacuuming your stairs, upholstery and car interiors. It's great for picking up stubborn pet hair.



3 in 1 Tool

1-1-129167-00

3-in-1 tool includes crevice tool for awkward areas and corner, dusting brush for areas such as skirting and an upholstery tool for cleaning sofas, curtains, chair seats and car interiors.



Flexi Crevice Tool

1-1-131393-00

A handy long, flexible tool for getting far behind and around furniture.



Fur and Fluff Tool

1-1-131392-00

Specifically designed to remove extra stubborn pet hair from upholstery, furniture and carpets.



It's quick and easy to register for your **FREE** **2 year guarantee**

Online at: vax.co.uk/guarantees

Please retain your original receipt for proof of purchase.

we're here if you need us

Online vax.co.uk/support

Call: (UK) **0844 412 8455** (ROI) 1-800 928 308

Monday-Friday 8.30am to 6.30pm, Saturday 9.00am to 5.00pm *

Alternatively, you can write to us at:

Vax Ltd., Kingswood Road, Hampton Lovett, Droitwich, Worcestershire, WR9 0QH, UK



You're home.™



@VaxUK

Vax Ltd. Kingswood Road, Hampton Lovett, Droitwich, Worcestershire, WR9 0QH, UK
email: info@vax.co.uk website: vax.co.uk

Version 1.0



EEC Statement of Compliance: Manufacturer/EEC importer: Vax Limited, hereby on our own responsibility, declare that the U86-E2e series is manufactured in compliance with the following Directives:

Safety: 2006/95/EC Low Voltage Directive. **EMC:** 2004/108/EC Electromagnetic Compatibility Directive.



Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice.

© 2014 All rights reserved. VAX®, VAX Lozenge, are trade marks or registered trade marks of Techtronic Floor Care Technology Ltd.