

A QUIET CLEAN WITH POWERFUL PERFORMANCE



LET'S GET STARTED.

Let's talk safety



Basic safety precautions

This vacuum cleaner is intended for household use only and NOT for commercial or industrial use.

- Only use the vacuum cleaner indoors on dry surfaces and keep the area you're cleaning well lit.
- Keep fingers, hair and loose clothing away from moving parts and openings whilst using the vacuum cleaner.
- This vacuum cleaner can be used by children aged from 8



Don'ts

- Don't use this vacuum cleaner if it has been dropped, damaged or left outdoors or the filters not in their original place.
- Don't run over the power cord or use vacuum cleaner if the power cord or plug is damaged. Please contact our Customer Care Line on: 0330 026 8455 (Mon-Fri 8:30am to 6:30pm, Sat 9:00am to 5:00pm).
- Don't handle the plug or use the vacuum cleaner with wet hands.
- Don't pull or carry this vacuum cleaner by the power cord. Don't use the power cord as a handle, pull the power cord around corners, sharp edges or close a door over the power cord. Don't unplug vacuum cleaner by pulling on the power cord.
- Don't lift or carry the vacuum cleaner by the dirt container handle.



Do's

- Turn off all controls on the vacuum cleaner before disconnecting or connecting the power cord.
- Always make sure both the pre-motor/post-motor filters are in place before use.
- Always switch off the vacuum cleaner before disconnecting or connecting the hose and accessories.
- Keep all openings clear and free from debris as this may affect the airflow/suction.
- Always replace the fuse in the plug with a British 13amp fuse.
- Always protect the power cable from heated surfaces and open flames.

Let's talk safety

years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the vacuum cleaner in a safe way and understand the hazards involved. Children shall not play with the vacuum cleaner. Cleaning and user maintenance shall not be made by children without supervision.

- Only Vax recommend tools and accessories should be used with this vacuum cleaner.
- Don't vacuum up any flammable or combustible materials (lighter fluid, petrol, kerosene etc.) or use the vacuum cleaner in an area with explosive vapours or liquid.
- Don't vacuum up hot coals, cigarette butts, matches or smoking hot burning items or use in an area where there may be harmful fluids (chlorine, bleach, and ammonia drain cleaner).
- Don't attempt to remove blockages with sharp objects as this may cause damage to your vacuum cleaner.
- Don't vacuum up hard or sharp objects such as glass, nails, screws or coins etc.
- Don't use the vacuum cleaner with incorrect voltage as this may result in damage or injury to the user. The correct voltage is listed on the ratings label.
- Take extra care when positioning and using the vacuum cleaner on the stairs.
- Use only CE approved 13amp extension cords, non-approved extension cords may overheat. Care should be taken to arrange the extension cord as it can be a trip hazard.
- Store your vacuum cleaner in a cool, dry area. If filters have been cleaned as per user guide instructions ensure they are thoroughly dry before storing away.

PLEASE KEEP INSTRUCTIONS FOR FURTHER USE.

Thank you for buying this Air™Silence Pet.

Taking care of your carpets and hard floors

The Air™ Silence Pet is designed to make vacuuming carpets and hard floors regularly, as effective and efficient as possible and this user guide will help you get the most out of your machine.

Maintaining your carpets and hard floors will ensure they keep their appearance for longer. You've chosen the carpets and hard floor for your home for a reason and Vax will help you take good care of them.

Taking care of your Air™ Silence Pet

Also inside this guide are instructions on maintaining your new machine, so that it's always ready when you are to tackle your carpets and hard floors.

Taking care of you



We're here if you need us. Instead of taking me back to the shop, simply visit:

vax.co.uk/support or call:

(UK) **0330 026 8455** (ROI) 1-800 928 308

Monday-Friday 8:30am to 6:30pm, Saturday 9:00am to 5:00pm

Calls are charged at the UK local rate. Please make a note of the serial number and model number of the product before calling.

Alternatively, you can write to us at:


Vax Ltd., Plot 302, Stonebridge Cross Business Park, Hampton Lovett, Droitwich, WR9 0LW, UK

This user guide can be found online at: vax.co.uk/support



Let us know what you think @VaxUK

Contents



Initial Setup for normal operation

- 1. Use the base accessories.
 - Shortest hose.
 - Extension tube set to shortest practicable length.
- 2. Clean filters installed.
- 3. Dust receptacle empty.
- 4. All Bleeds must be closed.
- 5. Variable Power set to Maximum.
- 6. Floor heads/tools set to Carpet Mode for carpet cleaning.
- 7. Mechanical Agitation turned ON for carpet cleaning.
- 8. Floor heads/tools set to Hard Floor Mode for hard floor cleaning.
- 9. Mechanical Agitation turned OFF for hard floor cleaning.

Air™ Silence Pet

Included with your machine



Accessory Hose and Handle



Telescopic Extension Tube



Combination Floor Head



3-in-1 Tool



Tool Connector



Post-motor Filter



Pre-motor Filter



TurboTool



Hard Floor Tool

Getting to know your machine



Dirt container release button

Dirt container

Carry handle

Cord rewind button

Post-motor filter cover and release button

Power On/Off button

Floor head parking slot

Post-motor filter (hidden)



Technical Specification

Name Air Silence Pet Voltage See rating label on machine for details Wattage See rating label on machine for details Cord length 6.5m Weight 5.5kg

Accessories & Consumables

Filter kit (Type 111)* 1-1-134395-00

TurboTool (Type 5)* 1-1-134418-00


Tool connector (Type 1)*
1-1-133838-00

Combination floor tool (Type 6)*
1-1-134330-00
3-in-1 Tool (Type 1)
1-1-129167-00

Getting started

PLEASE READ 'LET'S TALK SAFETY' AT THE BEGINNING BEFORE USE

Assembling your machine



Press both buttons at the end of hose and insert into hose entry point.



Insert hose grip into telescopic extension tube.



Press button on telescopic extension tube and adjust to required length.



Insert the other end of the telescopic tube into the floor head.

Carrying your machine

Always use the carry handle to lift and carry your vacuum cleaner. Do not use the dirt container release handle. The dirt container should be locked into place before lifting the vacuum cleaner by the carry handle.





Before you begin cleaning

- Always switch off and unplug the vacuum cleaner before connecting or disconnecting the hose/attachments, or removing and emptying the dirt container.
- The vacuum cleaner is equipped with a thermal cut-out. If for any reason the vacuum cleaner does overheat the thermostat will automatically turn the vacuum cleaner off. If this happens, switch the vacuum cleaner off and unplug from electrical socket. Remove and empty the dirt container also check the vacuum cleaner for blockages. Allow the vacuum cleaner to cool for approximately 1 hour (if you have cleaned the filters please wait 24 hours for the filters to fully dry before putting back into the vacuum).
- · Filters require cleaning at least every 3 months.
- If the vacuum cleaner is blocked, switch off and unplug before removing the blockage.
- When using the accessories always make sure the brushbar is switched to the off position.


IMPORTANT: The base of the vacuum cleaner should always be positioned flat on the floor when starting and in use. The dirt container should be locked into place before lifting the vacuum cleaner by the carry handle.

Using your machine

How to use



Unwind the power cord. Do not pull further than the yellow marker.



Plug into mains and press the on/off button to switch the machine on.




For use on carpets click rocker switch forward. For use on hard floors click rocker switch back.



Raise brushes for carpets.



Lower brushes for hard floors.




Slide vent cover on hose grip open to reduce suction if required.

Using accessories



Choose an accessory and push onto the telescopic extension tube or hose.



The tool connector must be fitted on the hose when using the TurboTool.

When unwinding the power cord always pull out to the yellow marker but no further.



Taking care of your machine

Emptying and cleaning the dirt container




Lift dirt container release handle. The dirt bin lid will 'pop up'. Remove dirt container.



Hold dirt container over a bin and press dirt release clip on the bottom of the dirt container, allowing dirt and debris to fall out.

Cleaning the shroud



Twist separator anti-clockwise, pull to remove.



Tap the shroud over a bin to remove dirt and debris.

Don't over fill the dirt container to avoid blocking the air flow through the vacuum cleaner.

Taking care of your machine

Cleaning the pre-motor filter



Lift dirt container release handle. The dirt bin lid will 'pop up'.



Pull tab on pre-motor filter to remove.



Tap the filter over a bin to remove any dirt and debris.



24hr

Rinse the filter under water (40°C Max). Leave to dry for 24 hours before placing back in the machine.

IMPORTANT: The exhaust filter is designed to offer long life with no maintenance. The filter should be checked periodically and when heavily discoloured it should be replaced. Please do not wash, scrub or brush the filter as this will damage the delicate filter media.

Post-motor filter maintenance



Press down the release button on the post-motor filter cover, pull to remove.



Press down tab at the top of the filter and pull to remove.




Check the post-motor filter for discolouration.



Storing your machine



Press cord rewind button to retract cord.



Place floor head into parking slot on the back of vacuum cleaner for storage and carrying.

Clean the pre-motor filter every time the dirt container is emptied and replace the post-motor filter every 12 months.



Let's talk technical

IMPORTANT: Remove accessory from hose or telescopic extension tube before performing maintenance or trouble shooting checks.

Removing blockages from the TurboTool




Slide the locking ring to remove.



Lift and separate the housing.



Using a pair of scissors, cut any hair or debris free from around the brushes.



Line up the tabs on front of housing and push together to refit. Slide locking ring into groove to secure.

Removing blockages from the hose



Insert a broom handle or similar blunt instrument into the hose to remove blockage.

To test for a blockage in the hose, drop a small ball of paper into the hose. The paper will drop through if the hose is clear.



Don't forget your accessories!

Order at: www.vax.co.uk/spares-and-solutions

Pro cleaning kit 1-1-133326-00

All our best tools all in one kit that makes cleaning your home quicker, easier and with even better results. We've taken care of cleaning all of the hard to reach areas such as on top of cupboards and in between blinds to the dust that collates behind and within the radiator.



TurboTool (Type 5) 1-1-134418-00

Use the TurboTool for vacuuming your stairs, upholstery and car interiors. It's great for picking up stubborn pet hair.



Fur 'n' Fluff Tool 1-1-131392-00

Specifically designed to remove extra stubborn pet hair from upholstery, furniture and carpets.



Notes

What to do if it goes wrong

Problem

Solution

There is an accessory missing

• Check the 'This pack contains' panel on the box to make sure the part is included with your machine.

Why does my vacuum cleaner have no power?

- The plug may not be fully pushed into the electrical socket.
- Check the fuse in the plug if this needs replacing, always replace with a British 13amp fuse.
- The motor thermostat may have tripped. If this has happened, unplug the vacuum cleaner. Remove and empty the dirt container and check the hose for blockages.
 Clean the filters and allow the vacuum cleaner to cool for approximately 1 hour (if you have washed the filters you will need to wait 24 hours for the filters to fully dry before putting them back into the vacuum cleaner).

Why won't the vacuum cleaner pick up?

- The dirt container may not be correctly fitted, remove the dirt container from the vacuum cleaner and check it's assembled correctly, refit ensuring it's locked into place.
- The filter may be clogged, clean the filter. Go to 'Taking care of your machine'.
- The dirt container may be blocked, empty the dirt container. Go to 'Taking care
 of your machine'.
- There may be a blockage in the hose/tube. Disconnect from the vacuum cleaner and carefully remove any blockages. Go to 'Let's talk technical'.

• The filters may be clogged, clean the filter. Go to 'Taking care of your machine'.

Why is dust escaping from the vacuum?

IMPORTANT: To reduce the risk of personal injury, unplug the vacuum before performing maintenance/ troubleshooting checks.

It's quick and easy to register for your **FREE**

6 year guarantee

Online at: vax.co.uk/guarantees

Please retain your original receipt for proof of purchase.

we're here if you need us

Online vax.co.uk/support

Call: (UK) 0330 026 8455 (ROI) 1-800 928 308

Monday-Friday 8:30am to 6:30pm, Saturday 9:00am to 5:00pm*

Alternatively, you can write to us at-

Vax Ltd, Plot 302, Stonebridge Cross Business Park, Hampton Lovett, Droitwich, Worcestershire, WL9 0LW, UK

[†] Registration required. Terms and conditions apply, see vax.co.uk for details.

^{*} Calls are charged at the UK local rate. Please make a note of the serial number and model number of the product before calling.

GET IN TOUCH

EEC Statement of Compliance: Manufacturer/EEC importer: Vax Limited, hereby on our own responsibility, declare that the C85-AW-Pe manufactured in compliance with the following Directives: **Safety**: 2006/95/EC Low Voltage Directive. **EMC**: 2004/108/EC Electromagnetic Compatibility Directive.

Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice.

© 2015 All rights reserved. VAX®, VAX Lozenge, are trade marks or registered trade marks of Techtronic Floor Care Technology Ltd.

