



**Built-in oven HBA13B1.0B**



**BOSCH**

[en] Instruction manual



**Safety precautions** ..... 4

Before installation ..... 4

Safety notes ..... 4

Causes of damage ..... 4

**Your new oven** ..... 5

Control panel ..... 5

Buttons and display ..... 5

Function selector ..... 5

Temperature selector ..... 5

Cooking compartment ..... 6

Accessories ..... 6

**Before using the oven for the first time** ..... 8

Setting the clock ..... 8

Heating up the oven ..... 8

Cleaning the accessories ..... 8

**Setting the oven** ..... 8

Type of heating and temperature ..... 8

**Setting the time-setting options** ..... 9

Timer ..... 9

Cooking time ..... 9

End time ..... 10

Clock ..... 10

**Childproof lock** ..... 10

**Changing the basic settings** ..... 11

**Care and cleaning** ..... 11

Cleaning agents ..... 11

Detaching and refitting the rails ..... 12

Detaching and attaching the oven door ..... 12

Removing the door cover ..... 12

Removing and installing the door panels ..... 13

**Troubleshooting** ..... 13

Malfunction table ..... 13

Replacing the bulb in the oven ceiling light ..... 14

Glass cover ..... 14

**After-sales service** ..... 14

E number and FD number ..... 14

**Energy and environment tips** ..... 14

Saving energy ..... 14

Environmentally-friendly disposal ..... 14

**Tested for you in our cooking studio** ..... 15

Cakes and pastries ..... 15

Baking tips ..... 16

Meat, poultry, fish ..... 17

Tips for roasting and grilling ..... 19

Preprepared products ..... 19

Special dishes ..... 20

Defrost ..... 20

Drying ..... 21

Preserving ..... 21

**Acrylamide in foodstuffs** ..... 22

**Test dishes** ..... 22

Baking ..... 22

Grilling ..... 23

Additional information on products, accessories, replacement parts and services can be found at [www.bosch-home.com](http://www.bosch-home.com) and in the online shop [www.bosch-eshop.com](http://www.bosch-eshop.com)

## **⚠ Safety precautions**

Please read this instruction manual carefully. Please keep the instruction and installation manuals in a safe place. Please pass on these manuals to the new owner if you sell the appliance.

### **Before installation**

#### **Damage during transport**

Check the appliance for damage after unpacking it. Do not connect the appliance if it has been damaged in transit.

#### **Electrical connection**

Only a licensed expert may connect the appliance. You will lose your warranty entitlement in the event of any damage caused by incorrect connection.

### **Safety notes**

This appliance is intended for domestic use only. This appliance must only be used for food preparation.

Adults and children must not operate the appliance without supervision,

- if they are physically or mentally incapable of doing so or
- if they have insufficient knowledge or experience.

Never let children play with the appliance.

### **Hot cooking compartment**

#### **Risk of burns!**

- Never touch the interior surfaces of the cooking compartment or the heating elements. Open the appliance door carefully. Hot steam may escape. Small children must be kept at a safe distance from the appliance.
- Never prepare food containing large quantities of drinks with a high alcohol content. Alcoholic vapours can catch fire in the cooking compartment. Only use small quantities of drinks with a high alcohol content and open the appliance door carefully.

#### **Risk of fire!**

- Never store combustible items in the cooking compartment. Never open the appliance door if there is smoke inside. Switch off the appliance. Pull out the mains plug or switch off the circuit breaker in the fuse box.
- Do not place greaseproof paper loosely over accessories during preheating. A draught is created when the appliance door is opened. The greaseproof paper may come into contact with the heating element and catch fire. Always weight down the greaseproof paper with a dish or a baking tin. Only cover the surface required with greaseproof paper. The greaseproof paper must not protrude over the accessories.

#### **Risk of short circuit!**

Never trap connecting cables of electrical appliances in the hot appliance door. The cable insulation could melt.

#### **Risk of scalding!**

Never pour water into the hot cooking compartment. This will produce hot steam.

### **Hot accessories and ovenware**

#### **Risk of burns!**

Never remove ovenware or accessories from the cooking compartment without an oven cloth or oven gloves.

### **Improper repairs**

#### **Risk of electric shock!**

Improper repairs are dangerous. Repairs may only be carried out by one of our trained after-sales engineers. If the appliance is defective, pull out the mains plug or switch off the appliance at the circuit breaker in the fuse box. Call the after-sales service.

## **Causes of damage**

### **Caution!**


- Accessories, foil, greaseproof paper or ovenware on the cooking compartment floor: do not place accessories on the cooking compartment floor. Do not cover the cooking compartment floor with any sort of foil or greaseproof paper. Do not place ovenware on the cooking compartment floor if a temperature of over 50 °C has been set. This will cause heat to accumulate. The baking and roasting times will no longer be correct and the enamel will be damaged.
- Water in a hot cooking compartment: do not pour water into the cooking compartment when it is hot. This will cause steam. The temperature change can cause damage to the enamel.
- Moist food: do not store moist food in the cooking compartment when it is closed for prolonged periods. This will damage the enamel.
- Fruit juice: when baking particularly juicy fruit pies, do not pack the baking tray too generously. Fruit juice dripping from the baking tray leaves stains that cannot be removed. If possible, use the deeper universal pan.
- Cooling with the appliance door open: only allow the cooking compartment to cool when it is closed. Even if the appliance door is only open a little, front panels of adjacent units could be damaged over time.
- Heavily soiled oven seal: if the oven seal is heavily soiled, the oven door will no longer close properly when the oven is in operation. The fronts of adjacent units could be damaged. Always keep the oven seal clean.
- Oven door as a bearing surface: do not stand or place objects on the oven door when it is open. Do not place ovenware or accessories on the oven door.
- Carrying the appliance: do not carry or hold the appliance by the door handle. The door handle cannot support the weight of the appliance and could break.

# Your new oven

Here you will learn about your new oven. The control panel and the individual operating controls are explained. You will find information on the cooking compartment and the accessories.

## Control panel

Here, you will see an overview of the control panel. All of the symbols never appear in the display at the same time. Ανάλογα Depending on the appliance model, individual details may differ.



| Επεξήγηση |                      |
|-----------|----------------------|
| 1         | Function selector    |
| 2         | Buttons and display  |
| 3         | Temperature selector |

### Buttons

The sensors are located under the individual buttons. They must not be pressed too firmly. Only touch the corresponding symbol.

### Buttons and display

You can use the buttons to set various additional functions. You can read the values that you have set in the display.

| Button               | Use                                                      |
|----------------------|----------------------------------------------------------|
| Time-setting options | Selects the timer , cooking time , end time  and clock . |
| Childproof lock      | Locks and unlocks the control panel.                     |
| - Minus              | Decreases the set values.                                |
| + Plus               | Increases the set values.                                |

The time-setting option that is currently selected in the display is indicated by the brackets [ ] around the corresponding symbol. Exception: for the clock, the symbol only lights up when you are making changes.

### Function selector

Use the function selector to set the type of heating.

| Setting      | Use                                                                                                                                                        |
|--------------|------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Off position | The oven switches off.                                                                                                                                     |
| 3D hot air*  | For cakes and pastries on one to three levels. The fan distributes the heat from the heating ring in the back panel evenly around the cooking compartment. |

\* Type of heating used to determine the energy efficiency class in accordance with EN50304.

| Setting           | Use                                                                                                                                                              |
|-------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Hot air grilling  | For roasting meat, poultry and whole fish. The grill element and the fan switch on and off alternately. The fan causes the hot air to circulate around the dish. |
| Grill, large area | For grilling steaks, sausages, bread and pieces of fish. The whole area below the grill heating element becomes hot.                                             |
| Defrost           | For defrosting, e.g. meat, poultry, bread and cakes. The fan causes the warm air to circulate around the dish.                                                   |
| Oven light        | Switches on the oven light.                                                                                                                                      |

\* Type of heating used to determine the energy efficiency class in accordance with EN50304.

When you make settings, the oven light in the cooking compartment switches on.

### Temperature selector

The temperature selector is used to set the temperature or grill setting.


| Setting      | Meaning                                                                                                                                 |
|--------------|-----------------------------------------------------------------------------------------------------------------------------------------|
| Off position | The oven does not heat up.                                                                                                              |
| 50-270       | Temperature range<br>The temperature in the cooking compartment in °C.                                                                  |
| I, II, III   | Grill settings<br>The grill settings for "Grill, large area" .<br>I = setting 1, low<br>II = setting 2, medium<br>III = setting 3, high |

When the oven is heating, the symbol lights up in the display. It goes out during pauses in the heating. For the Defrost type of heating, the symbol does not light up.

## Cooking compartment

The oven light is located in the cooking compartment. A cooling fan protects the oven from overheating.

### Oven light

During operation, the oven light in the cooking compartment is on. The  setting on the function selector can be used to switch on the light without heating the oven.

### Cooling fan


The cooling fan switches on and off as required. The hot air escapes above the door. Caution: do not cover the ventilation slots. Otherwise the oven will overheat.

So that the cooking compartment cools down more quickly after operation, the cooling fan continues to run for a certain period afterwards.

## Accessories

The accessories can be inserted into the oven at 5 different levels.

You can pull out the accessories two thirds of the way without them tipping. This allows dishes to be removed easily.



The accessories can become deformed when they get hot. As soon as they have cooled down, the deformation disappears with no effect on the function.


You can buy accessories from the after-sales service, from specialist retailers or online. Please specify the HEZ number.


| Special accessories | HEZ number | Use                                                                                                                                                                                                                                                                                                                                             |
|---------------------|------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Wire rack           | HEZ334000  | For ovenware, cake tins, joints, grilled items and frozen meals.                                                                                                                                                                                                                                                                                |
| Enamel baking tray  | HEZ331000  | For cakes and biscuits.<br>Slide the baking tray into the oven with the sloping edge facing towards the oven door.                                                                                                                                                                                                                              |
| Universal pan       | HEZ332000  | For moist cakes, pastries, frozen meals and large joints. It can also be used to catch dripping fat when you are grilling directly on the wire rack.<br>Slide the universal pan into the oven with the sloping edge facing the oven door.                                                                                                       |
| Wire insert         | HEZ324000  | For roasting. Always place the wire rack in the universal pan. This ensures that dripping fat and meat juices are collected.                                                                                                                                                                                                                    |
| Grill tray          | HEZ325000  | Use for grilling instead of the wire rack or as a splatter guard, so that the oven does not become very dirty. Only use the grill tray in the universal pan.<br>Grilling on the grill tray: only use at shelf height 1, 2 and 3.<br>Using the grill tray as a splatter guard: insert the universal pan with the grill tray under the wire rack. |
| Glass pan           | HEZ336000  | A deep baking tray made of glass. Can also be used as a serving dish.                                                                                                                                                                                                                                                                           |
| Pizza tray          | HEZ317000  | Ideal for pizza, frozen products or large round cakes. You can use the pizza tray instead of the universal pan. Place the baking tray on the wire rack and proceed according to the details in the tables.                                                                                                                                      |



### Wire rack

For ovenware, cake tins, joints, grilled items and frozen meals.


Insert the wire rack with the curvature pointing downward .



### Insert grid

For roasting.

Always place the insert grid in the universal pan. This ensures that dripping fat and meat juices are collected.



### Universal pan

For moist cakes, pastries, frozen meals and large joints. It can also be used to catch dripping fat when grilling directly on the wire rack.

Slide the universal pan into the oven with the sloping edge facing the oven door.

## Special accessories

You can purchase special accessories from the after-sales service or specialist retailers. You will find a comprehensive range of products for your oven in our brochures and on the Internet. The availability of special accessories and whether it is possible to order them online may vary depending on your country. Please see the sales brochures for more details.

Not all optional accessories are suitable for every appliance. When purchasing, please always quote the exact designation (E-no.) of your appliance.

| <b>Special accessories</b>                                                     | <b>HEZ number</b> | <b>Use</b>                                                                                                                                                                                                                                                                                             |
|--------------------------------------------------------------------------------|-------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Bakestone                                                                      | HEZ327000         | The bakestone is perfect for preparing home-made bread, bread rolls and pizzas which require a crispy base. The bakestone must always be preheated to the recommended temperature.                                                                                                                     |
| Enamel baking tray with non-stick coating                                      | HEZ331010         | Cakes and biscuits can be removed more easily from the baking tray. Slide the baking tray into the oven with the sloping edge facing towards the oven door.                                                                                                                                            |
| Universal pan with non-stick coating                                           | HEZ332010         | Moist cakes, pastries, frozen meals and large joints can be removed more easily from the universal pan. Slide the universal pan into the oven with the sloping edge facing the oven door.                                                                                                              |
| Profi extra-deep pan with wire insert                                          | HEZ333000         | Ideally suited for preparing large amounts.                                                                                                                                                                                                                                                            |
| Lid for the Profi extra-deep pan                                               | HEZ333001         | The lid converts the Profi extra-deep pan into the Profi roasting dish.                                                                                                                                                                                                                                |
| Glass roasting dish                                                            | HEZ915001         | The glass roasting dish is suitable for stews and bakes that are cooked in the oven. It is ideally suited to automatic programmes or automatic roasting.                                                                                                                                               |
| Telescopic shelves                                                             |                   |                                                                                                                                                                                                                                                                                                        |
| 2-level                                                                        | HEZ338250         | The pull-out rails at levels 2 and 3 allow you to pull accessories out further without them tipping.                                                                                                                                                                                                   |
| 3-level                                                                        | HEZ338352         | The pull-out rails at levels 1, 2 and 3 allow you to pull accessories out further without them tipping.<br>The 3-level pull-out is not suitable for appliances that have a rotary spit.                                                                                                                |
| 3-level complete pull-out                                                      | HEZ338356         | The pull-out rails at levels 1, 2 and 3 allow you to pull accessories out fully without them tipping.<br>The 3-level complete pull-out is not suitable for appliances that have a rotary spit.                                                                                                         |
| 3-level complete pull-out with stop function                                   | HEZ338357         | The pull-out rails at levels 1, 2 and 3 allow you to pull accessories out fully without them tipping. The pull-out rails lock in position allowing accessories to be easily placed on top.<br>The 3-level complete pull-out with stop function is not suitable for appliances that have a rotary spit. |
| Self-cleaning side walls                                                       |                   |                                                                                                                                                                                                                                                                                                        |
| Appliance with one oven light                                                  | HEZ339020         | You can retrofit side walls so that the cooking compartment automatically cleans itself during operation.                                                                                                                                                                                              |
| Appliances with one oven light and automatic roasting                          | HEZ339020         | You can retrofit side walls so that the cooking compartment automatically cleans itself during operation.                                                                                                                                                                                              |
| Self-cleaning oven ceiling and side walls                                      |                   |                                                                                                                                                                                                                                                                                                        |
| Appliances with one oven light and a folding grill element                     | HEZ329020         | You can retrofit the ceiling and side walls so that the cooking compartment automatically cleans itself during operation.                                                                                                                                                                              |
| Appliances with two oven lights and a folding grill element                    | HEZ329022         | You can retrofit the ceiling and side walls so that the cooking compartment automatically cleans itself during operation.                                                                                                                                                                              |
| Appliances with one oven light, a folding grill element and a meat thermometer | HEZ329027         | You can retrofit the ceiling and side walls so that the cooking compartment automatically cleans itself during operation.                                                                                                                                                                              |
| Steam filter                                                                   | HEZ329000         | You can retrofit this in your oven. The steam filter filters out grease particles from the exhaust air, thereby reducing odours.<br>Only for appliances with a 6, 7 or 8 as the second digit in the E-no. (e.g. HBA38B750).                                                                            |
| System steamer                                                                 | HEZ24D300         | For easy preparation of vegetables and fish.                                                                                                                                                                                                                                                           |

## After-sales service products

You can obtain suitable care and cleaning agents and other accessories for your domestic appliances from the after-sales

service, specialist retailers or (in some countries) online via the e-Shop. Please specify the relevant product number.

|                                                                 |                                                                                                                                                                                    |
|-----------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Cleaning cloths for stainless-steel surfaces Product no. 311134 | Reduces the build-up of dirt. Impregnated with a special oil for perfect maintenance of your appliance's stainless-steel surfaces.                                                 |
| Oven and grill cleaning gel Product no. 463582                  | For cleaning the cooking compartment. The gel is odourless.                                                                                                                        |
| Microfibre cloth with honeycomb structure Product no. 460770    | Especially suitable for cleaning delicate surfaces, such as glass, glass ceramic, stainless steel or aluminium. The microfibre cloth removes liquid and grease deposits in one go. |
| Door lock Product no. 612594                                    | To prevent children from opening the oven door. The locks on different types of appliance door are screwed in differently. See the information sheet supplied with the door lock.  |

## Before using the oven for the first time

In this section, you can find out what you must do before using your oven to prepare food for the first time. First read the section on *Safety information*.

### Setting the clock

After the appliance has been connected, the ⌚ symbol and four zeros light up in the display. Set the clock.

1. Press the ⌚ button.

The time 12:00 is shown in the display.

2. Use the + or - button to set the clock.

After a few seconds, the time that has been set is adopted.

### Heating up the oven

To remove the new cooker smell, heat up the oven when it is empty and closed. An hour of 3D hot air at 240 °C is ideal for this purpose. Ensure that no packaging remnants have been left in the cooking compartment.

1. Use the function selector to set 3D hot air.
2. Set the temperature selector to 240 °C.

After an hour, switch off the oven. To do so, turn the function selector to the off position.

### Cleaning the accessories

Before you use the accessories for the first time, clean them thoroughly with hot soapy water and a soft dish cloth.


## Setting the oven

There are various ways in which you can set your oven. Here we will explain how you can select the desired type of heating and temperature or grill setting. You can select the oven cooking time and end time for your dish. Please refer to the section on *Setting the time-setting options*.


### Type of heating and temperature

Example in the picture: 3D hot air at 190 °C.

1. Use the function selector to set the type of heating.



2. Set the temperature or grill setting using the temperature selector.



The oven begins to heat up.

### Switching off the oven


Turn the function selector to the off position.

### Changing the settings

The type of heating and temperature or grill setting can be changed at any time using their respective selectors.




# Setting the time-setting options

Your oven has various time-setting options. You can use the  button to call up the menu and switch between the individual functions. All the time symbols are lit when you can make settings. The brackets [ ] show you which time-setting option you have currently selected. A time-setting option which has already been set can be changed directly with the **+** or **-** button when the relevant time symbol is in brackets.

## Timer

You can use the timer as a kitchen timer. It runs independently of the oven. The timer has its own signal. In this way, you can tell whether it is the timer or a cooking time which has elapsed.


### 1. Press the button once.

The time symbols light up in the display and the brackets are around .


### 2. Use the **+** or **-** button to set the timer duration.

Default value for **+** button = 10 minutes

Default value for **-** button = 5 minutes

After a few seconds, the time setting is adopted. The timer starts. The [] symbol lights up in the display and the timer duration counts down. The other time symbols go out.

### The timer duration has elapsed

A signal sounds. 00:00 is shown in the display. Use the  button to switch off the timer.

### Changing the timer duration






Use the **+** or **-** button to change the timer duration. After a few seconds, the change is adopted.

### Cancelling the timer duration

Use the **-** button to reset the timer duration to 00:00. The change will be adopted after a few seconds. The timer is switched off.

### Checking the time settings

If several time-setting options are set, the relevant symbols are illuminated on the display. The symbol for the time-setting option that is visible in the display is shown in brackets.

To call up the , ,  or , press the  button repeatedly until the brackets are around the relevant symbol. The display shows the value for a few seconds.

## Cooking time


The cooking time for your dish can be set on the oven. When the cooking time has elapsed, the oven switches itself off automatically. This means that you do not have to interrupt other work to switch off the oven. The cooking time cannot be accidentally exceeded.

Example in the picture: cooking time 45 minutes.

### 1. Use the function selector to set the type of heating.

### 2. Set the temperature or grill setting using the temperature selector.

### 3. Press the button twice.

00:00 is shown in the display. The time symbols light up and the brackets are around .




### 4. Use the **+** or **-** button to set the cooking time.



Default value for **+** button = 30 minutes

Default value for **-** button = 10 minutes




The oven will start up after a few seconds. The cooking time counts down in the display and the [] symbol lights up. The other time symbols go out.


### The cooking time has elapsed

A signal sounds. The oven stops heating. 00:00 is shown in the display. Press the  button. You can set a new cooking time using the **+** or **-** button. Or press the  button twice and turn the function selector to the off position. The oven switches off.

### Changing the cooking time






Use the **+** or **-** button to change the cooking time. After a few seconds, the change is adopted. If the timer has been set, press the  button beforehand.

### Cancelling the cooking time

Use the **-** button to reset the cooking time to 00:00. After a few seconds, the change is adopted. The cooking time is cancelled. If the timer has been set, press the  button beforehand.

### Checking the time settings

If several time-setting options are set, the relevant symbols are illuminated on the display. The symbol for the time-setting option that is visible in the display is shown in brackets.



To call up the , ,  or , press the  button repeatedly until the brackets are around the relevant symbol. The display shows the value for a few seconds.


## End time


You can change the time at which you wish your dish to be ready. The oven starts automatically and finishes at the desired time. You can, for example, put your dish in the cooking compartment in the morning and set the cooking time so that it is ready at lunch time.

Ensure that food is not left in the cooking compartment for too long as it may spoil.

Example in the picture: it is 10:30 am, the cooking time is 45 minutes and the oven is required to finish cooking at 12:30 pm.






1. Adjust the function selector.
2. Set the temperature selector.
3. Press the  button twice.
4. Use the **+** or **-** button to set the cooking time.
5. Press the  button.

The brackets are around . The time when the dish will be ready is displayed.



6. Use the **+** or **-** button to set a later end time.



After a few seconds, the oven adopts the settings and switches to standby position. The time at which the dish will be ready is shown in the display and the  symbol is in brackets. The  and  symbols go out. When the oven starts, you can see the cooking time counting down in the display and the  symbol is in brackets. The  symbol goes out.



## Childproof lock

The oven has a childproof lock to prevent children switching it on accidentally.


The oven will not react to any settings. The timer and clock can also be set when the childproof lock has been activated.

If the type of heating and temperature or grill setting have been set, the childproof lock interrupts the heating.


## The cooking time has elapsed

A signal sounds. The oven stops heating. 00:00 is shown in the display. Press the  button. You can set a new cooking time using the **+** or **-** button. Or press the  button twice and turn the function selector to the off position. The oven switches off.

## Changing the end time






Use the **+** or **-** button to change the end time. After a few seconds, the change is adopted. If the timer has been set, first press the  button twice. Do not change the end time if the cooking time has already started to elapse. The cooking result would no longer be correct.

## Cancelling the end time


Use the **-** button to reset the end time to the current time. After a few seconds, the change is adopted. The oven starts. If the timer has been set, first press the  button twice.


## Checking the time settings

If several time-setting options are set, the relevant symbols are illuminated on the display. The symbol for the time-setting option that is visible in the display is shown in brackets.

To call up the  timer,  cooking time,  end time or  clock, press the  button repeatedly until the brackets are around the relevant symbol. The display shows the value for a few seconds.



## Clock

After the appliance is connected or following a power cut, the  symbol and four zeros light up in the display. Set the clock.

1. Press the  button.  
The time 12:00 is shown in the display.
2. Use the **+** or **-** button to set the clock.  
After a few seconds, the time that has been set is adopted.

## Changing the clock

No other time-setting option should have been set.

1. Press the  button four times.  
The time symbols light up in the display and the brackets are around .
2. Use the **+** or **-** button to change the clock.  
After a few seconds, the time that has been set is adopted.


## Hiding the clock

You can hide the clock. For more information, please refer to the section *Changing the basic settings*.


## Activating the childproof lock


No cooking time or end time should have been set.

Press and hold the  button for approx. four seconds.

The  symbol appears in the display. The childproof lock is activated.

## Deactivating the childproof lock

Press and hold the  button for approx. four seconds.

The  symbol goes out in the display. The childproof lock is deactivated.

# Changing the basic settings

Your oven has various basic settings. These settings can be customised to suit your requirements.

| Basic setting                                                               | Selection 1        | Selection 2                    | Selection 3        |
|-----------------------------------------------------------------------------|--------------------|--------------------------------|--------------------|
| <b>c1</b> Clock display                                                     | always*            | only with the $\ominus$ button | -                  |
| <b>c2</b> Signal duration upon completion of a cooking time or timer period | approx. 10 seconds | approx. 2 minutes*             | approx. 5 minutes  |
| <b>c3</b> Waiting time until a setting is applied                           | approx. 2 seconds  | approx. 5 seconds*             | approx. 10 seconds |

\* Factory setting

No other time-setting option should have been set.

1. Press and hold the  $\ominus$  button for approx. 4 seconds.  
The current basic setting for the clock display is shown in the display, e.g. c1 1 for selection 1.
2. Use the **+** or **-** button to change the basic setting.
3. Confirm by pressing the  $\ominus$  button.  
The next basic setting appears in the display. You can scroll through all levels with the  $\ominus$  button and change the setting with the **+** or **-** button.
4. To finish, press and hold the  $\ominus$  button for approx. 4 seconds.  
All basic settings are applied.

You may change the basic settings at any time.

# Care and cleaning

With good care and cleaning, your oven will remain clean and fully-functioning for a long time to come. Here we will explain how to maintain and clean your oven correctly.

## Notes

- Slight differences in the colours on the front of the oven are caused by the use of different materials, such as glass, plastic and metal.
- Shadows on the door panel which look like streaks, are caused by reflections made by the oven light.
- Enamel is baked on at very high temperatures. This can cause some slight colour variations. This is normal and does not affect their function. The edges of thin trays cannot be completely enamelled. As a result, these edges can be rough. This will not impair the anti-corrosion protection.

## Cleaning agents

To ensure that the different surfaces are not damaged by using the wrong cleaning agent, observe the information in the table. Do not use

- sharp or abrasive cleaning agents,
- cleaning agents with a high concentration of alcohol,
- hard scouring pads or sponges,
- high-pressure cleaners or steam cleaners.

Wash new sponge cloths thoroughly before use.

| Area       | Cleaning agents                                                                                                     |
|------------|---------------------------------------------------------------------------------------------------------------------|
| Oven front | Hot soapy water:<br>Clean with a dish cloth and dry with a soft cloth. Do not use glass cleaners or glass scrapers. |

| Area                           | Cleaning agents                                                                                                                                                                                                                                                                                                                                                                                                        |
|--------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Stainless steel                | Hot soapy water:<br>Clean with a dish cloth and dry with a soft cloth. Remove flecks of limescale, grease, starch and albumin (e.g. egg white) immediately. Corrosion can form under such residues.<br><br>Special stainless steel cleaning products suitable for warm surfaces are available from our after-sales service or from specialist retailers. Apply a thin layer of the cleaning product with a soft cloth. |
| Door panels                    | Glass cleaner:<br>Clean with a soft cloth. Do not use a glass scraper.                                                                                                                                                                                                                                                                                                                                                 |
| Door cover                     | Stainless steel cleaning agents (available from our after-sales service or from specialist retailers):<br>Please observe the manufacturer's instructions.                                                                                                                                                                                                                                                              |
| Cooking compartment            | Hot soapy water or a vinegar solution:<br>Clean with a dish cloth.<br><br>If there are heavy deposits of dirt, use a stainless steel scouring pad or oven cleaner. Only use when the cooking compartment is cold.<br><br>It is best to use the self-cleaning function. Observe the instructions in the <i>Self-cleaning</i> section when doing so.                                                                     |
| Glass cover for the oven light | Hot soapy water:<br>Clean with a dish cloth.                                                                                                                                                                                                                                                                                                                                                                           |
| Shelves                        | Hot soapy water:<br>Soak and clean with a dish cloth or brush.                                                                                                                                                                                                                                                                                                                                                         |
| Telescopic shelves             | Hot soapy water:<br>Clean with a dish cloth or a brush.<br><br>Do not soak. Clean in the dishwasher, or in the oven as part of the self-cleaning programme. The rails may be damaged causing them to jam.                                                                                                                                                                                                              |


| Area        | Cleaning agents                                                |
|-------------|----------------------------------------------------------------|
| Accessories | Hot soapy water:<br>Soak and clean with a dish cloth or brush. |

## Detaching and refitting the rails

The rails can be removed for cleaning. The oven must have cooled down.

### Detaching the rails


1. Lift up the front of the rail
2. and unhook it (figure A).
3. Then pull the whole rail forward
4. and remove it (Fig. B).



Clean the rails with cleaning agent and a sponge. For stubborn deposits of dirt, use a brush.

### Refitting the rails

1. First insert the rail into the rear socket, press it to the back slightly (figure A),
2. and then hook it into the front socket (figure B).




The rails fit both the left and right sides. The kinked section must always be at the bottom.

## Detaching and attaching the oven door

For cleaning purposes and to remove the door panels, you can detach the oven door.

The oven door hinges each have a locking lever. When the locking levers are closed (figure A), the oven door is secured in place. It cannot be detached. When the locking levers are open in order to detach the oven door (Fig. B), the hinges are locked. They cannot snap shut.




### ⚠ Risk of injury!

Whenever the hinges are not locked, they snap shut with great force. Ensure that the locking levers are always fully closed or, when detaching the oven door, fully open.

### Detaching the door


1. Open the oven door fully.
2. Fold up the two locking levers on the left and right (figure A).
3. Close the oven door as far as the limit stop. With both hands, grip the door on the left and right-hand sides. Close the door a little further and pull it out (figure B).




### Attaching the door

Reattach the oven door in the reverse sequence to removal.

1. When attaching the oven door, ensure that both hinges are inserted straight into the opening (figure A).
2. The notch on the hinge must engage on both sides (figure B).



3. Fold back both locking levers (figure C). Close the oven door.



### ⚠ Risk of injury!


If the oven door falls out accidentally or a hinge snaps shut, do not reach into the hinge. Call the after-sales service.

## Removing the door cover

The oven door cover can become discoloured. To carry out thorough cleaning, you can remove the cover.

1. Open the oven door fully.
2. Unscrew the oven door cover. To do this, undo the left and right screws (figure A).

3. Remove the cover (figure B).



Make sure that the oven door is not closed while the cover is removed. The inner panel may be damaged.

Clean the cover with a stainless-steel cleaning agent.

4. Replace the cover and secure it in position.


5. Close the oven door.

## Removing and installing the door panels


To facilitate cleaning, you can remove the glass panels from the oven door.

### Removal

1. Detach the oven door and lay it on a cloth with the handle facing down.
2. Unscrew the cover at the top of the oven door. To do this, undo the left and right screws (fig. A).
3. Lift the top panel up and out (fig. B).



4. Unscrew the retaining clips on the right and left. Lift the panel and remove the brackets from the panel (fig. C). Take out the panel.




Clean the panels with glass cleaner and a soft cloth.

Do not use sharp or abrasive materials or a glass scraper. This may damage the glass.

### Fitting

When fitting, make sure that the lettering "right above" is upside down at the bottom left.

1. Insert the panel diagonally towards the back (fig. A).
2. Stick the retaining clips onto the right and left-hand sides of the panel, aligning them so that the carriers are over the screw holes, and then screw in place (fig. B).



3. Insert the uppermost panel diagonally towards the back. The smooth surface must face outwards.
4. Put the cover back in place and screw it on.
5. Attach the oven door.

**Do not use the oven again until the panels have been correctly fitted.**

## Troubleshooting

Malfunctions often have simple explanations. Refer to the table before calling the after-sales service as you may be able to remedy the fault yourself.

### Malfunction table

If a dish doesn't turn out as well as you had hoped, refer to the section *Tested for you in our cooking studio*, where you will find plenty of cooking tips and tricks.

| Problem                              | Possible cause                    | Remedy/information                                                           |
|--------------------------------------|-----------------------------------|------------------------------------------------------------------------------|
| The oven does not work.              | The circuit breaker is defective. | Look in the fuse box and check that the circuit breaker is in working order. |
|                                      | Power cut                         | Check whether the kitchen light or other kitchen appliances are working.     |
| ⌚ and zeros light up in the display. | Power cut                         | Reset the clock.                                                             |

| Problem                    | Possible cause                 | Remedy/information                                   |
|----------------------------|--------------------------------|------------------------------------------------------|
| The oven does not heat up. | There is dust on the contacts. | Turn the control knobs back and forth several times. |

### Error messages

If an error message with **E** appears, press the ⏸ button. The message disappears. A time function that has been set is cleared. If the error message does not disappear, please contact the after-sales service.

You can take remedial action yourself if the following error message is displayed.

| Error message | Possible cause                                        | Remedy/information                                                                          |
|---------------|-------------------------------------------------------|---------------------------------------------------------------------------------------------|
| <b>E011</b>   | A button was depressed for too long or is covered up. | Press all buttons individually. Check whether any buttons are jammed, covered up or soiled. |

**⚠ Risk of electric shock!**

Incorrect repairs are dangerous. Repairs may only be carried out by one of our trained after-sales engineers.

**Replacing the bulb in the oven ceiling light**


If the bulb in the oven light fails, it must be replaced. Heat-resistant, 40 watt spare bulbs can be obtained from our after-sales service or a specialist retailer. Only use these bulbs.

**⚠ Risk of electric shock!**

Switch off the circuit breaker in the fuse box.

1. Place a tea towel in the oven when it is cold to prevent damage.

2. Unscrew the glass cover by turning it anti-clockwise.



3. Replace the bulb with one of the same type.
4. Screw the glass cover back in.
5. Remove the tea towel and switch on the circuit breaker.

**Glass cover**

You must replace a damaged glass cover. Suitable glass covers may be obtained from the after-sales service. Please specify the E number and FD number of your appliance.

---

## After-sales service

Our after-sales service is there for you if your appliance needs to be repaired. We will always find the right solution in order to avoid unnecessary visits from a service technician.

**E number and FD number**

When calling us, please give the product number (E no.) and the production number (FD no.) so that we can provide you with the correct advice. The rating plate containing these numbers can be found on the right-hand side of the oven door. You can make a note of the numbers of your appliance and the telephone number of the after-sales service in the space below to save time should it be required.

---

| E no. | FD no. |
|-------|--------|
|       |        |

---

---

**After-sales service** ☎

---

Please note that there will be a fee for a visit by a service technician in the event of a malfunction, even during the warranty period.

Please find the contact data of all countries in the enclosed customer service list.

**To book an engineer visit and product advice**

- GB** 0844 8928979  
Calls from a BT landline will be charged at up to 3 pence per minute. A call set-up fee of up to 6 pence may apply.
- IE** 01450 2655

Trust the expertise of the manufacturer, and rest assured that the repair will be carried out by trained service technicians using original spare parts for your domestic appliance.

---

## Energy and environment tips

Here you can find tips on how to save energy when baking and roasting and how to dispose of your appliance properly.

**Saving energy**

- Only preheat the oven if this is specified in the recipe or in the operating instruction tables.
- Use dark, black lacquered or enamelled baking tins. They absorb the heat particularly well.
- Open the oven door as infrequently as possible while you are cooking, baking or roasting.
- It is best to bake several cakes one after the other. The oven is still warm. This reduces the baking time for the second cake. You can also place two loaf tins next to each other.
- For longer cooking times, you can switch the oven off 10 minutes before the end of the cooking time and use the residual heat to finish cooking.

**Environmentally-friendly disposal**

Dispose of packaging in an environmentally-friendly manner.



This appliance complies with European Directive 2002/96/EC on Waste Electrical and Electronic Equipment (WEEE). The directive gives a framework for the collection and recycling of old appliances, which is valid across the EU.

# Tested for you in our cooking studio


Here you will find a selection of dishes and the ideal settings for them. We will show you which type of heating and which temperature are best suited for your dish. You can find information about suitable accessories and the height at which they should be inserted. There are also tips about cookware and preparation methods.

## Notes

- Whether you should preheat or place food into a cold oven, is indicated in the respective tables.  
Do not line the accessories with greaseproof paper until after they have been preheated.
- The times specified in the tables are guidelines only. They will depend on the quality and composition of the food.
- Use the accessories supplied. Additional accessories may be obtained as special accessories from specialist retailers or from the after-sales service.  
Before using the oven, remove any unnecessary accessories and ovenware from the cooking compartment.
- Always use oven gloves when taking hot accessories or ovenware out of the cooking compartment.

## Cakes and pastries

### Baking on one level

When baking with  3D hot air, use the following shelf heights for the accessory:

- Cakes in tins: level 2
- Cakes on trays: level 3

### Baking on two or more levels

Use  3D hot air.

Baking on 2 levels

- Wire rack or universal pan at shelf position 3
- Wire rack at shelf position 1.

Baking on 3 levels:

- Wire rack at shelf position 5
- Universal pan at shelf position 3
- Wire rack at shelf position 1.


Baking trays that are placed in the oven at the same time will not necessarily be ready at the same time.

The tables show numerous suggestions for your dishes.

If you have 2 small, round cake tins, place them on one level next to each other on the wire rack.

If you have 4 small, round cake tins, place 2 next to each other on each wire rack. Slide in the wire racks one above the other.

If you are baking with 3 loaf tins at the same time, place these on the wire racks as indicated in the picture.



### Baking tins

It is best to use dark-coloured metal baking tins.














Baking times are increased when light-coloured baking tins made of thin metal or glass dishes are used, and cakes do not brown so evenly.

If you wish to use silicone baking tins, use the information and recipes provided by the manufacturer as a guide. Silicone baking tins are often smaller than normal tins. The amount of mixture and recipe instructions may differ.

### Tables

The tables show the ideal type of heating for the various cakes and pastries. The temperature and baking time depend on the amount and composition of the mixture. This is why temperature ranges are given in the tables. You should try the lower temperature first, since a lower temperature results in more even browning. You can increase the temperature next time if necessary.

Additional information can be found in the *Baking tips* section following the tables.

| Food                  | Dish                                                   | Shelf position | Type of heating                                                                         | Temperature in °C | Time in minutes |
|-----------------------|--------------------------------------------------------|----------------|-----------------------------------------------------------------------------------------|-------------------|-----------------|
| Victoria sandwich     | Wire rack + 2 x Ø 20 cm tins                           | 3              |  * | 160-170           | 20-25           |
| Light fruit cake      | Wire rack + high Ø 20 cm tin                           | 2              |  * | 150-160           | 80-90           |
| Rich fruit cake       | Wire rack + Ø 23 cm high round tin or 20 cm square tin | 2              |  * | 130-140           | 180-190         |
| Fruit crumble         | Wire rack + flat glass dish                            | 3              |  * | 160-170           | 40-45           |
| Sponge cake (fatless) | Wire rack + baking tin (dark coated)                   | 2              |  * | 160-170           | 30-40           |
| Swiss roll            | Universal pan + swiss roll tin                         | 3              |  * | 170-180           | 10-12           |
| Tart                  | Universal pan + Ø 20 cm plate or pie tin               | 3              |  * | 180-190           | 50-60           |
| Quiche                | Wire rack + quiche tin (dark coated)                   | 3              |  * | 180-190           | 40-45           |
| (White) Bread         | Wire rack + loaf tin (1 x 900 g or 2 x 450 g)          | 3              |  * | 190-200           | 25-30           |
| Scones                | Universal pan                                          | 3              |  * | 180-190           | 15-20           |
| Biscuits              | Universal pan                                          | 3              |  * | 160-170           | 15-20           |
| Small cakes           | Wire rack + 12-cup tin                                 | 3              |  * | 150-160           | 15-20           |
| Jam tarts             | Wire rack + 12-cup tin                                 | 2              |  * | 180-190           | 15-20           |

\* Preheat.

\*\* Preheat at higher temperature, then reduce and insert food.

| Food              | Dish                           | Shelf position | Type of heating | Temperature in °C | Time in minutes |
|-------------------|--------------------------------|----------------|-----------------|-------------------|-----------------|
| Meringues         | Universal pan                  | 3              | 🌀*              | 80-90             | 100-150         |
| Pavlova           | Universal pan                  | 3              | 🌀**             | 150** + 100       | 100-150         |
| Soufflé           | Wire rack + 1,2 l soufflé dish | 2              | 🌀*              | 160-170           | 45-50           |
| Pie               | Wire rack + pie dish           | 3              | 🌀*              | 180-190           | 45-50           |
| Yorkshire pudding | Universal pan + 12-cup tin     | 3              | 🌀*              | 190-200           | 15-20           |
| Jacket potatoes   | Universal pan                  | 3              | 🌀*              | 160-170           | 60-70           |
| Pizza (homemade)  | Universal pan                  | 3              | 🌀*              | 210-220           | 20-25           |

\* Preheat.

\*\* Preheat at higher temperature, then reduce and insert food.

| Food                        | Dish                                              | Shelf position | Type of heating | Temperature in °C | Time in minutes |
|-----------------------------|---------------------------------------------------|----------------|-----------------|-------------------|-----------------|
| Victoria sandwich, 2 levels | 2 wire racks + 4 x Ø 20 cm tins                   | 3+1            | 🌀*              | 160-170           | 30-35           |
| Scones, 2 levels            | Universal pan + wire rack with baking tray        | 3+1            | 🌀*              | 170-180           | 20-25           |
| Biscuits, 2 levels          | Universal pan + wire rack with baking tray        | 3+1            | 🌀*              | 150-160           | 20-25           |
| Biscuits, 3 levels          | Universal pan + 2 wire racks with baking trays    | 5+3+1          | 🌀*              | 140-150           | 25-35           |
| Small cakes, 2 levels       | 2 wire racks + 2 x 12-cup tins                    | 3+1            | 🌀*              | 150-160           | 25-30           |
| Meringues, 2 levels         | Universal pan + wire rack with baking tray        | 3+1            | 🌀*              | 80-90             | 100-150         |
| Jacket potatoes, 2 levels   | 2 wire racks                                      | 3+1            | 🌀*              | 160-170           | 60-75           |
| (White) Bread, 2 levels     | 2 wire racks + loaf tins (2 x 900 g or 4 x 450 g) | 3+1            | 🌀*              | 180-190           | 35-40           |
| Pizza (homemade), 2 levels  | Universal pan + wire rack with baking tray        | 3+1            | 🌀*              | 180-190           | 40-45           |

\* Preheat.

## Baking tips

|                                                                                                                     |                                                                                                                                                                                                                                                                    |
|---------------------------------------------------------------------------------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| You wish to bake according to your own recipe.                                                                      | Use similar items in the baking tables as a guide.                                                                                                                                                                                                                 |
| How to establish whether sponge cake is baked through.                                                              | Approximately 10 minutes before the end of the baking time specified in the recipe, stick a cocktail stick into the cake at the highest point. If the cocktail stick comes out clean, the cake is ready.                                                           |
| The cake collapses.                                                                                                 | Use less fluid next time or set the oven temperature 10 degrees lower. Observe the specified mixing times in the recipe.                                                                                                                                           |
| The cake has risen in the middle but is lower around the edge.                                                      | Do not grease the sides of the springform cake tin. After baking, loosen the cake carefully with a knife.                                                                                                                                                          |
| The cake goes too dark on top.                                                                                      | Place it lower in the oven, select a lower temperature and bake the cake for a little longer.                                                                                                                                                                      |
| The cake is too dry.                                                                                                | When it is done, make small holes in the cake using a cocktail stick. Then drizzle fruit juice or an alcoholic beverage over it. Next time, select a temperature 10 degrees higher and reduce the baking time.                                                     |
| The bread or cake (e.g. cheesecake) looks good, but is soggy on the inside (sticky, streaked with water).           | Use slightly less fluid next time and bake for slightly longer at a lower temperature. For cakes with a moist topping, bake the base first. Sprinkle it with almonds or bread crumbs and then place the topping on top. Please follow the recipe and baking times. |
| The cake is unevenly browned.                                                                                       | Select a slightly lower temperature to ensure that the cake is baked more evenly. Protruding greaseproof paper can affect the air circulation. For this reason, always cut greaseproof paper to fit the baking tray.                                               |
| The bottom of a fruit cake is too light.                                                                            | Place the cake one level lower the next time.                                                                                                                                                                                                                      |
| The fruit juice overflows.                                                                                          | Next time, use the deeper universal pan, if you have one.                                                                                                                                                                                                          |
| Small baked items made out of yeast dough stick to one another when baking.                                         | There should be a gap of approx. 2 cm around each item. This gives enough space for the baked items to expand well and turn brown on all sides.                                                                                                                    |
| You were baking on several levels. The items on the top baking tray are darker than that on the bottom baking tray. | Always use 🌀 3D hot air to bake on more than one level. Baking trays that are placed in the oven at the same time will not necessarily be ready at the same time.                                                                                                  |



Condensation forms when you bake moist cakes.

Baking may result in the formation of water vapour, which escapes above the door. The steam may settle and form water droplets on the control panel or on the fronts of adjacent units. This is a natural process.

## Meat, poultry, fish

### Ovenware

The universal pan with insert wire rack is suitable for large roasts. You may also use any heat-resistant ovenware.

Glass ovenware is the most suitable. Ensure that the lid of the roasting dish fits well and closes properly.

Add a little more liquid when using enamelled roasting dishes.

With roasting dishes made of stainless steel, browning is not so intense and the meat may be somewhat less well cooked. Increase the cooking times.

Always place the ovenware in the centre of the wire rack.

Place hot glass ovenware on a dry mat after cooking. The glass could crack if placed on a cold or wet surface.

### Roasting



The information in the table applies to food placed in a cold oven and for meat taken directly from the refrigerator.

The joints of meat should weigh between 500 g and 2 kg.

Ensure that you always use the lower temperature, if the weight of the joint you wish to roast is high.




















If there are several pieces of meat, calculate the roasting time using the weight of the heaviest piece of meat. The individual pieces of meat should be approximately the same size.

### Meat

When using the  Top/bottom heating and  Circulated air grilling types of heating, turn the pieces of meat halfway through the cooking time.

When the roast is ready, turn off the oven and allow it to rest for 10 minutes. This allows better distribution of the meat juices.

When roasting joints of pork with a rind, make cuts in the rind crossways and if it is to be turned, first place the joint with the rind side down in the dish.

| Food                              | Dish                                     | Shelf position | Type of heating                                                                      | Temperature in °C | Time, min. per 500 g + add. time |
|-----------------------------------|------------------------------------------|----------------|--------------------------------------------------------------------------------------|-------------------|----------------------------------|
| <b>Beef</b>                       |                                          |                |                                                                                      |                   |                                  |
| Slow roast joint                  | Universal pan with wire insert           | 1              |    | 130-140           | 40 + 40                          |
| Top side, top rump                | Universal pan with wire insert           | 1              |   | 160-170           | 30 + 25                          |
| <b>Lamb</b>                       |                                          |                |                                                                                      |                   |                                  |
| Leg                               | Universal pan with wire insert           | 1              |  | 160-170           | 30 + 25                          |
| Shoulder (bone in)                | Universal pan with wire insert           | 1              |  | 160-170           | 25 + 20                          |
| Shoulder (boned and rolled)       | Universal pan with wire insert           | 1              |  | 170-180           | 25 + 25                          |
| Rack of lamb                      | Universal pan with wire insert           | 1              |  | 180-190           | 25 + 25                          |
| <b>Pork</b>                       |                                          |                |                                                                                      |                   |                                  |
| Roast joint                       | Universal pan with wire insert           | 1              |  | 180-190           | 35 + 35                          |
| Loin joint                        | Universal pan with wire insert           | 1              |  | 170-180           | 30 + 30                          |
| Belly                             | Universal pan with wire insert           | 1              |  | 160-170           | 30 + 25                          |
| Gammon joint                      | Universal pan with wire insert           | 1              |  | 160-170           | 30 + 30                          |
| <b>Poultry</b>                    |                                          |                |                                                                                      |                   |                                  |
| Chicken                           | Universal pan with wire insert           | 1              |  | 170-180           | 25 + 25                          |
| Chicken, portion (200-250 g each) | Universal pan with wire insert           | 1              |  | 190-200           | 20 + 25                          |
| Chicken, quarter (450 g each)     | Universal pan with wire insert           | 1              |  | 180-190           | 20 + 25                          |
| Duck                              | Universal pan with wire insert           | 1              |  | 180-190           | 20 + 20                          |
| Turkey, crown                     | Universal pan with wire insert           | 1              |  | 160-170           | 15 + 15                          |
| Turkey, whole (up to 12 kg)       | Universal pan with wire insert           | 1              |  | 160-170           | 12 + 12                          |
| <b>Casserole</b>                  |                                          |                |                                                                                      |                   |                                  |
| Diced meat (beef, pork, lamb)     | Wire rack + glass roasting dish with lid | 2              |  | 140               | 120-150 (total time)             |
| Braising steaks                   | Wire rack + glass roasting dish with lid | 2              |  | 140               | 120-150 (total time)             |
| Chicken                           | Wire rack + glass roasting dish with lid | 2              |  | 140               | 60-90                            |

### Complete meal

| Food         | Dish                                       | Shelf position | Type of heating | Temperature in °C                 | Time, min. per 500 g + add. time                               |
|--------------|--------------------------------------------|----------------|-----------------|-----------------------------------|----------------------------------------------------------------|
| With beef    | Wire rack + universal pan with wire insert | 4+1            |                 | 160, then 200 (yorkshire pudding) | weight of meat (see table above) + 15-25 for yorkshire pudding |
| With chicken | Wire rack + universal pan with wire insert | 4+1            |                 | 180                               | weight of chicken (see table above)                            |

| Food                              | Dish                           | Shelf position | Type of heating | Temperature in °C | Time, min. per 500 g + add. time |
|-----------------------------------|--------------------------------|----------------|-----------------|-------------------|----------------------------------|
| <b>Lamb</b>                       |                                |                |                 |                   |                                  |
| Leg                               | Universal pan with wire insert | 1              |                 | 150-170           | 30 + 35                          |
| Rack of lamb                      | Universal pan with wire insert | 1              |                 | 180-200           | 25 + 25                          |
| <b>Pork</b>                       |                                |                |                 |                   |                                  |
| Roast joint                       | Universal pan with wire insert | 1              |                 | 180-200           | 35 + 40                          |
| Belly                             | Universal pan with wire insert | 1              |                 | 220-240           | 25 + 40                          |
| <b>Poultry</b>                    |                                |                |                 |                   |                                  |
| Chicken                           | Universal pan with wire insert | 1              |                 | 200-220           | 25 + 15                          |
| Chicken, portion (200-250 g each) | Universal pan with wire insert | 3              |                 | 210-230           | 25 + 25                          |
| Chicken, quarter (450 g each)     | Universal pan with wire insert | 2              |                 | 220-240           | 20 + 25                          |
| Duck                              | Universal pan with wire insert | 1              |                 | 190-210           | 20 + 20                          |

### Grilling

When grilling, preheat the oven for approx. 3 minutes, before putting the food in.

Always grill with the oven door closed.

As far as possible, the pieces of food you are grilling should be of equal thickness. This will allow them to brown evenly and remain succulent and juicy.

Turn grilled items after the specified time.

Whole fish does not need to be turned. Place the whole fish in the oven in the swimming position with the dorsal fin pointing upwards. Placing a scored potato or a small oven-proof container in the stomach cavity of the fish will provide stability.

Do not add salt to steaks until they have been grilled.

Place the food to be grilled directly on the wire rack. If you are grilling a single piece, the best results are achieved by placing it in the centre of the wire rack.

The universal pan should also be inserted underneath. To prevent a high degree of smoke from forming, do not insert the pan higher than level 3. The meat juices are collected in the pan and the oven is kept cleaner.

Do not insert the baking tray or universal pan at level 4 or 5. The high heat distorts it and the cooking compartment can be damaged when removing it.

The grill element switches on and off continually. This is normal. The grill setting determines how frequently this will happen.

| Food                   | Dish                      | Shelf position | Type of heating | Grill setting | Time in minutes             |
|------------------------|---------------------------|----------------|-----------------|---------------|-----------------------------|
| <b>Beef</b>            |                           |                |                 |               |                             |
| Steaks, height 2-3 cm  | Wire rack + universal pan | 5+3            |                 | 3             | 1. side 4-5, 2. side 4-5    |
| Burgers, height 1-2 cm | Wire rack + universal pan | 5+3            |                 | 3             | 1. side 6-8, 2. side 4-6    |
| <b>Lamb</b>            |                           |                |                 |               |                             |
| Steaks, height 2-3 cm  | Wire rack + universal pan | 5+3            |                 | 3             | 1. side 6-7, 2. side 6-7    |
| Chops, height 2-3 cm   | Wire rack + universal pan | 5+3            |                 | 3             | 1. side 5-6, 2. side 5-6    |
| <b>Pork</b>            |                           |                |                 |               |                             |
| Steaks, height 1-2 cm  | Wire rack + universal pan | 5+3            |                 | 3             | 1. side 6-7, 2. side 6-7    |
| Chops, height 2-3 cm   | Wire rack + universal pan | 4+3            |                 | 3             | 1. side 10-12, 2. side 9-10 |
| Burgers, height 1-2 cm | Wire rack + universal pan | 5+3            |                 | 3             | 1. side 6-8, 2. side 4-6    |

| Food                          | Dish                      | Shelf position | Type of heating | Grill setting | Time in minutes             |
|-------------------------------|---------------------------|----------------|-----------------|---------------|-----------------------------|
| Sausages, thickness 2-4 cm    | Wire rack + universal pan | 4+3            |                 | 3             | 10-15, turn occasionally    |
| <b>Gammon</b>                 |                           |                |                 |               |                             |
| Steaks, height 1-3 cm         | Wire rack + universal pan | 5+3            |                 | 3             | 1. side 4-5,<br>2. side 3-4 |
| <b>Chicken</b>                |                           |                |                 |               |                             |
| Drumsticks, 150 g each        | Wire rack + universal pan | 3+2            |                 | 3             | 1. side 17,<br>2. side 8    |
| Breast (boneless), 150 g each | Wire rack + universal pan | 3+2            |                 | 3             | 1. side 20,<br>2. side 10   |
| <b>Fish</b>                   |                           |                |                 |               |                             |
| Whole trout, 300 g each       | Wire rack + universal pan | 2+1            |                 | 2             | 20-25                       |
| Filletts, 150 g each          | Wire rack + universal pan | 4+3            |                 | 3             | 1. side 5-7,<br>2. side 5-7 |

## Tips for roasting and grilling

|                                                                     |                                                                                                                                                                                                                                       |
|---------------------------------------------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| The table does not contain information for the weight of the joint. | Select the next lowest weight from the instructions and extend the time.                                                                                                                                                              |
| How to tell when the roast is ready.                                | Use a meat thermometer (available from specialist shops) or carry out a "spoon test". Press down on the roast with a spoon. If it feels firm, it is ready. If the spoon can be pressed in, it needs to be cooked for a little longer. |
| The roast is too dark and the crackling is partly burnt.            | Check the shelf height and temperature.                                                                                                                                                                                               |
| The roast looks good but the juices are burnt.                      | Next time, use a smaller roasting dish or add more liquid.                                                                                                                                                                            |
| The roast looks good but the juices are too clear and watery.       | Next time, use a larger roasting dish and use less liquid.                                                                                                                                                                            |
| Steam rises from the roast when basted.                             | This is normal and due to the laws of physics. The majority of the steam escapes through the steam outlet. It may settle and form condensation on the cooler switch panel or on the fronts of adjacent units.                         |

## Preprepared products

Observe the instructions on the packaging.

If you line the accessories with greaseproof paper, make sure that the paper is suitable for these temperatures. Make sure the paper is a suitable size for the dish to be cooked.

The cooking result greatly depends on the quality of the food. Pre-browning and unevenness can sometimes even be found on the raw product.

Leave a little space between bread rolls when crisping them up. Do not place too many bread rolls on the accessories.

Sprinkle grated cheese over the top of your lasagne to give it a beautiful and evenly browned finish.

| Food                           | Dish                        | Shelf position | Type of heating | Temperature in °C | Time in minutes |
|--------------------------------|-----------------------------|----------------|-----------------|-------------------|-----------------|
| <b>Pizza, frozen</b>           |                             |                |                 |                   |                 |
| Pizza with a thin base         | Universal pan               | 3              |                 | 200-210           | 10-15           |
|                                | Universal pan + wire rack   | 3+1            |                 | 170-180           | 20-25           |
| Pizza with a thick base        | Universal pan               | 3              |                 | 200-210           | 15-20           |
|                                | Universal pan + wire rack   | 3+1            |                 | 170-180           | 20-25           |
| Pizza-Baguette                 | Universal pan               | 3              |                 | 170-180           | 25-30           |
| <b>Pizza, chilled</b>          |                             |                |                 |                   |                 |
| Pizza                          | Universal pan               | 3              |                 | 200-210           | 10-15           |
| <b>Potato products, frozen</b> |                             |                |                 |                   |                 |
| Chips                          | Universal pan               | 3              |                 | 210-220           | 20-25           |
|                                | Universal pan + baking tray | 3+1            |                 | 180-190           | 30-35           |
| Duchess potatoes               | Universal pan               | 3              |                 | 200-210           | 15-20           |
| Hash browns (fried potatoes)   | Universal pan               | 3              |                 | 200-210           | 15-20           |

\* Preheat.

| Food                         | Dish                      | Shelf position | Type of heating | Temperature in °C | Time in minutes |
|------------------------------|---------------------------|----------------|-----------------|-------------------|-----------------|
| Potato wedges                | Universal pan             | 3              | 🔥*              | 190-210           | 20-25           |
| <b>Baked goods, frozen</b>   |                           |                |                 |                   |                 |
| Rolls, baguettes             | Universal pan             | 3              | 🔥*              | 180-190           | 10-15           |
| <b>Baked goods, prebaked</b> |                           |                |                 |                   |                 |
| Part baked white bread       | Universal pan             | 3              | 🔥*              | 180-190           | 15-20           |
|                              | Universal pan + wire rack | 3+1            | 🔥*              | 160-170           | 20-25           |
| <b>Fried foods, frozen</b>   |                           |                |                 |                   |                 |
| Fish fingers                 | Universal pan             | 3              | 🔥*              | 200-210           | 15-20           |
| Chicken nuggets              | Universal pan             | 3              | 🔥*              | 170-180           | 20-25           |
| <b>Lasagne, frozen</b>       |                           |                |                 |                   |                 |
| Lasagne, 400 g               | Wire rack                 | 2              | 🔥*              | 180-190           | 35-40           |
| Lasagne, 1200 g              | Wire rack                 | 2              | 🔥*              | 180-190           | 40-50           |
| <b>Lasagne, chilled</b>      |                           |                |                 |                   |                 |
| Lasagne, 400 g               | Wire rack                 | 2              | 🔥*              | 170-180           | 25-30           |
| Lasagne, 1200 g              | Wire rack                 | 2              | 🔥*              | 170-180           | 30-35           |

\* Preheat.

## Special dishes

At low temperatures, 🔥 3D hot air is equally useful for producing creamy yoghurt as it is for proving light yeast dough.

First, remove accessories, hook-in racks or telescopic shelves from the cooking compartment.

### Preparing yoghurt

1. Bring 1 litre of milk (3.5 % fat) to the boil and cool down to 40 °C.
2. Stir in 150 g of yoghurt (at refrigerator temperature).
3. Pour into cups or small screw-top jars and cover with cling film.

4. Preheat the cooking compartment as indicated.

5. Place the cups or jars on the cooking compartment floor and incubate as indicated.

### Proving dough

1. Prepare the dough as usual, place it in a heat-resistant ceramic dish and cover.
2. Preheat the cooking compartment as indicated.
3. Switch off the oven and place the dough in the cooking compartment and leave it to prove.

| Dish          | Ovenware               |                                  | Type of heating | Temperature                                                                   | Cooking time |
|---------------|------------------------|----------------------------------|-----------------|-------------------------------------------------------------------------------|--------------|
| Yoghurt       | Cups or screw-top jars | on the cooking compartment floor | 🔥               | 50 °C Preheat                                                                 | 5 mins       |
|               |                        |                                  |                 | 50 °C                                                                         | 8 hrs        |
| Proving dough | Heat-resistant dish    | on the cooking compartment floor | 🔥               | 50 °C Preheat                                                                 | 5-10 mins    |
|               |                        |                                  |                 | Switch off the appliance and place the yeast dough in the cooking compartment | 20-30 mins   |

## Defrost

The defrosting time will depend on the type and quantity of the food.


Observe the instructions on the packaging.

Take frozen food out of its packaging and place in a suitable dish on the wire rack.

Place poultry on a plate with the breast side facing down.

| Frozen food                                                                                                                                                      | Accessories | Level | Type of heating | Temperature                                   |
|------------------------------------------------------------------------------------------------------------------------------------------------------------------|-------------|-------|-----------------|-----------------------------------------------|
| e.g. cream cakes, buttercream cakes, gateaux with chocolate or sugar icing, fruit, chicken, sausage and meat, bread and bread rolls, cakes and other baked items | Wire rack   | 1     | 🔥               | The temperature selector remains switched off |

## Drying

With  3D hot air, you can dry foods brilliantly.





Use unblemished fruit and vegetables only and wash them thoroughly.

Drain off the excess water, then dry them.

Line the universal pan and the wire rack with greaseproof or parchment paper.

Turn very juicy fruit or vegetables several times.

Remove fruit and vegetables from the paper as soon as they have dried.

| Fruit and herbs         | Accessories          | Level | Type of heating                                                                   | Temperature | Cooking time       |
|-------------------------|----------------------|-------|-----------------------------------------------------------------------------------|-------------|--------------------|
| 600 g apple rings       | Universal pan + rack | 3+1   |  | 80 °C       | 5 hrs (approx.)    |
| 800 g pear slices       | Universal pan + rack | 3+1   |  | 80 °C       | 8 hrs (approx.)    |
| 1.5 kg damsons or plums | Universal pan + rack | 3+1   |  | 80 °C       | 8-10 hrs (approx.) |
| 200 g herbs, washed     | Universal pan + rack | 3+1   |  | 80 °C       | 1½ hrs (approx.)   |

## Preserving

For preserving, the jars and rubber seals must be clean and intact. If possible, use jars of the same size. The information in the table is for round, one-litre jars.

### Caution!

Do not use jars that are larger or taller than this. The lids could crack.

Only use fruit and vegetables in good condition. Wash them thoroughly.

The times given in the tables are a guide only. The time will depend on the room temperature, number of jars, and the quantity and temperature of the contents. Before you switch off the appliance or change the cooking mode, check whether the contents of the jars are bubbling as they should.

### Preparation

1. Fill the jars, but not to the top.
2. Wipe the rims of the jars, as they must be clean.
3. Place a damp rubber seal and a lid on each jar.

| Fruit in one-litre jars                   | When it starts to bubble | Residual heat      |
|-------------------------------------------|--------------------------|--------------------|
| Apples, redcurrants, strawberries         | Switch off               | approx. 25 minutes |
| Cherries, apricots, peaches, gooseberries | Switch off               | approx. 30 minutes |
| Apple purée, pears, plums                 | Switch off               | approx. 35 minutes |

### Vegetables

As soon as bubbles begin to form in the jars, set the temperature back to between 120 and 140 °C. Depending on

4. Seal the jars with the clips.

Place no more than six jars in the cooking compartment.

### Making settings

1. Insert the universal pan at level 2. Arrange the jars on it so that they do not touch each other.
2. Pour ½ litre of hot water (approx. 80 °C) into the universal pan.
3. Close the oven door.
4. Set  Bottom heating.
5. Set the temperature to between 170 and 180 °C.

### Preserving

#### Fruit

After approx. 40 to 50 minutes, small bubbles begin to form at short intervals. Switch off the oven.

After 25 to 35 minutes of residual heat, remove the preserving jars from the cooking compartment. If they are allowed to cool for longer in the cooking compartment, germs could multiply, promoting acidification of the preserved fruit.

the type of vegetable, heat for approx. 35 to 70 minutes. Switch off the oven after this time and use the residual heat.

| Vegetables with cold cooking water in one-litre jars | When it starts to bubble | Residual heat      |
|------------------------------------------------------|--------------------------|--------------------|
| Gherkins                                             | -                        | approx. 35 minutes |
| Beetroot                                             | approx. 35 minutes       | approx. 30 minutes |
| Brussels sprouts                                     | approx. 45 minutes       | approx. 30 minutes |
| Beans, kohlrabi, red cabbage                         | approx. 60 minutes       | approx. 30 minutes |
| Peas                                                 | approx. 70 minutes       | approx. 30 minutes |

### Taking out the jars

After preserving, remove the jars from the cooking compartment.

### Caution!

Do not place the hot jars on a cold or wet surface. They could suddenly burst.

# Acrylamide in foodstuffs

Acrylamide is mainly produced in grain and potato products prepared at high temperatures, such as potato crisps, chips,

toast, bread rolls, bread or fine baked goods (biscuits, gingerbread, cookies).

## Tips for keeping acrylamide to a minimum when preparing food

|                |                                                                                                                                                                                                                           |
|----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| <b>General</b> | <ul style="list-style-type: none"> <li>■ Keep cooking times to a minimum.</li> <li>■ Cook meals until they are golden brown, but not too dark.</li> <li>■ Large, thick pieces of food contain less acrylamide.</li> </ul> |
| <b>Baking</b>  | <p>With top/bottom heating max. 200 °C.<br/>With 3D hot air or hot air max. 180 °C.</p>                                                                                                                                   |
| Biscuits       | <p>With top/bottom heating max. 190 °C.<br/>With 3D hot air or hot air max. 170 °C.<br/>Egg or egg yolk reduces the production of acrylamide.</p>                                                                         |
| Oven chips     | <p>Spread evenly over the baking tray, in a single layer. Bake at least 400 g per baking tray so that the chips do not dry out</p>                                                                                        |

## Test dishes

These tables have been produced for test institutes to facilitate the inspection and testing of the various appliances.

In accordance with EN 50304/EN 60350 (2009) and IEC 60350.

### Baking

Baking on 2 levels:

Always insert the universal pan above the baking tray.

Baking on 3 levels:

Insert the universal pan in the middle.

Viennese whirls:


Baking trays that are placed in the oven at the same time will not necessarily be ready at the same time.

Apple pie on 1 level:

Place dark springform cake tins next to each other diagonally on the same level.

Apple pie on 2 levels:



Place dark springform cake tins next to each other (see illustration).



| Dish                      | Accessories and tins                              | Level | Type of heating | Temperature in °C | Cooking time in minutes |
|---------------------------|---------------------------------------------------|-------|-----------------|-------------------|-------------------------|
| Viennese whirls (preheat) | Baking tray                                       | 3     | ⊗               | 140-150           | 30-40                   |
|                           | Universal pan + baking tray                       | 3+1   | ⊗               | 140-150           | 30-45                   |
|                           | 2 baking trays + universal pan                    | 5+3+1 | ⊗               | 130-140           | 40-55                   |
| Small cakes (preheat)     | Baking tray                                       | 3     | ⊗               | 150-170           | 20-35                   |
|                           | Universal pan + baking tray                       | 3+1   | ⊗               | 140-160           | 30-45                   |
|                           | 2 baking trays + universal pan                    | 5+3+1 | ⊗               | 130-150           | 35-55                   |
| Hot water sponge cake     | Springform cake tin on the wire rack              | 2     | ⊗               | 160-170           | 25-40                   |
| Apple pie                 | Wire rack+ 2 springform cake tins, dia. 20 cm     | 3     | ⊗               | 160-180           | 75-95                   |
|                           | 2 wire racks + 2 springform cake tins, dia. 20 cm | 3+1   | ⊗               | 170-190           | 70-100                  |

## Grilling

If you are grilling food directly on the wire rack, the universal pan should also be inserted at level 1. The liquid is then collected, keeping the oven cleaner.

| Dish                                      | Accessories               | Level | Type of heating                                                                    | Grill setting | Cooking time in minutes |
|-------------------------------------------|---------------------------|-------|------------------------------------------------------------------------------------|---------------|-------------------------|
| Toast<br>Preheat for 10 minutes           | Wire rack                 | 5     |  | 3             | 1/2-2                   |
| Beefburgers, 12 pieces*<br>do not preheat | Wire rack + universal pan | 4+1   |  | 3             | 25-30                   |

\* turn over after  $\frac{2}{3}$  of the cooking time.



**Robert Bosch Hausgeräte GmbH**

Carl-Wery-Straße 34

81739 München

Germany

**[www.bosch-home.com](http://www.bosch-home.com)**



9000704691

910912