

cookworks

Model No.: KHC-617D DIGITAL HALOGEN OVEN INSTRUCTION MANUAL



WARNING: This appliance is operating at high temperatures. To ensure your safety and the safety of others, please ensure you read these instructions paying particular attention to the Safety Warnings before you operate this product and retain for future reference.

IMPORTANT SAFETY PRECAUTIONS

1. **Please read through the instruction manual before your first use and keep it for future use.**
2. **Do not touch hot surfaces. Always use the lid handle to remove the glass lid from the glass pot. Always wear protective, insulated oven gloves or mitts when removing food items or handling the Halogen oven - The oven gets very hot.**
3. To protect against electrical shock do not immerse cord, plugs, or main body in water or other liquid.
4. **Close supervision is necessary when any appliance is used by or near children.**
5. Unplug from outlet when not in use and before cleaning. Allow to cool before attaching or removing parts or cleaning.
6. Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner. Take it to a qualified serviceperson for examination and repair.
7. Do not use accessory attachments not recommended by the appliance manufacturer as may cause injury.
8. Do not let cord hang over edge of table or counter, or touch hot surfaces.
9. Do not place on or near a hot gas or electric burner, or heated oven.
10. Extreme caution must be used when moving an appliance containing hot food or liquids.
11. This appliance is intended for household use only, do not use appliance for other than intended use.
12. The appliance must not be immersed in water.
13. **This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.**

14. **Children should be supervised to ensure that they do not play with the appliance.**
15. **Keep the appliance and its cord out of reach of children aged less than 8 years.**
16. Do not leave food in oven overnight.
17. **Always carry the appliances by the handles on the lids. NEVER lift the appliances by hanging the power cord.**
18. When operating the oven, keep at least 10cm of space on all sides of the oven to allow for adequate air circulation.
19. Use on a secure and stable worktop. Do not place near the edge of the worktop.
20. Do not place the product where it can either fall or be submerged into water or any other liquid.
21. Always place the glass pot into the base before plugging in the power plug and switching ON. Never operate the oven without first placing it on the supplied base.
22. Do not move the oven while in use.
23. A fire may occur if the oven is covered by or placed near the flammable material, including curtains, draperies, walls, and the like, when in operation.
24. Do not store any item on the oven during operation.
25. Do not place any of the following materials in the oven: cardboard, plastic, paper, or anything similar.
26. Do not store any materials, other than manufacturer's recommended accessories in this oven when not in use.
27. To disconnect, pull the lid handle upward (i.e. Off position), then remove plug from wall outlet. Always hold the plug, but never pull the cord.
28. The appliance has a tempered, safety glass cover and container. The glass is stronger than ordinary glass and more resistant to breakage. Avoid scratching cover and container surface or nicking edges. If the glass has a scratch or nick, contact a qualified serviceperson for examination.

29. All metal items in the oven, such as the cooking racks, can get very hot during cooking. Please be careful when removing these items from the oven. Always wear oven gloves or use the provided tongs.
30. **The temperature of accessible surfaces may get hot when the appliance is operating.** Please make sure that the power cord will not touch the container and the lid when the appliance is in operation.
31. Please use the appliances with supplied containers and supports.
32. The handle of the appliance should not be pushed down when the lid is not onto the container.
33. NOTE - This product may emit some odour when it is first used. This is due to lubricant on the elements burning off and is NORMAL. It will not continue following further use.
34. Important- Always place the glass pot on the pot support stand when cooking your food. NEVER put the glass pot directly on the countertop. Never leave the product unattended while in use.
35. DO NOT operate the Halogen Oven near to where aerosol products are being used.
36. Always be extremely cautious when preparing foods using fats and oil around heat as these can catch fire or scold.
37. Never leave the product unattended while in use.
38. Where you see this symbol on the product or attachments, it means:
CAUTION: this surface may get very hot during use.




SAVE THESE INSTRUCTIONS

KNOW YOUR APPLIANCE


Product

- A. Digital control panel
- B. Lid unit
- C. Lid handle with safety switch
- D. Glass pot
- E. Extender ring
- F. Base support stand




Accessories

- 1. Tongs
- 2. Low rack
- 3. High rack
- 4. Lid holder



Digital Control Panel

- 1. Temperature indicator
- 2. Time indicator
- 3. Time button
- 4. Start/Stop button
- 5. LED display
- 6. Temperature button
- 7. Pause button



BEFORE FIRST USE

1. DO NOT operate the Halogen Oven with other household appliances plugged into the same power socket as there may be a risk of fusing the circuit.
2. Remove the lid, glass pot, base and accessories from the retail box.
3. Read the instruction thoroughly and follow the important safety instructions.
4. Clean parts with damp cloth thoroughly. Never clean the lid with water or any other liquid. Only the glass pot can be wash by water or other liquid.
5. Make sure all the parts are completely dry before use.
6. Select a flat, heat-resistant, non-flammable surface to operate the oven.
7. Ensure the power cord is not touching anything hot.
8. Ensure you have adequate clear space above the product when raising the glass lid from the glass pot.

ASSEMBLING INSTRUCTION

1. Place the base support stand on a stable, flat and dry surface.
2. Place the glass pot onto base support stand.
3. Insert the mains plug into a mains power outlet.
4. Carefully place the lid on the glass pot.
Note: The appliance will only operate when the handle is pushed down into a horizontal position to activate the safety switch.
5. Push the release button on the handle and then put the handle down to ensure the safety switch at the rear of the lid is pressed.
6. Set the temperature to 100°C and timer to 15 minutes. (see section "operation instructions")
7. After a few minutes a small amount of smoke and odour may be emitted from the oven, this is normal on first use.
8. Once the oven has reached its timed stop. pull the handle upward.
9. Unplug the unit from mains. Remove the lid and place it into the lid holder to let it cool down.

OPERATION INSTRUCTIONS

Caution: Always operate this product on a flat horizontal surface. Do not operate under or near curtains or other combustible materials.

Using the appliance

Remove the lid and put the most suitable rack into the glass pot before placing the food inside. Cooking the food without the rack is not recommended. Putting the food on the rack can improve the hot air circulation around the food. Keep the food away from the glass wall at least 3cm.

Note : Food can be packed into aluminium foil or put onto an oven-safe container.

1. Place the lid on the glass pot securely. Make sure the food does not touch the lid and allow at least 10 cm clearance from the halogen bulb.

2. Standby mode:

Once the appliance is plugged in and the mains power switched on, the LED digital Timer will display 0:10, Temperature indicator light will stay at 120.

3. Operation mode:

Push the release button on the handle and push down the handle into the horizontal position to activate the safety switch at the rear side of the appliance. If the safety switch is not activated, the oven will stay in Standby Mode and all buttons will not respond to all your actions except with a beep sound.

4. Set cooking time and temperature (in operation mode):

- **Press the Time button.** While the illuminated indicator is flashing, press the (+) or(-) button lightly to increase or reduce the time selected in increments of 1 minute from 0 to 120 minutes. Holding the + or- button will help the increment change faster. (note: after pressing Time button, if '+' or '-' buttons are not pressed within 5 seconds then the Time mode will default back to off and Time button will need to be pressed again).




- **Press the Temp button.** The temperature indicator illuminates. While the illuminated indicator is flashing, press the (+) or (-) button lightly to increase or reduce the temperature selection in increments of 10°C, from 60°C to 250°C. Holding the button will help the increment change faster.(note: after pressing Temp button, if '+' or '-' buttons are not pressed within 5 seconds then the Temp mode will default back to off and Temp button will need to be pressed again).

5. The timing and temperature is now set and the cooking process commences when the **START/STOP** button is pressed. The halogen bulb will illuminate as the Halogen Oven begins the cooking cycle. The halogen bulb will switch off once the desired temperature has been reached, however the cooking cycle will continue.

6. The halogen tube is thermostatically controlled and has to switch on and off (light on and off) automatically during the cooking process to maintain the desired cooking temperature. This is not a fault. The fan will still run for the entire cooking cycle.

7. When the cooking time has completed (0:00), an audible beep will be heard. The fan will continue running for a while to cool down before the cooking cycle completely stops.

8. **Pull the lid handle up into the vertical position. Raise the lid using the lid handle and put it onto the lid holder to cool down. NEVER put the hot oven lid**



onto the countertop or table after cooking. This may damage the surface of the furniture or cause a fire hazard.

9. **Remove heating rack from glass pot using the tongs.**

Note: Always ensure that oven gloves or mitts are worn during this process.

10. **Always unplug the appliance from the mains power socket after use.**

Pause

Press **PAUSE** button to pause the cooking cycle, press the **PAUSE** button again to resume and continue the cooking cycle.

Or

Pull the lid handle up into the vertical position to switch the oven into standby mode. Push the lid handle down again to resume and continue the cooking cycle.

Cancel and Reset

Press the **START/STOP** function on the control panel to cancel the operation. The timer and temperature will be reset to default values.

NOTE: please use PAUSE button if you only want to suspend the cooking for a while.

Preheating

The Halogen oven heats up much quicker than a conventional oven, preheating is less likely required. If preheating is still required, set the required temperature and set the time for 5 minutes. Once the temperature has been reached, the halogen bulb will turn off and the food can now be placed in the glass pot.

WARNING: DO NOT touch the glass surface of the Halogen Oven - it will get extremely hot when in use and will remain hot for some time afterwards.

When removing the glass lid, always use the lid handle to raise the lid, as this will operate the safety switch and turn the Halogen Oven power off. The Halogen Oven will be very hot; ensure that oven gloves or mitts are used when opening the glass lid.

COOKING WITH EXTENDER RING

While the size of the food is larger than the glass pot, the extender ring should be used to enlarge the internal capacity of the oven, the extender ring fits between the glass pot and the lid. The set-up of the oven with the extender ring fitted is the same as the normal set-up procedure.

The food capacity with and without the extender ring is nominally 15 litres and 10 litres respectively.

WARNING: The extender ring can become very hot when the halogen oven is operating. NEVER attempt to touch the metal ring with your bare hands. You will risk getting burnt.



COOKING HINTS

- The cooking time depends on the size and weight etc. of the food to be cooked. Most meat, for example, comes with a recommended cooking time. This should be used as a guide only as the Halogen Oven cooks faster than conventional ovens so you may need to allow less time to cook the food. For guidance, refer to the cooking times suggested in this booklet.
- To ensure that the food is cooked, use a cooking thermometer or pierce the food with a fork or skewer to check for uncooked juice on meats, poultry, etc. When cooking vegetables, check for tenderness.
- Moisture may build up inside the Halogen Oven when cooked food is not removed soon after the cooking time has expired. The steam/moisture build-up can be avoided by removing the food as soon as it is cooked.
- Use the tongs provided to lift the food off the cooking racks.
- Always ensure that food is piping hot inside before serving.

CLEANING AND MAINTENANCE

- **WARNING:** Cleaning and user maintenance shall not be made by children.
- **CAUTION:** Always unplug and allow the oven to cool down before cleaning.
- **WARNING:** To avoid electric shock, never immerse the lid in water or other liquid.
- **CAUTION:** DO NOT attempt to wash the glass bowl or lid until they have cooled down to room temperature. If cold water is poured onto the glass while it is still hot, it could crack or break the glass.
- Wipe lid using a damp, clean dish cloth or sponge with a little mild dishwashing detergent.
- DO NOT use steel wool scouring pads, abrasive cleaners or scrape surfaces with metal utensils as this may damage the unit.
- Wash glass pot and the accessories in mild detergent and water.
- Wipe the base stand with sponge or dish cloth with mild dishwashing detergent. DO NOT immerse into water.
- If scrubbing is necessary, use a nylon or polyester mesh pad.
- Ensure all parts are completely dry before storage.
- The glass pot is NOT DISHWASHER PROOF.
- The electrical lid unit or accessories must not be put in a dishwasher as they are NOT DISHWASHER PROOF.



DO NOT Pour water into container immediately after operation. It could crack the glass pot.

COOKING TIME SUGGESTIONS

Note : Always remember that cooking instructions are intended only as a guide. If you have followed the instructions and the food is still not piping hot throughout, simply return it to the oven and cook it until it is.

Food	Time	Temperature
Chicken	30-40min	180-200°C
Fish	10-15min	130-150°C
Pork	15-20min	180-200°C
Cake	10-12min	140-160°C
Lobster	12-15min	140-160°C
Shrimp	10-12min	150-180°C
Sausage	10-13min	120-150°C
Potato	12-15min	180-200°C
Rice	15-20min	150-180°C
Crab	10-13min	140-160°C

Fahrenheit to Celsius Conversion Table

Fahrenheit (F°)	Celsius (C°)
140	60
176	80
212	100
248	120
284	140
320	160
356	180
392	200
428	220
464	240
482	250

TROUBLESHOOTING

Check problems using the chart below. If the oven still does not work properly, contact a qualified serviceperson.

PROBLEM	POSSIBLE CAUSE
Burnt food	Temperature set too high, or time set too long.
Undercooked food	Temperature set too low, or time set too short.
Unit will not power ON	Handle not pushed down in order to operate safety switch. Thermostat not set. Timer not set.
The halogen tube doesn't light	Oven temperature has reached thermostat temperature setting. Timer has completed its set running time.

TECHNICAL DATA

Model no.	KHC-617D
Voltage	220-240V~ 50Hz
Power Consumption	1200-1400 W
Oven capacity	Nominally 10 litres, extendable to 15 litres using extender ring
Thermostat	60-250 °C
Timer	0-120 minutes
Overall Dimension (With Base Stand)	(H) 330 mm (W) 410 mm
Glass Container Dimensions	(H) 165 mm (Ø) 330 mm
Net Weight	6.35 kg

CONNECTION TO POWER

- Before connecting, check that the voltage indicated on the appliance (bottom of the appliance) corresponds with the main voltage in your home. If this is not the case, consult your dealer and do not use.
- This appliance may be fitted with a non-rewirable plug. If you need to change the fuse in a non-rewirable plug, the fuse cover must be refitted. If the fuse cover is lost or damaged, the plug must not be used until a replacement is obtained (available from the appliance manufacturer).
- If the plug has to be changed because it is not suitable for your socket, or becomes damaged, it should be cut off and appropriate plug fitted following the wiring instructions. The plug removed must be disposed of safely as insertion into a mains socket is likely to cause an electrical hazard.
- This unit must be earthed.
- This equipment must be disconnected from the mains when not in use. Do not allow this unit to be exposed to rain or moisture.

The wires in the Mains Power Lead are coloured with the following code:


BLUE	=	NEUTRAL
BROWN	=	LIVE
GREEN-YELLOW	=	EARTH

IMPORTANT:

If the colour of the wires in the mains power lead do not correspond with the coloured marking identifying the terminals in your plug, proceed as follows:

- Blue must connect to the terminal marked N(Neutral)or coloured Black.
- Brown must connect to the terminal marked L(Live)or coloured Red.
- Green/Yellow must connect to the terminal marked E (Earth) or coloured green.

Ensure that the plug is fitted with a 13 amp fuse (BS1362).



WARNING:

Disconnect from the Mains Power Supply when not in use or before removing the cover from the plug.

Do not expose this unit to rain or moisture.

Mains Supply: 220-240V~ 50Hz only.

DISPOSAL INFORMATION



Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your local authority for recycling advice.



PRODUCT GUARANTEE

This product is guaranteed against manufacturing defects for a period of



Year

This product is guaranteed for twelve months from the date of original purchase.

Any defect that arises due to faulty materials or workmanship will either be replaced, refunded or repaired free of charge where possible during this period by the dealer from whom you purchased the unit.

The guarantee is subject to the following provisions:

- The guarantee does not cover accidental damage, misuse, cabinet parts, knobs or consumable items.
- The product must be correctly installed and operated in accordance with the instructions contained in this manual. A replacement copy of this instruction Manual can be obtained from www.argos-support.co.uk
- It must be used solely for domestic purpose.
- The guarantee will be rendered invalid if the product is re-sold or has been damaged by inexpert repair.
- Specifications are subject to change without notice.
- The manufacturer disclaims any liability for the incidental or consequential damages.
- The guarantee is in addition to, and does not diminish your statutory or legal rights.

Guarantor: Argos Limited
489 - 499 Avebury Boulevard
Central Milton Keynes
MK9 2NW
www.argos-support.co.uk