

1 Assembly

Warranty Information

Grey Technology has provided the SW22 Cordless Power Sweeper with a **12 month guarantee**.

In Guarantee:

Please retain your receipt as proof of purchase. In the rare and unfortunate event of your Gtech product being faulty, please accept our apologies and we will aim to remedy the problem as fast as possible once brought to our attention. However please be aware that due to Company Policy, Grey Technology can only repair or replace all or part of the product if proof of purchase is provided and the claim is made within 12 months of the purchase date.

If your product is within the 12 months warranty period you should either return this product with its receipt to the retailers where the product was purchased or if a simple part or advice is required ring the Gtech Helpline where we will be more than happy to assist.

Note: Gtech cannot refund any monies if the product was brought from a third party.
Note: The battery is a consumable item and is not covered by this guarantee.

We would like to remind our customers that the Gtech guarantee does not cover any unauthorised repairs and will be annulled:

- 1 if the product has been damaged due to incorrect use or maintenance.
- 2 if any part is modified or replaced or if it is used in any way that is not recommended by Gtech.
- 3 if it is used with any parts not produced or not recommended by Gtech.
- 4 if it is used for purposes other than those specified by Gtech.

If after reading the manual and following the instructions you are sure that the product is defective please call the **Gtech Helpline on 01905 345891**.

A Customer Service Advisor will be available to deal with any problems you have with our product. To assist them please be ready with the product, a detailed description of the problem, and your proof of purchase.

Out of Guarantee:

If your Gtech product is over 12 months old and you need any parts or advice then please contact our Helpline. Parts will be sent out usually within 2 weeks of request.

The  symbol indicates that this product is covered by legislation for waste electrical and electronic products (EN2002/96/EC)

When the sweeper has reached the end of its life, it and the Li-Ion battery it contains should not be disposed of with general household waste. The battery should be removed from the sweeper and both should then be disposed of properly at a recognised recycling facility.

WARNING: Only use the charger supplied with the product.

Call your local council, civic amenity site, or recycling centre for information on the disposal and recycling of electrical products. Alternatively visit www.recycle-more.co.uk for advice on recycling and to find your nearest recycling facilities.

Using another charger may damage the product and the battery and will invalidate your guarantee.


13/03



Gtech
clever cordless creations

customer helpline **01905 345891** support@greytechnology.co.uk
www.gtechonline.co.uk

Gtech
SW22




- | | |
|---------------------------|--|
| 1 Main Unit | 7 Lower Handle |
| 2 Brush Bar | 8 Recocharge Charging Station (inside Dust Tray) |
| 3 Front Visor | 9 LED Indicator |
| 4 Dust Tray | 10 ON/OFF button |
| 5 Upper Handle | |
| 6 Telescopic Handle Tubes | |

Technical specification

Unit operating cycle with full battery	up to 2 hours (dependent on floor surface)
Battery type	7.4V DC 2600mAh Li-Ion
Charging period for fully discharged battery	3 hours
Battery charger output	10V DC, 1000mA
Battery charger model	GTECH-100100
Sound Level	75db (A)
Weight	1.4Kg

WARNING: Only use a replacement battery as supplied by the manufacturer and only use the charger provided with the product. Using another charger may damage the product and battery.

IMPORTANT: READ ALL INSTRUCTIONS BEFORE USE. RETAIN INSTRUCTIONS FOR FUTURE REFERENCE.


 Do not use in rain or leave outdoors whilst raining.

Important Safeguards


- 1 Do not store or charge the unit outdoors.
- 2 Do not use outdoors or on wet surfaces.
- 3 Do not handle the charger or appliance with wet hands.
- 4 Not to be used as a toy; pay close attention when used by or near children.
- 5 This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- 6 Children should be supervised to ensure that they don't play with the appliance.
- 7 Use only as described in this manual.
- 8 Never modify the charger in any way.
- 9 Only use the charger supplied with the product. Do not attempt to use the charger with any other product nor attempt to charge this product with another charger. A charger that is suitable for one type of battery pack may create a risk of fire when used with another battery pack.
- 10 Do not abuse the charger cord as this can increase the risk of fire or electric shock. Never carry the charger by the cord. Do not pull the cord to disconnect from a socket; grasp the plug and pull to disconnect.
- 11 If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.
- 12 A hazard may occur if the appliance runs over the supply cord.
- 13 The plug must be removed from the socket before cleaning or maintaining the appliance.
- 14 Keep the charger cord away from hot surfaces and sharp edges.
- 15 Do not handle the charger with wet hands.
- 16 The battery must be removed from the appliance before it is discarded.
- 17 Before use check the power supply and charger cord for signs of damage or ageing. To avoid damage it is not recommended to wrap the cord around the charger for storage. A damaged or entangled charger cord can increase the risk of fire and electric shock.
- 18 The appliance must be disconnected from the mains supply when removing the battery.
- 19 This product includes Li-Ion batteries; **do not incinerate batteries or expose to high temperatures**, as they may explode. Leaks from battery cells can occur under extreme conditions. If the liquid gets on the skin wash immediately with soap and water; if the liquid gets into the eyes, flush them immediately with clean water for a minimum of 10 minutes and seek medical attention. Liquid ejected from the battery may cause irritation or burns. In an emergency situation contact professional help immediately!
- 20 Do not use with any opening blocked; keep openings free of dust, lint, hair and anything that may interfere with the brushes.
- 21 Keep hair, clothing, fingers, and all parts of body clear of moving parts.
- 22 Do not pick up anything that is flammable, burning or smoking.
- 23 Use extra care when cleaning on stairs.
- 24 Use extra care when cleaning on stairs.

FOR HOUSEHOLD USE ONLY


2 Operation





Floor Cleaning



- 1 For normal cleaning push the sweeper flat over the floor.



- 2 For deeper cleaning and carpet grooming, lift the Handle to lower the brush bar into the carpet.




Handheld Operation and Stair Cleaning

Carrying

To avoid spilling dirt from the Dust Tray do not carry the product 'nose down'.

Bin Empty

To achieve the best performance, empty the Dust Tray after each use.



4 Care & Maintenance

WARNING: Do not accidentally turn the unit on while cleaning it.

Each week clean the product with a dry cloth, plus the chamber in which the Dust Tray fits. Remove hair and fibre from the Brush Bar and Edge Wheel.



- 1 Don't use abrasive materials to clean the product or immerse it in water.
- 2 Don't pick up liquids or use on wet floors.
- 3 Don't use on concrete, Tarmac or other rough surfaces.
- 4 Don't pick up pieces of string or fabrics with the unit.
- 5 Don't clean rug tassels or frayed carpets with the unit.

Brush Bar & Edge Wheel Removal

The Brush Bar and Edge Wheel can be removed for cleaning or replacement.

- 1 Push the latch and un-hook the Edge Wheel Cover from the front of the unit.
- 2 Slide the belt off the end of the Brush Bar drive gear.
- 3 Lift the end of the Brush Bar, then slide out of the unit.
- 4 The Edge Wheel Brush can be pushed out of the cover.
- 5 Remove any hair, fibre and dust from the Edge Wheel and Brush Bar.
- 6 Replace the Brush Bar by fitting the shaft into the bearing in the housing, then engage the end with the drive gear into the unit. **Note: peg to relocate into unit.**

Note: peg to relocate into unit.




Product Is Not Working Properly?

- 1 Empty the Dust Tray.
- 2 Remove any build-up of hair or fibre from the Brush Bar and Edge Wheel.
- 3 If the product does not operate and the LED indicator flashes RED then recharge the battery.
- 4 If the LED is flashing YELLOW clean the brush bar and remove any blockages.
- 5 If the Product does not operate and the LED is off then call the customer helpline

3 Battery Charging and Status Indication

- 1 Plug the charging stand into an electrical outlet. Place the sweeper onto the charging stand with the rear of the unit sitting over the contacts.



- 2 The LED indicator shows the charge level of the battery when charging.

Charging status

- = Less than 80%
- = More than 80%
- = Fully charged

A discharged battery will only take around 3 hours to fully recharge. Charging will stop automatically when the battery has fully charged. The ecocharge stand has an efficient standby function to top up the battery when needed. If not being used the product can be left on the charging stand so it will always be fully charged until it is needed for use.

- 1 **WARNING:** Only use the charger provided with the product. Using another charger may damage the product and battery.
- 2 Before use check the power supply and charger cables for signs of damage or ageing. A damaged charger can increase risk of fire or electric shock.
- 3 If the battery is damaged in any way do not attempt to charge it and replace it immediately.

To maintain optimum battery life and performance it is recommended to follow these guidelines. Storing a fully discharged battery for over 1 month can damage the battery and reduce its life. Recharge a flat battery after use, and do not leave the battery in a fully discharged condition for more than 1 month. If the product is to be stored for a longer period of time partly charge the battery every 3 months.

The LED indicator shows the charge level of the battery when discharging during use. When the battery is fully discharged the product will stop and the LED flashes red.

Discharging status

- = More than 20%
- = Less than 20%
- = Less than 10%
- ☀ = Flashing red : battery fully discharged and needs recharging.

The product has a protective cut out function that will operate in case of overloading or jamming of the brush bar. The product will stop and the LED indicator will flash yellow.

- ☀ = Flashing yellow : clean the brush bar

Remove any blockage or objects jamming the brush bar. Clean any hairs or fibre from the brush bar. Wait until yellow LED stops flashing, then press the button to restart the unit.





5 Battery Pack Removal & Replacement

At the end of the product's or battery's life the battery should be removed for disposal and recycling. Only a technically competent person should undertake battery removal and replacement.

If uncertain as to how to replace your battery pack, we suggest you take your unit to a reputable small appliance service technician to have this service performed.

Follow these steps for battery removal or replacement:

- 1 Switch off the product and ensure the Charger is disconnected.
- 2 Remove the Telescopic Tubes and Dust Tray.
- 3 Turn the unit over, being careful not to switch the product on.
- 4 Press the clip to release the Battery Cover.
- 5 Carefully lift the battery out, press the clip and pull the connector to disconnect the battery (fig a)
- 6 Remove the protective connector cover from the new battery.
- 7 Push the connectors together, ensuring they are securely fitted. (fig b)
- 8 Place the battery into the product and refit the cover. (fig c)



WARNING: Never touch the metal contacts in the connectors with a metal object.

ONLY USE A REPLACEMENT BATTERY AS SUPPLIED BY MANUFACTURER
Replacement batteries, Brush Bars and Edge Wheels can be purchased through the helpline Tel: 01905 345891 or by visiting www.gtechonline.co.uk