Move 2

Index / Move 2

Overview

Sonos Move 2 is the premium portable speaker that lets you bring powerful stereo sound from room to room and outdoors.

- **Weatherproof design.** Move 2 doesn't fear water and dust resistance levels mean it's tumble-safe, pet-proofed, and other outdoor-worthy.
- **Battery lasts up to 24 hours.** Easily recharge by setting Move 2 on the included charging cradle. Or use the USB-C cable for a quick boost.
- **Stream music over Wi-Fi and Bluetooth.** Get access to countless stereo sources with Wi-Fi. Use Bluetooth when you're out.
- **Sonos S2 compatible.** Sonos S2 controls the Sonos app and unlocks features like the Sonos Voice Control and Trueplay™.
- **Line-in.** Add your source easily by wall-Move 2 to your Sonos system.

Controls and lights

Volume control

- Volume up (audio right, or top on 1)
- Volume down (audio left, or top on 2)

Note: When Move is playing, press and hold 1 or 2 to quickly change the volume.

Play/Pause

- Press once to play or pause audio.
- Press and hold to group with the audio playing on another Sonos player (or ungroup).

Next/Previous

- Press + to skip to the next song.
- Press - to go to the previous song. Press and hold - to rewind through the track. Release to resume playback.

Voice set-mute on/off

Press the voice set-mute button to turn voice recognition on or off. When it's off, the mic icon across it is the lamp.

- When the light is on, voice control is enabled.
- When the light is off, voice control is disabled.

Press the voice set-mute button to open the voice settings in the Sonos app.

Status light

Displays the product's connection to WiFi or Bluetooth. Indicates when the volume is turned up and speaks up to. [Learn more](#)

Battery Light

Indicates the battery status.

- Blinking orange indicates low battery.
- Solid orange indicates the battery is charging. The light will stay on for a 10-second time then turn off, unless the battery is full.

Note: Press battery check in the Sonos app.

Connector panel

1	**Handle**	Attach to easy lifting and carrying any you can take the Move 2 wherever you go.
2	**Power button**	**Press to power on.** The status light turns to let you know Sonos Move 2 is active. **Press to put to sleep.** The status light turns off and you'll hear a short tone. **Press and hold to power off.** The status light turns off and you'll hear a short tone. **Note:** Move 2 goes to sleep automatically after 30 minutes when not off the charging base.
3	**Bluetooth button**	Press to connect to a mobile device via Bluetooth. Move 2 will automatically connect to the last device used. Press again to disconnect the current device. Press and hold to pair a new device.
4	**Universal microphone switch**	Turn and microphone on or off. You can tap on voice control on the Sonos app. • When the switch is off (down), the mic and lamp are disabled so that Sonos Voice Control and Alexa can't hear you. The lamp is off. • When the switch is on (up), microphone-related features like auto-Trueplay are available. Sonos control is available if the voice assistant is turned off on the connected device.
5	**USB-C port**	• **Power.** Use a compliant USB-PD power supply to 45 W. • **Service.** Connect to a computer for updates. • **Ethernet.** Use the Sonos Combo, Ethernet and an Ethernet cable to connect to your router. Ethernet is the most reliable way to use wireless Sonos and your wireless broadband if your WiFi is crowded. • **Line-in.** Use the Line-in to Sonos or Line-in Combo Adapter to connect your turntable, CD player, or other device.
6	**Charging dock**	Set Move 2 on the charging base and it snaps onto for at home use while recharging. **Note:** Move 2 is designed to be used only with the Move 2 WC-1 USB-C PSU power supply or any other USB-C compliant USB-PD power supply to 45 W.

Charging

FEATURE	DESCRIPTION
Charging base	Set Sonos Move 2 on its charging base for easy recharging. The battery light will turn on for 10 seconds to let you know Move 2 is seated correctly. Make sure the charging contacts are touching. Move 2 can be used while it's charging. The charging base is for indoor use only—be sure to keep it dry. **Note:** Check battery level in the Sonos app.
USB-C port	Move 2 is designed to be used only with the Sonos AC-W-USB-1 (70 W) power supply or any other USB-C compliant USB-PD power supply to 45 W recommended.

Battery Saver

You can enable **Battery Saver** in the Sonos app to lower power-to-battery life when Move 2 is inactive. Move 2 will automatically connect to WiFi when you press play.

1. Go to **Settings** ⚙.
2. Select Move 2 in your group.

Note: Move 2 won't respond in this Sonos app until it's powered back on.

Bluetooth pairing

1. Turn Bluetooth on in your device settings.
2. Press and hold the Bluetooth button on the back of the speaker until you hear a tone. Move 2 is in pairing mode when the speaker is ready to pair.
3. Choose **Sonos Move 2** from the list of available devices in your Bluetooth settings. Your mobile device will automatically connect next time you press the Bluetooth button.

Select a location

You can put your Sonos Move 2 just about anywhere. For maximum performance, here's a few guidelines:

- **Sonos Voice Control.** Locate your voice-set-to-mute speaker with the mic and microphone indicator lights. Sonos Voice Control controls sound by voice—it only takes a few seconds to add when you set up your speakers. [Sonos.com/voice](#)
- **Amazon Alexa.** Just install the Alexa app and the Alexa app with the Sonos skill enabled. You'll make requests to Alexa through the Sonos app. [Sonos.com/alexa](#)

Tip: Don't put Sonos Move 2 where it can block your WiFi signal. Locate it where it can receive the strongest signal from your router. Use an Ethernet connection to your router if you have one. Ethernet is the most reliable way to use wireless Sonos and your wireless broadband if your WiFi is crowded.

Note: Move 2 is designed for supported indoor and outdoor locations. Don't place it where it can be exposed to rain or moisture.

Microphone on/off

The microphone in Sonos Move 2 is used for voice control and other features found in the **Settings** menu for each Trueplay™.

The universal microphone switch on the back allows you to quickly turn on or off all microphones in the Sonos system. When the microphone is off, the microphone indicator light on the front of Move 2 is lit.

Sonos Voice Control and Alexa will not respond to your voice when the microphone is turned off.

When the voice control light is on:

- If you set up voice control, it's ready to listen.
- Sonos Voice Control is enabled and ready.
- Alexa is enabled and ready to listen.

When the voice control light is off:

- If you set up voice control, it's not available.
- The universal microphone switch could be on or off.

Battery Saver

You can enable **Battery Saver** in the Sonos app to lower power-to-battery life when Move 2 is inactive. When Battery Saver is on, Move 2 will automatically connect to WiFi when you press play.

1. Go to **Settings** ⚙.
2. Select Move 2 in your group.

Note: Move 2 won't respond in this Sonos app until it's powered back on.

Auto Trueplay

Trueplay tuning optimizes the Sonos Room and Move 2 for the best sound. Trueplay tuning uses your speaker's microphones to detect the environment and make specific tuning adjustments so you get great sound wherever you've placed it. Trueplay tuning takes about a minute listening to:

1. Select **Settings** ⚙.
2. Choose the product you want to tune.
3. Select **Trueplay**, and then turn **Auto Trueplay**.

Set up stereo pair

Pair two Sonos speakers in the same room for an even wider, stereo experience. Use separate names as the left channel and one speaker as the right channel.

Note: The Sonos subwoofer is a stereo pair must be the same type.

Tip: Sonos Move 2 is designed to be used only with the power adapter included for S2 for Sonos line-powered products. Learn more about Sonos Move 2 and Sonos Move 2 power adapter.

1. Open the Sonos app, and go to **Settings** ⚙.
2. Choose one of the speakers you want to pair the stereo pair.
3. Select **Set Up Stereo Pair** in the pop-up.

Learn more

Trueplay tuning optimizes the Sonos Room and Move 2 for the best sound. Trueplay tuning uses your speaker's microphones to detect the environment and make specific tuning adjustments so you get great sound wherever you've placed it. Trueplay tuning takes about a minute listening to:

1. Select **Settings** ⚙.
2. Choose the product you want to tune.
3. Select **Trueplay**, and then turn **Auto Trueplay**.

Voice services

Use your voice to control your Sonos system with any voice assistant Sonos products: play and control music, adjust volume, and more.

- **Sonos Voice Control.** Control your whole home system with Sonos voice control built right into your speakers. Sonos Voice Control comes ready to use—it only takes a few seconds to add when you set up your speakers. [Sonos.com/voice](#)
- **Amazon Alexa.** Just install the Sonos app and the Alexa app with the Sonos skill enabled. You'll make requests to Alexa through the Sonos app. [Sonos.com/alexa](#)

Tip: Don't put Sonos Move 2 where it can block your WiFi signal. Locate it where it can receive the strongest signal from your router. Use an Ethernet connection to your router if you have one. Ethernet is the most reliable way to use wireless Sonos and your wireless broadband if your WiFi is crowded.

Note: Move 2 is designed for supported indoor and outdoor locations. Don't place it where it can be exposed to rain or moisture.

Trueplay™

Every room is different. Trueplay tuning measures how sound reflects off walls, furnishings, and other surfaces in the room. Then Sonos tunes your speaker to make sure it sounds great no matter where you've placed it. Trueplay tuning is one of the mobile devices running iOS 9 or later. During tuning, you'll move around the room. Here's how to get started:

1. Select **Settings** ⚙.
2. Choose the product you want to tune.
3. Select **Trueplay**, and then turn **Auto Trueplay**.

Auto Trueplay

Auto Trueplay automatically tunes your speaker whenever it detects a change in its environment. Auto Trueplay uses your speaker's microphones to detect the environment and make specific tuning adjustments so you get great sound wherever you've placed it. Auto Trueplay takes about a minute listening to:

1. Select **Settings** ⚙.
2. Choose the product you want to tune.
3. Select **Trueplay**, and turn on **Auto Trueplay**.

Set up stereo pair

Pair two Sonos speakers in the same room for an even wider, stereo experience. One speaker serves as the left channel and one speaker as the right channel.

Note: The Sonos subwoofer is a stereo pair must be the same type.

Tip: Sonos Move 2 is designed to be used only with the power adapter included for S2 for Sonos line-powered products. Learn more about Sonos Move 2 and Sonos Move 2 power adapter.

1. Open the Sonos app, and go to **Settings** ⚙.
2. Choose one of the speakers you want to pair the stereo pair.
3. Select **Set Up Stereo Pair** in the pop-up.

Learn more

Specifications

FEATURE	DESCRIPTION
Audio	
Amplifiers	Three Class-D digital amplifiers
Tweeters	Two angled tweeters create a crisp and accurate high-frequency response and stereo separation
Woofers	Two extended-excursion woofers for faithful playback of rich mid-range and frequencies and deep bass
Microphones	• Far-field microphone array • All microphones, including voice control, can be turned off using their universal microphone switch on the back of the speaker
Voice	• Integrated voice control • When the voice control light is off, voice assistants are not listening. Turn the voice-related features like auto-Trueplay and WiFi off.
Sonos	Enables Sonos app **Note:** The universal microphone switch must be turned on.
Auto Trueplay	This software continually optimizes the speaker's sound for its environment. Auto Trueplay is off by default. Enable in the Sonos app **Note:** The universal microphone switch must be turned on.
Adjustable EQ	• Bass • Treble • Loudness

Power & Connectivity

Power supply	**Charging base.** 100-240 VAC, 1.5A 50-60Hz, 7.2 A Output: 15.5 VDC, 2.2 A, 45 W **USB port.** USB-C PD power with 45 W, 20 VAC, 2.25 A **Note:** Move 2 can recharge using Wireless charging base.
Battery (Approximate)	**Capacity.** 7.700 mah **Replacement.** Visit our website for more information. **Playback.** Actual battery playback varies in varying conditions to determine the proper playback method to your area
WiFi	Connects to WiFi networks with any 802.11 a/b/g/n/ac/ 2.4 GHz or 5 GHz broadcast capable router
Bluetooth	Bluetooth 5.0 network audio streaming from any Bluetooth-enabled device
USB-C	Connect an audio source using an auxiliary cable and the Sonos Line-in Combo Adapter. Connect your router with an Ethernet cable for a wired Sonos system. (Ethernet-to-Ethernet adapter)
Charging	• When the Sonos wireless charging base is connected over 15 Watts required by the radio equipment, and now 45 Watts in order to achieve the maximum charging speed.
CPU	QuadCore 4x A53 1.4 GHz

Details & Dimensions

Dimensions (H x W x D)	6.53 x 6.29 x 4.84 in (165.7 x 159.7 x 122.9 mm)
Weight	6.61 lb (3.0 kg) (Includes battery)
Operating temperature	32° to 104° F (0° to 40° C)
Storage temperature	-13° to 158° F (-25° to 70° C)
Humidity resistant	Move 2 meets IP54 water and dust resistance levels **Note:** The charging base is for indoor use only.
Colors	Matte black Matte white Matte clay
What's in the box?	Move 2, charging base with 6 ft (2 m) USB-C to C cable, AC-W-USB-2 PSU power adapter, and Ethernet quick

Important safety information

Caution: Danger of explosion if battery is incorrectly replaced. Replace only with the same or equivalent type.

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this unit in or near water. Household cleaners or solutions can damage the finish on your Sonos product.

Sonos products with rubber rings on the bottom, such as Move, Move 2, One, and One SL, may leave a temporary mark on certain surfaces, including wood finishes. This may not be visible immediately and may appear in time. Use caution.

6. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus that produce heat.
7. Do not expose batteries (battery pack or batteries installed) to excessive heat such as sunshine or fire.
8. Only use attachments/accessories specified by the manufacturer, such as wall or ceiling mounts, carts, stands, tripods, brackets, or tables. Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
9. Unplug this apparatus during lightning storms or when unused for long periods of time.
10. Refer all servicing to Sonos qualified service personnel. Servicing is required when the apparatus has been damaged in any way.
11. The three-prong circuit is for safety purposes to disconnect the equipment.
12. Connect to a grounded, three-wire electrical outlet that is separated from any wireless radio. In order to maintain conformance with FCC radio frequency emission limits.

Warning: Changes or modifications to this unit not expressly approved by Sonos may void the user's authority to operate the equipment.