DCP-L3510CDW / DCP-L3517CDW / DCP-L3550CDW / DCP-L3551CDW / MFC-L3710CW / MFC-L3730CDN / MFC-L3735CDN / MFC-L3745CDW / MFC-L3750CDW / MFC-L3770CDW

Quick Setup Guide


Read the *Product Safety Guide* first, then read this *Quick Setup Guide* for the correct installation procedure.


Not all models are available in all countries.

The latest manuals are available at the Brother Solutions Center: support.brother.com/manuals.

D01LVD001-00
UK
Version A


Unpack the machine and check the components






Drum Unit and Toner Cartridge Assemblies*
(Black, Cyan, Magenta, and Yellow)


* Already installed in the machine



Waste Toner Box*



Belt Unit*



(For U.K.) (For Others)

Telephone Line Cord
(For MFC models)




AC Power Cord




Telephone Line Cord Adapter
(Australia only)
(For MFC models)




Brother Installation Disc



Quick Setup Guide



Product Safety Guide



Reference Guide
(only for certain models)

NOTE:

- The components included in the box may differ depending on your country.
- The available connection interfaces vary depending on the model.
- Interface cables are not included. You must purchase the correct interface cable if you require one.

  USB cable
  We recommend using a USB 2.0 cable (Type A/B) that is no more than 2 metres long.

  Network cable
  (DCP-L3550CDW / DCP-L3551CDW / MFC-L3730CDN / MFC-L3735CDN / MFC-L3745CDW / MFC-L3750CDW / MFC-L3770CDW)
  Use a straight-through Category 5 (or greater) twisted-pair cable.


- The illustrations in this *Quick Setup Guide* show the MFC-L3770CDW.

Secure Network Access
Your machine's default password is on the label on the back of the machine (preceded by "Pwd"). We strongly recommend you change it to protect your machine from unauthorised access.


Watch our Video FAQs for help with setting up your Brother machine:
support.brother.com/videos.


1 Remove the packing materials and re-install the drum unit and toner cartridge assemblies


Remove all the blue packing tape.




Slide all eight yellow drum locks.









Remove the orange part from each cartridge.





Push firmly.






2 Load paper in the paper tray







Adjust the paper guides.




Do not exceed this mark.






3 Connect the power cord and turn the machine on



Back



Front

4 Select your country/language (Initial setup only)

After turning the machine on, you may be required to set your country or language (depending on your machine).
If required, follow the on-screen instructions.

5 Select your language (if needed)
(Only for certain models)

■ For LCD models

1. Press **Menu**.
2. Press ▲ or ▼ to display [Initial Setup], and then press **OK**.
3. Press ▲ or ▼ to display [Local Language], and then press **OK**.
4. Press ▲ or ▼ to select your language, and then press **OK**.
5. Press **Stop/Exit**.

■ For touchscreen models

1. On the machine's touchscreen, press [Settings] > [All Settings] > [Initial Setup] > [Local Language].
2. Press your language.
3. Press ⌂.

6 Select a device to connect to your machine


Computer



Go to 7 and follow the instructions.


NOTE:
(For DCP-L3510CDW / DCP-L3517CDW / DCP-L3551CDW)
We recommend configuring wireless settings from your computer.

Mobile Device



Go to 8 and follow the instructions.

7 Connect your computer



Put the installation disc into your CD/DVD drive, or download the Full Driver & Software Package at:

For Windows®: support.brother.com/windows
For Mac: support.brother.com/mac

If you are using a recently released operating system on your computer, visit the above websites for updated driver and software information.

Brother regularly updates firmware to add features and apply bug fixes. To check for the latest firmware, visit support.brother.com/up7.

▶ **Follow the on-screen instructions and prompts.** ▶ **Finished**

For Windows®:
If the Brother screen does not appear automatically, go to **Computer (This PC)**. Double-click the CD/DVD-ROM icon, and then double-click **start.exe**.

For Mac:
For full driver functionality, we recommend choosing the **CUPS driver** when adding a printer.


Can't Connect? Check the following:

Wireless network	▶ Restart your wireless access point/router (if possible).	▶ Restart your machine and computer, and then go to 7.	▶ If still not successful, go to 8.
Wired network / USB connection	▶ Disconnect the cable.	▶	▶ If still not successful, visit support.brother.com for FAQs & Troubleshooting.

8 Alternative wireless setup

Find your SSID (Network Name) and Network Key (Password) on your wireless access point/ router and write them in the table provided below.

SSID (Network Name)	
Network Key (Password)	



If you cannot find this information, ask your network administrator or wireless access point/router manufacturer.


▶

■ For LCD models

To select each menu option, press ▲ or ▼, and then press **OK** to confirm.
Select [Network] > [WLAN] > [Setup Wizard].

■ For Touchscreen models

Press WiFi > [Setup Wizard] > [Yes].



▶

Select the SSID (Network Name) for your access point/router and enter the Network Key (Password).

When the wireless setup is successful, the touchscreen/LCD displays [Connected].

If setup is not successful, restart your Brother machine and your wireless access point/router, and repeat 8.

▶

Even if you do not have a wireless access point/router, you can connect your device and your machine directly. For additional wireless network support, go to support.brother.com/wireless-support.

For Computer

Go to 7 to install software.


For Mobile Device

Go to 9 to install apps.

9 Print or scan using your mobile device

Your mobile device must be connected to the same wireless network as your Brother machine.

Brother SupportCenter is a mobile app that provides the latest support information for your Brother product.
Visit the App Store or Google Play™ to download.



Works with Apple AirPrint

AirPrint is available for all supported iOS devices including iPhone, iPad and iPod touch. You do not need to download any software to use AirPrint. For more information, see the *Online User's Guide*.

Download and install the Mopria® Print Service app from Google Play™ using your Android™ device.

Download and install our free application **Brother iPrint&Scan** from a mobile application store, such as the App Store, Google Play™ or Microsoft® Store using your mobile device.

Optional apps
You can print from and scan to your mobile device using various apps. For instructions, see the *Online User's Guide*.

Additional Wireless Support: support.brother.com/wireless-support

For FAQs, Troubleshooting, and to download software and manuals, visit support.brother.com. For product specifications, see the *Online User's Guide*.

© 2018 Brother Industries, Ltd. All rights reserved.