REMATCH™ WIRELESS

QUICK START GUIDE

PLATFORM COMPATIBILITY
NINTENDO SWITCH™ 2
NINTENDO SWITCH™
NINTENDO SWITCH™ LITE
NINTENDO SWITCH™ OLED

CERTIFICATION MODEL:
CWBB0027


IMPORTANT
READ BEFORE USING

SETUP

1. Pairing the Controller

A. Turn on your Nintendo Switch™ 2 device and press any button on the controller.
B. If your controller does not automatically connect, it will need to be paired with the device.
C. Using the Joy-Con™ controllers, navigate to Controllers > Change Grip/Order.
D. Now, using your controller, press and hold the sync button (at the top of the controller by the charging port) for 3 seconds until it pairs and the player indicator light at the bottom is solid.

Tip: To unpair the controller from the Nintendo Switch™ 2, hold down the sync button (located at the top of the controller) for at least 1 second.




2. Re-connecting the Controller

A. If the controller is not connecting with the device, but has already been paired, simply go into Controllers > Change Grip/Order.
B. When prompted, press L and R on your controller to connect.

Tip: You can also press and hold the "Home" button to wake up the controller and Nintendo Switch™ 2 device.

3. Charging the Controller




A. When the controller is low on battery, the "function" button's LED (located at the bottom center of the controller) will blink RED every 30 seconds.
B. Using the included USB-C cable, connect the controller to one of the USB ports on the Nintendo Switch™ 2 dock.
C. While charging, the "function" button's LED will pulse RED. When the controller is fully charged, the LED will turn WHITE.

Note: To prevent the controller battery from completely draining out, please charge the controller every 3 months even if it's not in use.

4. Program Back Buttons

A. To program the back buttons, hold the "function" button and press the button you'd like to map a control to. Once the LED is lashing, press any button on the controller to map that button's function to the back. The LED will blink quickly 3 times, indicating successful programming.
B. To clear a mapped function or disable the back buttons completely, hold down the "function" button and double press any back button.



TURTLE BEACH™

Any questions?
www.turtlebeach.com/support

Please register your product to receive important updates.
www.turtlebeach.com/productregistration

For warranty, visit:
www.turtlebeach.com/warranty