BUSH

Instruction manual

KBB258 Party Lights Boombox



You'll soon be enjoying your new Party Lights Boombox

It all begins here, with your instructions. Don't worry, there's nothing too technical coming up. Just simple, step-by-step guidance to get you up and running quickly. Sound good? Then let's get started.

Help and Guidance

We're here to help you get the most from your Party Lights Boombox. Should you require any guidance, a simple solution can often be found online at:

www.bush-support.com

If you still require further assistance, call one of our experts on **0345 604 0105.**

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting**

BUSH

Contents

1 Safety information

Safety information 6

2 Getting to know your Party Lights Boombox

Ready? Let's begin 10

Connection 12

Power connection/Inserting batteries(optional) 13

Auxiliary connection 14

3 Using your Party Lights Boombox

Time setting/Inserting CD 16

Playing a CD 17

Programmed play mode 18

FM radio/AUX in Function 19

Bluetooth Connection/Party Lights Operation 20

4 Other information

Technical specification 22

5 Product support

Troubleshooting 24

Help and assistance 25

Disposal 26

Guarantee 27

section of these instructions, or online at **www.bush-support.com** If you still require further assistance, call one of our experts on **0345 604 0105**.

1 Safety information

Safety information

Important - Please read these instructions fully before installing or operating

Please take the time to follow the instructions in this owner's guide carefully. It will help you set up and operate your system properly and enjoy all of its advanced features.

- Please save this owner's guide for future reference.
- The product label is located on the back of the product.
- Do not use this apparatus near water or moisture.
- Do not use this product near a bathtub, washbowl, kitchen sink, and laundry tub, in a wet basement, near a swimming pool, or anywhere else that water or moisture is present.
- Do not leave it in high temperatures as electronic devices and plastic parts may warp in heat.
- Do not block or cover slots, holes or openings on the product by placing on soft furnishings such as carpets, rugs or beds as these are provided for functionality and/or ventilation to ensure safe operation of the product.
- Do not store in dusty or dirty areas.
- Servicing is required when the apparatus has been damaged in any way: such as liquid has been spilled or objects have fallen into the apparatus; the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
- Do not attempt to open the product. This product does not contain any user serviceable parts. Unauthorized handling of the device may damage it and will void your warranty.

Opening or removing covers may expose you to dangerous voltages or other hazards.
To prevent risk of fire or electric shock, avoid overloading wall outlets, extension cords, or integral convenience receptacles.
If this product will not be used for a long period of time, make sure that all of the batteries are removed from the battery compartments.

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting**

Safety information

Important - Please read these instructions fully before installing or operating



The exclamation point within an equilateral trangle is intended to alert the user to the presence of important operation and maintenance (servicing) instructions in the literature accompanying the appliance.

Fig 1.



The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated dangerous voltage within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons..

Fig 2.

The use of apparatus in moderate climates.

No naked flame sources,such as lighted candles,should be placed on the apparatus.

To preserve our environment,dispose of used batteries according to your local laws or regulations.

The mains plug is used as disconnect device,the disconnect device shall remain readily operable.

To reduce the risk of fire or electric shock,do not expose this apparatus to rain or moisture

Do not place objects filled with water,such as a vase,on the apparatus.

The battery shall not be exposed to excessive heat such as sunshine,fire or the like.



Invisible laser radiation when open and interlocks defeated.Avoid exposure to beam of laser.



This equiment is a Class II or double insulated electrical appliance,it does not require a safety connection to electrical earth.

section of these instructions, or online at **www.bush-support.com** If you still require further assistance, call one of our experts on **0345 604 0105**.

Getting to know your Party Lights Boombox

2

Getting to know your Party Lights Boombox

You'll be up and running in no time

Ready? Let's begin...

Please read these instructions carefully. They contain important information which will help you get the best from your product and ensure safe and correct installation and operation.

If you require any further assistance, our technical experts are happy to help. For full details, refer to the product support section at the end of these instructions.


Accessories

1. AC power cord



Accessory

2. Instruction manual



Accessory

Fig 3.

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting**

Getting to know your Party Lights Boombox

You'll be up and running in no time




Fig 4.

1. CD Compartment
2. FM Stereo Indicator
3. Power Indicator
4. LCD Display
5. Power button
6. Stop button
7. Skip backwords
8. Programme/ Repeat button
9. Clock setting button
10. Earphone jack
11. Skip forwards
12. Light switch button
13. Play/Pause
14. Speaker & Party Lights
15. Tunning
16. Telescopic Antenna
17. Volume
18. CD/AUX/BT/FM Switching button
19. AC Line in
20. AUX in jack
21. Battery Compartment
22. Handle

section of these instructions, or online at **www.bush-support.com** If you still require further assistance, call one of our experts on **0345 604 0105**.

Getting to know your Party Lights Boombox

You'll be up and running in no time

Connection

Please consider carefully where your boombox will be situated and make sure that it is:

- on a flat and stable surface
- within 1.4 metres of a power socket
- where you can fully extend the wire radio aerial
- at least 1 metre away from other electrical appliances to avoid interference.




Fig 5.

1. Extend the wire radio aerial. A vertical position is recommended for maximum signal strength.
2. Plug the mains power plug into the mains power wall socket and switch on (Fig 5). Then press power button, the red power LED to the right of the display will light up.

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting**

Getting to know your Party Lights Boombox

You'll be up and running in no time

Power connection / Inserting batteries (optional)

Before inserting the batteries (not included), please ensure that the Boombox is unplugged from the mains power supply.

1. Underneath the Boombox, remove the battery compartment cover.
2. Insert 6 "C" size (UM-2) batteries(Fig 6), making sure to note the '+' and '-' markings and position the batteries the correct way around.
3. Replace the battery compartment cover, making sure that it 'clicks' home.

Note: When the battery power is low, you will notice that the audio quality will be a little distorted and the volume will be quieter. Please switch off the CD Cassette Boombox and replace the batteries.




Fig 6.

section of these instructions, or online at **www.bush-support.com** If you still require further assistance, call one of our experts on **0345 604 0105**.

Getting to know your Party Lights Boombox

You'll be up and running in no time

Auxiliary connection

Using a 3.5mm audio input connection cable (not included), allows for a quick and easy connection to an external sound source.

1. Connect one end of a 3.5mm audio connection cable to the headphone or auxiliary out socket of your secondary device, connect the other end to the Line in socket on the back of your Boombox.
2. Slide the Mode switch to 'CD (AUX)'.
3. Press the Play button on your external device to start playback through the Boombox speakers.
4. To gain optimal volume levels, adjust the volume control on both the secondary device and on the Boombox.

Note: It is recommended that you unplug the audio cable from the Line in socket after you have finished listening to your external device, as the CD player cannot be used whilst an audio cable is connected. Please wait for approximately 15 seconds after unplugging the audio cable, for the Boombox to return to CD mode.

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting**

Using your Party Lights Boombox

3

Using your Party Lights Boombox

Let's get started

Time setting

1.Press and hold the CLOCK button;24H will be displayed & flashing.
2.When 24H is flashing,press the CLOCK button until the hour digit flashes.
3.Using the SKIP(forward or backward) button to select the hour.
4.Press CLOCK button to confirm the hour.The minute digits will now flash on the display.
5. Using the SKIP(forward or backward) button to select the minutes.
6.Press CLOCK button to confirm the minutes and complete the time setup.

Inserting a CD

Check that your Boombox is in CD (AUX) mode.

1. Lift up the lid of the CD player on the front edge, where there is a scooped recess.

Note: On first use, please remove the protective card from the CD compartment.

2. Place and audio CD with its label side upward in the CD compartment and close the lid of the CD player.
3. The total number of tracks on the CD will appear in the LED Display after a few seconds.

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting**

Using your Party Lights Boombox

Let's get started

Playing a CD

Your Boombox will play audio CDs as well as CD-Recordable (CD-R) and CD-Rewritable (CD-RW) CDs. Do not attempt to play CD-ROM, CDI, VCD, DVD or computer CDs.

Note: If you stop or pause playing a CD for 20 minutes, your Boombox will switch off automatically.

1. Press the CD PLAY/PAUSE button. The Play/Program Indicator will light and the CD will start playing from the first track.
2. Adjust the Volume control to obtain the desired sound level from the Built-in Speakers.
3. To suspend playing, press the CD PLAY/PAUSE button and the track no. of the playback track will flash.
   To resume playing, press the CD PLAY/PAUSE button again.
4. You can choose to play your favorite track directly by pressing either the Skip Forward button or Skip Backward button. The LCD Display will indicate the correct track number selected.
5. To locate a particular passage within a track, keep the CD Search Forward button or CD Search Backward button depressed until it is found.
6. To repeat a particular track, press the CD Repeat button until the CD Repeat Indicator flashes.
7. To repeat the entire CD, press the CD **Prog/**Repeat button again until the CD Repeat Indicator lights steadily.
8. To repeat off, press the CD **Prog/**Repeat button again until the CD Repeat Indicator disappear.

section of these instructions, or online at **www.bush-support.com** If you still require further assistance, call one of our experts on **0345 604 0105**.

Using your Party Lights Boombox

Let's get started

Programmed play mode

In programmed play mode, you can program the play order of the tracks on your CD. You can program up to 20 tracks in total.

1. In CD stop mode, press the PROG/**REPEAT** button once. PROG L**C**D will appear and blink in the L**C**D Display.
2. Press the CD Skip Forward button or CD Skip Backward button to select the song to be programmed.
3. Press the PROG/**REPEAT** button again to store selection. The L**C**D display will blink to prompt for input.
4. Press the CD Skip Forward button or CD Skip Backward button to select the next song to be programmed and press the PROG button to store the second selection.
5. You may repeat steps 2 – 4 to program up to a total of 20 tracks.
6. Press the CD PLAY/PAUSE button to start playing in the programmed sequence.
7. To cancel programmed play, press the CD STOP button.

To exit programmed play mode, press the CD STOP button twice

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting**

Using your Party Lights Boombox

Let's get started

FM radio

1. Set the FUNCTION selector switch to the FM position.
2. Adjust the sound level using the VOLUME control.
3. Rotate the TUNING control to set the frequency required.
4. To insure maximum FM tuner reception, the Telescopic Antenna should be fully extended and rotated to obtain the best possible station reception.

section of these instructions, or online at **www.bush-support.com** If you still require further assistance, call one of our experts on **0345 604 0105**.

Bluetooth Connection

1. Slide the function switch to “BT”.
2. Active the Bluetooth function on your Bluetooth smart device.
3. Scan Bluetooth devices from your smart device and select "BUSH KBB-258BT".
4. Once paired successfully, you can play music.
5. The device will go into auto standby if there is not activity for 15minutes

Party Lights Operation

By pressing Light button,Six different modes of party lights for selection.

4 Other information

Other information

Helpful technical information

Specification

Power Supply:	AC 230-240V/50Hz
Power Consumption:	14W Max.
Batteries:	6 x 1.5V C size (UM-2) (Optional, Not included)
Output:	1W x 2 RMS
FM Frequency:	87.5MHz to 108 MHz
Supported CD Types:	CD / CD-R / CD-RW

Bluetooth v4.2 (Profile support: A2DP, AVCTP, AVDTP, AVRCP, HFP, SPP)

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting**

Product support 5

Product support

Help is always at hand

Troubleshooting

Problem	What to do
The unit does not work	Check if the batteries are inserted properly and not exhausted. Check if the mains cable is properly connected to the wall outlet and socket at the rear of the boombox.
No or distorted sound	Increase or decrease the volume level of the unit or of the external device in AUX IN mode. Clean the CD with a soft cloth or insert a different CD. Check the connection with the 3.5mm AUX IN jack. If in Bluetooth mode ensure the volume is turned up on the smart device
Poor FM reception	Fully extend the telescopic antenna. Move the boombox to a different location away from other electrical equipment.
CD tracks are skipped during play back	Clean the CD with a soft cloth or insert a different CD.
Bluetooth can not connect	Make sure your devices are within 10 metres from the Boombox Check you have activated the smart device bluetooth function Check the device is in the Bluetooth mode The device will go into auto standby if there is not activity for 15minutes

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting**

Product support

Help is always at hand

Help and assistance

If you require any technical guidance or find that your CD Casstte Boombox is not operating as intended, a simple solution can often be found in the **Troubleshooting** section of these instructions or online at **www.bush-support.com**

If you still require further assistance, call one of our experts on **0345 604 0105** . To help give us give you a fast and efficient service please have the following information ready:

Model Ref.		You can find these on the rating plate - a small information panel (usually a sticker or metal plate) on the rear of your product.
Serial number		
Date of purchase		This will be shown on your receipt

Local call rates applies*

Lines open 8am-7pm Monday to Saturday and 10am-4pm Sunday.

*Calls to Argos enquiry lines may attract a charge and set up fee from residential lines depending on your call plan/tariff. Mobile and other providers costs may vary, see www.bt.com/pricing for details.

For security and training purposes, telephone calls to and from customer service centres may be recorded and monitored. Calls from Republic of Ireland will attract international call charges.

section of these instructions, or online at **www.bush-support.com** If you still require further assistance, call one of our experts on **0345 604 0105**.

Product support

Help is always at hand

Disposal

The symbol on the product or its packaging indicates that this product may not be treated as household waste. Instead it should be handed over to the applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. For more detailed information about recycling this product, please contact your local council office your household waste disposal service or the shop where the product was purchased.



Declaration

Argos Ltd.hereby delcares that this Turntable with legs is in compliance with the essential requirements and other relevant provisions of the Radio Equipment Directive 2014/53/EU.The complete declaration of conformity can be obtained by contacting http://www.argos-support.co.uk

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG,Inc. and any use of such marks by Sainsburys Argos is under license.Other trademarks and trade names are those of their respective owners.

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting**

Product support

Help is always at hand

BUSH

Call us now and activate your 12 month guarantee

Thank you for choosing Bush. Your new product is guaranteed against faults and breakdowns for 12 months. Don't forget to register it with us today so we can provide you with our best possible after-sales service and useful updates.

www.bushregistration.co.uk

FREEPHONE*

0800 597 8548

Lines are open 8am - 8pm, 365 days a year. *Calls may be recorded and monitored.

Your Bush Guarantee

This product is guaranteed for twelve months from the date of original purchase. Any defect that arises due to faulty materials or workmanship will be repaired free of charge (or if applicable the product will be replaced or the purchase price refunded) where possible during this period by the dealer from who your purchased the unit.

The guarantee is subject to the following provisions:

- The guarantee does not cover accidental damage, misuse, cabinet parts, knobs or consumable items.
- The product must be correctly installed and operated in accordance with the instructions contained in the manual.
- It must be used solely for domestic purposes. The guarantee will be rendered invalid if the product is re-sold or has been damaged by inexpert repair.
- Specifications are subject to change without notice.
- Bush disclaim any liability for loss or damage arising from the breakdown of the product.
- This guarantee is in addition to and does not diminish your statutory or legal rights.

Important Data Protection Information

To find out how we and Domestic & General insurance Plc use your data

Please refer to the guarantee registration material or visit www.bushregistrations.co.uk

Guarantor: Argos Limited - 489 - 499 Avebury Blvd. - Milton Keynes - MK9 2NW

section of these instructions, or online at **www.bush-support.com** If you still require further assistance, call one of our experts on **0345 604 0105**.

BUSH

Contact:

www.bush-support.com

Helpline: 0345 604 0105