Era 100 SL



Model: Era 100 SL

Overview

The compact smart speaker designed for room-filling sound

- Powerful sound with 360° omnidirectional audio
- Tonally balanced, with 75° dispersion and 20Hz–20kHz frequency response
- Voice assistant built-in, with far-field microphones
- Four-color LED ring indicates volume, mute, and more
- Can be placed vertically or horizontally


See [Setup](#) to find out how to add it to your system.

Control and lights



Volume control	• Rotate up (clockwise) to increase volume • Rotate down (counterclockwise) to decrease volume **Note:** When the limit is reached, there's a tone. Also, the LED ring indicates the limit.
Play/Pause	• Press once to play a track • Press to pause • Press twice to skip the track • Press three times to go back a track
Mute/Volume	• Press 4 to mute the mic • Press 5 to set the volume **Note:** You can't tap the buttons to set the volume. Instead, you must rotate the volume control.
Status light	Shows how sound is received by a Wi-Fi® network and the sound system. See [Light status](#).

Connector panel



Ethernet button	• Press and release to pair your speaker • Press and hold to reconnect
USB-C port	• Connect a USB-C cable to charge your speaker or for a wired connection, using the Ethernet to USB-C adapter (sold separately), to connect your speaker to your network and the internet • Connect a USB-C cable to your computer for a wired connection • Ethernet: Use the Ethernet cable to connect your speaker to your network and the internet. Use the Ethernet to USB-C adapter (sold separately) for a USB-C cable. • Line-in: Connect the Aux cord to listen to music from your phone or other device. See [Line-in](#).

Select a location

Your Era 100 SL can be placed anywhere. For best performance, here's a few guidelines:

- Place your Era 100 SL on a flat, stable surface, such as a table or shelf. Avoid placing it on the floor.
- Keep your Era 100 SL at least 2 cm away from walls and other objects. This helps deliver the best sound.
- Don't place your Era 100 SL in a location that exceeds the limits listed in [Specifications](#).

Learn more

Trueplay™

Trueplay tunes the sound of your speaker to the room it's in. It uses your device's microphone to measure the sound in your room, and then adjusts the speaker's audio to sound its best.

Every time, before the Trueplay update that sent out to you can start, you must:

- Download the Sonos app to your iOS device.
- Set up your speaker in the app.

Then, to tune your speaker:

- Choose the room you want to tune.
- Select [Trueplay](#).

Tune your room

Use the Sonos Trueplay to tune the room to suit your voice. Move about your room as the tone plays. Then, you're ready to start.

Note: Trueplay tuning is not available for stereo pairs, surrounds, or subwoofers. Trueplay tuning is not available for Sonos Arc, Sonos Arc Ultra, Sonos Beam (Gen 2), or Sonos Amp.

Tune your speaker

Use the Sonos Trueplay to tune the speaker to suit your voice. Move about your room as the tone plays. Then, you're ready to start.

Note: Trueplay tuning is not available for stereo pairs, surrounds, or subwoofers. Trueplay tuning is not available for Sonos Arc, Sonos Arc Ultra, Sonos Beam (Gen 2), or Sonos Amp.

Tune with an iOS device

Use the Sonos Trueplay to tune the speaker to suit your voice. Move about your room as the tone plays. Then, you're ready to start.

Note: Trueplay tuning is not available for stereo pairs, surrounds, or subwoofers. Trueplay tuning is not available for Sonos Arc, Sonos Arc Ultra, Sonos Beam (Gen 2), or Sonos Amp.

Learn more

Bluetooth pairing

Pair your Bluetooth device with your speaker to play audio from it.

- Place and hold the Bluetooth button at the back of the speaker until you hear a tone. After 3 minutes, the speaker stops looking for a device.
- Choose the Wi-Fi network that is available device in your Bluetooth settings. Your mobile device can't connect to a network. Learn how

Line-in

Connect a cable to play audio from a turntable, CD player, or other audio source. Then, you can play that audio throughout your home. Or, you can play it only on your speaker. Learn how to connect a line-in device and how to set it up.

Learn more

Set up stereo pair

Set the Sonos speakers in the same room as one color (Sonos Move 2 or Sonos speaker sold as the left channel. Then, set up the other speaker as the right channel.

Note: Stereo pairing is not available for Sonos Arc, Sonos Arc Ultra, Sonos Beam (Gen 2), or Sonos Amp. Also, you can't pair a Sonos Era 100 SL with a Sonos Era 100 SL.

- Choose the room where you want to pair speakers.
- Select [Manage](#).
- Choose the speaker you want to be the left channel.
- Select [Create Stereo Pair](#).

Learn more

Set up surrounds

An easy way to turn any compatible speaker system or home theater audio into surround sound experience. Add two Sonos speakers as surrounds to your Sonos Arc, Sonos Arc Ultra, Sonos Beam (Gen 2), or Sonos Amp.

- Choose a room with a speaker that can be a soundbar.
- Select [Manage](#).
- Select [Add surrounds](#) and then choose [Add bookshelf or tall speaker](#) or [Add Sonos Move 2](#).

Learn more

Compatible audio equipment

Sonos amps, connected outdoor speakers for your home. These settings are adjustable.

Subwoofer	Turn surround sound up or off.
Surround	Turn surround sound up or off.
Music Level	Adjust surround volume for music.
Movie Playback	Isolate Dialog or Full Range. Set Night Sound to On or Off.

Product settings

You can customize these products for your surroundings.

Name	Set a different name.
Room Name	If you move your speaker to a new room, you can change the name.
Turn off the microphones	Turn off the microphones so that they don't hear you. Learn how to turn the microphones back on.
Mic	Turn off the microphones so that they don't hear you. Learn how to turn the microphones back on.
Trueplay	Tune the speaker to the room it's in. Learn how to tune your speaker.
Airplay Level	Turn up or down the volume for AirPlay® 2 audio. Learn how.
Battery Light	Set the battery light to On or Off. Learn how.
Touch Controls	Set the touch controls to On or Off. Learn how.
Satellite Tweak	Set the satellite tweak to On or Off. Learn how.
About	Check product's info like serial number, software version, and more.

Manage, add, and separate your group

Add a room to a group, or you can change the name of a group. Learn how.

- Choose a speaker, room, or group.
- Select [Manage](#).

Then, you can do any of the following:

- Choose a speaker, room, or group to add to your group.
- Select [Separate](#), and then select [Separate](#) to remove a speaker from a group.

Identify speakers in a group

If you have more than one speaker in a group, you can tell them apart by Sonos' blinking. Learning this helps you identify which speaker is which. Then, you can change the name of the speaker in the Sonos app. Learn how.

- Choose a speaker, room, or group.
- Select [Manage](#).
- Select [Identify speakers in a group](#).

Accessories

Find the perfect accessory for your Sonos system, ordered it directly in the Sonos app or [shop.sonos.com](#). Here's a few accessories that work with your Era 100 SL.

Era 100 Stand

Create adjustable stand for the Era 100 and Era 300. Fits both speaker securely in place.

Compatible products

- Connect to Sonos Arc with the speaker's power cord for clean cable management.
- Connect to Sonos Arc with the speaker's power cord for clean cable management and the [Ethernet to USB-C adapter](#) for a wired connection.

What's in the box?

Each Era 100 Stand comes with the following parts:

- 1 Era 100 Stand
- 1 Anti-slip pad
- 1 Cable management clip
- 1 Ethernet cable
- Attachment with 3 screws, 3 nuts, 1 bolt, 1 washer
- Allen key

What you'll need

- Phillips head screwdriver

Set it up

1. Take the attachment off the box and place the Era 100 Stand on a flat surface. Then, remove the attachment from the Era 100 Stand.

2. Position the speaker with the Ethernet port facing down. Then, align the holes on the attachment with the holes on the speaker and secure with the screws.

3. Insert the open end of the bracket in the attachment and secure with the bolt, washer, and nut. Then, tighten with a Phillips head screwdriver.

4. Insert the speaker's power cord into the Ethernet to USB-C adapter (sold separately) and connect the adapter to the speaker. Then, connect the other end of the Ethernet cable to the adapter.

5. Plug the power cord of the speaker into the power cord of the Sonos Arc.

6. Plug the cable into the Sonos Arc and route it around the Era 100 Stand.

7. Plug the power cord into a power outlet. Then turn the power on.

Era 100 Wall Mount

- The way to mount each Era 100 and Sonos Era 100 SL.
- Mounts your speaker in a vertical position, with power cord and cable out the back.

Create a flexible installation you can adjust for the best sound. Mount your speaker vertically or horizontally, with the power cord and cable out the back. Then, tilt it up or down for the best sound.

What's in the box?

Each Era 100 Wall Mount comes with the following parts:

- 1 Era 100 Wall Mount
- 1 Anti-slip pad
- 1 Cable management clip
- Attachment with 4 screws in flat and bolt shape, 1 bolt shaped, washer (part)

What you'll need

- Phillips head screwdriver
- Level

Set it up

1. Place the included template on the wall where you want to mount your speaker. Then, use a level to make sure the template is straight. Mark the screw holes on the wall.

2. Insert the screws into the holes in the attachment. Then, secure the attachment to the wall with the screws.

3. Insert the open end of the bracket in the attachment and secure with the bolt, washer, and nut. Then, tighten with a Phillips head screwdriver.

4. Plug the power cord of the speaker into the power cord of the Sonos Arc.

5. Plug the cable into the Sonos Arc and route it around the Era 100 Wall Mount.

6. Plug the power cord into a power outlet. Then turn the power on.

7. Position the speaker with the Ethernet port facing down. Then, align the holes on the bracket with the holes on the speaker and secure with the screws.

8. Position the speaker at the angle you like. Then, use the Allen key to tighten the screw on the bracket.

9. To attach the cable tie mount, select the location for the cable tie mount. Then, use the screw to attach the cable tie mount to the wall.

10. To attach the cable tie, wrap the cable tie around the cables. Then, insert the cable tie into the cable tie mount.

Specifications

Feature	Description
AUDIO	
Amplifier	Three class-D digital amplifiers
Tweeter	Two custom elliptical tweeters with waveguides for wide dispersion, enhanced clarity, and extended output at high volume
Woofer	One mid-woofer driven by two times the excursion of two traditional woofers for deep, powerful bass
Audio path	Dual-core processor with quad-DSP and quad-codec for lossless HD audio, clear dialogue, and more
Voice Assistant	Use the speaker's built-in microphones to control Sonos, voice functions
Bluetooth	The software interface that controls all the core functions of your Sonos system.
Power supply	Sonos 45W USB-C Power Adapter (PS45-US) Sonos 45W USB-C Power Adapter (PS45-EU)
USB-C port	USB-C port for power and connecting to an Ethernet adapter (sold separately) for a wired network connection • Connect one cable with an Ethernet cable and the Ethernet to USB-C adapter (sold separately)
LEDs	Status light Volume LED ring
Buttons (4)	Set up your speaker with the latest generation of the Sonos app Ethernet button
Line-in	Connect a cable to play audio from a turntable, CD player, or other audio source
Audio buffering	Stereo 24-bit PCM, 16-bit Dolby Digital (DD) 5.1 content
DETAILS AND DIMENSIONS	
Dimensions (H x W x D)	7.44 x 6.10 x 5.51 in / 189 x 155 x 140 mm
Weight	3.55 lb / 1.6 kg
Operating temperature	41°F to 95°F / 5°C to 35°C
Storage temperature	-4°F to 140°F / -20°C to 60°C
Humidity resistant	Designed to withstand high humidity. Not designed to be used in a shower, sauna, or in a swimming pool or hot tub.
Product finish	Black and white color finish with soft touch finish
Package contents	Sonos Era 100 SL, Ethernet to USB-C adapter, Power cord
Note: Specifications subject to change without notice.	

Important safety information

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Clean only with dry cloth. Use a dry cloth to clean the exterior of products, as damage from the use of any liquid cleaners.
6. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
7. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
8. Protect the power cord from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
9. Only use attachments/accessories specified by the manufacturer.
10. Unplug this apparatus during lightning storms or when unused for long periods of time.
11. Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
12. Apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the apparatus.
13. **Warning:** To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.
14. The mains plug of the power supply cord shall remain readily operable. To completely disconnect this apparatus from the AC mains, disconnect the power supply cord plug from the AC receptacle.
15. Accessories connected to the device via a network interface must be limited to those that comply with Limited Power Source (LPS) requirements and have suitable power ratings.