Era 100 SL



Model: Era 100 SL

Overview

The compact smart speaker designed for room-filling sound

- Powerful sound with 360° omnidirectional audio
- Tonally balanced, with 75° dispersion and 20Hz–20kHz frequency response
- Voice assistant built-in, with far-field microphones
- Four-color LED ring indicates the speaker's status and volume
- Dual **Sonos** ports make it easy to add more speakers

Control and lights

Volume control

- Volume up: slide right or tap +
- Volume down: slide left or tap –

Play/Pause

- Play music: tap to play
- Pause music: tap while the music is playing

Mute/Voice

- Mute: tap to mute the microphones
- Turn on the voice assistant: tap to activate the voice assistant

Status light

Shows the speaker's connection, volume, and activity. Learn more.

Connector panel



Ethernet button

- Pair a wired Sonos set-up device
- Clear wired set-up

USB-C port

- Add a USB-C accessory: Connect a USB-C accessory, using the Sonos mic-in adapter or a USB-C to USB-A adapter. Learn more about compatible USB-C accessories.
- Update your speaker's software: Connect a USB-C to USB-A cable to a computer with internet access. Learn more.
- Recover: Use the Sonos Recovery Tool to restore your speaker's software. Learn more.
- Limit AC: Activate the Sonos Limit Adapter to reduce the power consumption of your speaker. Learn more.

Select a location

Era 100 SL can be used in any position. For best performance, here's why guidelines:

- Place it where the microphones can hear you clearly. Avoid placing it near the corner of the room, behind furniture, or under a low ceiling.
- Keep it at least 1 inch (2.5 cm) away from walls and 12 inches (30 cm) away from the back of the speaker.
- Don't place it on a soft surface that can block sound, like a blanket, **learn more**.

Trueplay™

Trueplay tuning measures the sound in your room and adjusts the speaker to sound its best in your space. It's available on iOS devices. For the best results, move around the room as the tone plays.

Tuning takes about 1 minute. Trueplay tuning isn't available for stereo pairs, **learn more**.

Bluetooth pairing

Era 100 SL supports Bluetooth 5.0 for the use of its speaker and you can enjoy music from Bluetooth.

- Press and hold the Bluetooth button at the back of the speaker until you hear a tone. Wait for the Bluetooth light to flash white. Pairing mode is active.
- Choose Era 100 SL from the list of available devices in your Bluetooth settings. The Bluetooth light will automatically connect then.

Line-in

Era 100 SL supports line-in connection. To listen to anything with a stereo audio output, you can connect it to your speaker with a 3.5 mm audio cable. Connect the cable to the line-in port on the back of the speaker. Audio from the source will start playing.

Some devices, like turntables, require a preamp to connect to a line-in, **learn more**.

Set up stereo pair

Set the Sonos speakers in the same room as your main listening position. Place them equally distant from the left and right walls, and at least 8 inches (20 cm) apart.

- Open the Sonos app and go to Settings > System > Create Stereo Pair.
- Select **Create**.
- Choose the room you want to set up in.
- Select **Create**.

Set up surrounds

An easy way to add immersive surround sound is to have Sonos set up the room for stereo speakers. Add a Sonos Sub and Sonos One SL or Era 300 speakers as surrounds.

- Place each surround speaker about 3 feet (1 m) to the side of the main listening position.
- Select **Settings** ⚙.
- Select a room to set up the surround sound **Surrounds** and select **Surround Speakers**. Follow the instructions in the app to add the surround speakers.

Learn more

Compatible audio sources

Analog audio, connected to optional line-in port. These settings are adjustable.

Subwoofer	Turn surround sound on or off
Surround	Add surround speakers to your system
Music Level	Adjust surround volume for music
Movie Playback	Adjust Night Listening Mode, Full, or Off. Learn more about Night Listening Mode

Product settings

You can customize these product-level settings:

Name	Edit a speaker's name
Room Name	If two rooms are upstairs in the room, set one room as Upstairs and the other as Upstairs 2
Turn off the microphones	Turn off the microphones to disable the voice assistant. Learn more
Mic	Sonos products have different microphone setups. Learn more about the microphones in your product. Learn more
Trueplay	Tune the speaker to the room. Learn more
Airplay Level	Set the level of Airplay audio for each room. Learn more
Battery Light	Set the battery light to Always On, or to turn it off. Learn more
Touch Controls	Turn the touch controls on or off. Learn more
Satellite Tweak	Set the satellite ON, so you can control speaker volume from the Sonos app. Learn more
About Me	Show a speaker's details, such as its serial number and software version. Learn more

Zones

Sonos Zones are a way to group spaces with sound. Learn more and understand configuration for multiple speakers throughout a home. Learn more. Add a Sonos Amp to a speaker to make a zone. Learn more. Add a Sonos Boost to a wireless network to make a zone. Learn more. Add a Sonos Sub to a speaker to make a zone. Learn more. Add a Sonos Port to a stereo system to make a zone. Learn more. Add a Sonos Move to a speaker to make a zone. Learn more. Add a Sonos Roam to a speaker to make a zone. Learn more. Add a Sonos Arc to a speaker to make a zone. Learn more. Add a Sonos Beam to a speaker to make a zone. Learn more. Add a Sonos Era 300 to a speaker to make a zone. Learn more. Add a Sonos Era 100 to a speaker to make a zone. Learn more. Add a Sonos Era 100 SL to a speaker to make a zone. Learn more. Add a Sonos One to a speaker to make a zone. Learn more. Add a Sonos One SL to a speaker to make a zone. Learn more. Add a Sonos Five to a speaker to make a zone. Learn more. Add a Sonos Play:5 to a speaker to make a zone. Learn more. Add a Sonos Play:3 to a speaker to make a zone. Learn more. Add a Sonos Play:1 to a speaker to make a zone. Learn more. Add a Sonos Sub to a speaker to make a zone. Learn more. Add a Sonos Sub Mini to a speaker to make a zone. Learn more. Add a Sonos Sub Gen 3 to a speaker to make a zone. Learn more. Add a Sonos Sub Gen 4