ENGLISH

User's Guide

048-007-NA
048-007-EU

AFTERGLOW

PRISMATIC CONTROLLER FOR XBOX ONE

QUICK START Connect The Afterglow Prismatic Controller to your Xbox One via the included cable.

Program button	Program status LED color	Function
Press once	Blue	Set color and brightness with the analog sticks. Press program button to set.
Press twice	Green	Map actions to Multi-Function Wheels. (Activate wheel, then button to map.)
Press three times	Yellow	Turn red rumble / impulse LEDs on and off with D-Pad UP (on) or DOWN (off).

1



2

FEATURES

- Signature Prismatic LED lighting
- Dual Multi-Function Wheels allow users to remap up to 6 actions
- Premium ALPS analog sticks
- 3.5 mm audio jack and onboard audio controls
- Dual rumble motors and impulse triggers
- 10 ft (3 m) USB cable included
- Compatible with the Afterglow Configuration App for Xbox One

CONTENTS

1 Afterglow Prismatic Controller for Xbox One
1 10 ft (3 m) USB cable
1 Manual

CONNECTING THE AFTERGLOW PRISMATIC CONTROLLER



1. Plug the small (micro) USB end of the cable into the top of the controller.



2. Connect the large (standard) USB end of the cable into the Xbox One via any available USB port.



3. The white status LED above the Xbox button will illuminate, indicating that you are ready to play.

3

AUDIO SETTINGS



Increase and decrease volume by holding the audio function button and pressing the D-Pad UP or DOWN.



Adjust the game/chat audio balance by holding the audio button and pressing the D-Pad LEFT or RIGHT.



Mute and unmute your microphone by quickly pressing twice on the audio function button. The program status LED will turn RED when muted.

PRISMATIC LIGHT PIPE SETTINGS




1. Press the program button on the back of the controller once.



2. The program status LED will turn BLUE.


4



3. Use the LEFT analog stick to control the brightness and the RIGHT analog stick to control the hue of the lighting effects.



4. Before releasing the analog sticks, press the program button to lock in the lighting settings.



5

PROGRAMMING THE MULTI-FUNCTION WHEELS



1. Press the program button on the back of the controller twice.



2. The program status LED will turn GREEN.



3. Activate the Multi-Function Wheel in the direction you would like to map the action to.



4. The program status LED will begin flashing.



5. Press the action button, stick, bumper, or D-Pad direction you would like mapped to the Multi-Function Wheel.

6



6. The program status LED will turn off, indicating that the Multi-Function Wheel will now activate the mapped function.



7. Repeat steps 1 through 6 for all the buttons you want to map, or you can remap a different command to those that are already mapped.

RUMBLE / IMPULSE LED SETTING



1. Press the program button on the back of the controller three times.



2. The program status LED will turn yellow.



3. Press the D-Pad UP to set the rumble / impulse LEDs to ON, or press the D-Pad DOWN to set the LEDs to OFF.

7

MAINTAINING THE CONTROLLER

Minimal maintenance is required. It is advised to clean the controller with a microfiber cloth every other month.

TROUBLESHOOTING

If the controller is not turning on or the white status LED is not lighting up, try the following solutions:

- Check that the Xbox One is turned on and running properly.
- Ensure the cable is completely plugged in to both the console and the controller.
- Unplug the USB cable from the controller and plug it back in.
- If you experience any problems with the analog sticks or triggers, your controller may need to be recalibrated. Contact PDP Customer Support for recalibration instructions.
- If any further issues arise, please contact **PDP Customer Service** at **support.pdp.com** or **1(800) 331-3844** (USA and Canada only).

8

Downloaded from www.Manualslib.com manuals search engine