BUSH

Instruction manual

WDSAEINT86



You'll soon be enjoying your new washer-dryer.

It all begins here, with your instructions. Don't worry, there's nothing too technical coming up. Just simple, step-by-step guidance to get you up and running quickly. Sound good? Then let's get started.

Help and Guidance

We're here to help you get the most from your washer-dryer. Should you require any guidance, a simple solution can often be found online at:

www.bush-support.com

If you still require further assistance, call one of our experts on **0345 257 7271**.

* you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting** section of these instructions.

Issue 4 12/2020

Contents

1 Safety information

Safety information 6

2 Getting to know your washer-dryer

Ready? Let's begin 10

Accessories 12

3 Installing your washer-dryer

Installation requirements 14

Unpacking 14

Connections (electrical, water, gas) 19

4 Functions

Functions 22

5 Using your washer-drier

First use of washer-dryer 28

Standard and advanced functions/use 29

6 Care and Maintenance

Cleaning 34

Maintenance actions 34

Technical specifications 36

7 Product support

Troubleshooting 38

Help and assistance 39

Declaration of conformance to product standards 40

Disposal 41

or online at www.bush-support.com If you still require further assistance, call one of our experts on 0345 257 7271.

Safety information

1

Safety information

Important - Please read these instructions fully before installing or operating

- If the supply cord is damaged,it must be replaced by the manufacturer,its service agent or similarly qualified persons in order to avoid a hazard.
- The new hose-sets supplied with the appliance are to be used and that old hose-sets should not be reused.
- This washer-dryer is for indoor use only.
- The openings must not be obstructed by a carpet.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical,sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safeway and understand the hazards involved.
  Cleaning and maintenance shall not be made by children without supervision.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Pull out its plug from the power socket before cleaning or maintenance.
- Make sure that all pockets are emptied.
- Sharp and rigid items such as coin, brooch,nail,screw or stone etc.may cause serious damages to this machine.
- Pull out its plug and cut off water supply after the operation.
- Please check whether the water inside the drum has been drained before opening its door.Please do not open the door if there is any water visible.
- Pets and children may climb into the machine. Check the machine before every operation.
- Glass door may be very hot during the operation.Keep children and pets far away from the machine during the operation.
- Take care that power voltage and frequency shall be identical to those of washer-dryer.
- Do not use any socket with rated current less than that of washer-dryer. Never pull out power plug with wet hand.
- To ensure your safety,power cord plug must be inserted into an earthed three-pole socket.Check carefully and make sure that your socket is properly and reliably earthed.

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting** section of these instructions.

Safety information

Important - Please read these instructions fully before installing or operating

- Children of less than 3 years should be kept away unless continously supervised.
- Do not let kids play with the the machine.
- Packing materials may be dangerous to the children . Please keep all packing materials (plastic bags,foams etc) far away from the children.
- Washer-dryer shall not be installed in bath room or very wet rooms as well as in the rooms with explosive or caustic gases.
- Make sure that the water and electrical devices must be connected by a qualified technician in accordance with the manufacturer's instructions and local safety regulations.
- Before operating this machine,all packages and transport bolts must be removed.Otherwise,the washer-dryer may be seriously damaged while washing the clothes.
- Before washing the clothes at first time, the washer-dryer shall be operated in one round of the whole procedures without the clothes inside.
- The washer-dryer with single inlet valve only can be connected to the cold water supply. The washer-dryer with double inlet valves can be connected to the hot water and cold water supply.
- Your washer-dryer is only for home use and is only designed for the textiles suitable for machine washing.
- Flammable and explosive or toxic solvents are forbidden.Gasoline and alcohol etc.Shall not be used as detergents.Please only select the detergents suitable for washer-dryer, especially for drum.
- Be careful of burning when washer-dryer drains hot washing water.Never refill the water by hand during washing.
- After the program is completed, Please wait for two minutes to open the door.
- Please remember to disconnect water and power supply immediately after the clothes are washed.
- Do not climb up and sit on top cover of the machine.
  Do not lean against machine door.
- Please do not close the door with excessive forces.If it is found difficult to close the door,please check if the excessive clothes are put in or distributed well.
- The household washer-dryer isn't intended to be built-in.
- Cautions during Handling Machine
  1.Transport bolts shall be reinstalled to the machine by a specialized person.
  2.The accumulated water shall be drained out of the machine.
  3. Handle the machine carefully.
- Never hold each protruded part on the machine while lifting. Machine door can not be used as the handle during the conveyance.

or online at **www.bush-support.com**. If you still require further assistance, call one of our experts on **0345 257 7271**.

Safety information

Important - Please read these instructions fully before installing or operating

Cord entanglement hazard. The cable of the appliance can give rise to risks of entanglement, strangulation or tripping if not correctly placed. You must make sure that the electric cable is positioned safely.

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting** section of these instructions,

Getting to know your washer-dryer

2



Getting to know your washer-dryer

You'll be up and running in no time

Ready? Let's begin...


Please read these instructions carefully. They contain important information which will help you get the best from your washer-dryer and ensure safe and correct installation and operation.
If you require any further assistance, our technical experts are happy to help. For full details, refer to the product support section at the end of these instructions.


If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting** section of these instructions.

Getting to know your washer-dryer

You'll be up and running in no time

Component





1.Detergent Drawer

2.Door

3.Filter

4.Control Panel

5.Power lead

6.Drain hose

7.Transport bolt x 4

8.Water inlet

Getting to know your washer-dryer


You'll be up and running in no time

Model	capacity	Spin Speed	Energy class
WDSAEINT86	8kg	1400rpm	B

Accessories

This machine includes below accessories,please install these parts by yourself before operating.


- plastic hole plug x 4
- Inlet hose
- Self-tapping screws(ST4*12) x 8
- Self-tapping screws(M5*12) x 6
- Hinges
- Counter magnet
- Spacer
- Fixed position paper



Tools

You may use this tools to help install above parts

- glove
- spanner
- Automatic Driver
- Ruler
- glove
- Pencil



Installing your washer-dryer

3

Bringing it all together

Installation requirements

- In addition to the instructions mentioned here, special regulations of the relevant water and companies may apply. If in doubt, have the washer-drier connected by a qualified technician.
- The washer-dryer is heavy - caution when lifting it.
- Do not lift by projecting components (e.g. washer-dryer door).
- Warning: Frozen hoses may tear/burst. Do not install washer-dryer in outdoor areas or where there is a risk of frost.Please operate washer-dryer above 0°C.
- Lay hoses and cables in such a way that there is no risk of tripping over them.

⚠ An additional space (approximately 120mm) is required at the rear of the washer-dryer. This is to allow enough space for the water hose and drain hose connections.

- Dimension of the machine with door open.

Unpacking

Unpacking your washing machine

Caution:2 people are required to unpack the washing machine,it is recommended that gloves are worn.

Carefully remove all packing materials including the foam base, dispose of correctly.

Note:When opened,water droplets may be visible in the drum etc. this is normal as each appliance is tested before delivery.

Removing the transport bolts

Important:The transport bolts are designed to support the internal components during transit these MUST be removed before use.

1:Loosen the screws by rotating counterclockwise with a suiltable wrench,(Fig 1 2)

2:Remove the bolts by pulling them.(Fig 3)

3:When the transport bolts have been removed, insert the plastic transport screw taps found in the accessories bag into the holes.(Fig 4)




Fig1




Fig2





Fig3


Fig4

Levelling feet

1:For your machine to work efficiently with minimum vibration it should be settled on flat, nonslippery,firm ground.


2:You can adjust the balance of your machine by changing the positioning of its feet.

3:First,loosen the plastic adjustment nut.(Fig 5)

4:Adjust by rotating the feet upwards or downwards.(Fig 6)

5:After the desired position has been reached, tighten the plastic adjustment nut again by rotating it upwards.

Note:Never put cartons,wooden blocks or similar materials under the machine to balance irregularities in the level of the ground.


Fig5




Fig6

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting** section of these instructions.

Installing your washer-dryer

Bringing it all together

Please carefully read the below installation instruction.
Preparations should be made before moving the washing machine to installation place.

Illsutration of cabinet dimensions and installation position of the washing machine.
(Fig 7-1,2)




Fig7-1





Fig7-2


⚠WARNING

When installing the appliance into the kitchen ensure furniture ,if possible, the hoses are placed in either of the two recesses on the back of the appliance. This will help to prevent the hoses from becoming kinked or trapped.
Preparation and assembly of the door
The appliance can be arranged for the assembly of a door opening from right to left (Fig 8)or from left to right(Fig 9).



The door is open from right to left

Fig8



The door is open from left to right

Fig9

Installing your washer-dryer

Bringing it all together

Preparation the Fixed position paper(Fig 10)

1. Make the mark on the door according to the carbinet and washing machine height.





Fig10

2.Fixed position paper on the door.(Fig 11)



Shear fixed position paper

Paste on the Door(The door open from right to left)

Paste on the Door(The door open from left to right)

Fig11

Bringing it all together

3.Drill hole on the door(Fig 12)
Drill the hole on the door according to the fixed position paper.




Fig12

4.Installation the hinges and spacer(Fig 13)
Fix the hinges to the machine by means of the ST4*12 screws included.




Fig13

5.Installation the counter magnet(Fig 14 & Fig 15)
The appliance is prearranged for a magnetic closure of the door. To enable a correct operation of this device, it is necessary to screw the counter-magnet into the inner side of the door with M5*12 screws.




Fig14

Bringing it all together




Fig15

6.Installation the door(Fig 16 & Fig 17)
Fix the cabinet with M5*12 screws.




Fig16




Fig17

If you have any doubt on the installation, please consult the qualified person.

Bringing it all together

Connections

Water inlet hose connections

Important:This washer-dryer MUST only be connected to a cold water supply.

1:Connect the water inlet hose,the angled connection attaches to the water inlet on the back of the washer-dryer.(Fig 7)




Fig18

2:The straight connection attaches to the water supply valve.(Fig 8)




Fig19

3:Ensure all seals are in place before connecting.

Important:Only tighten the hose connection nut by hand - do not overtighten.

Drain hose connections

Important:The height of the top of the curve in the drain hose MUST be between 60 - 100cm from the floor.(Fig 9)




Fig20

Important: Drain hose can be fitted to the drainer or a wash basin.

Electrical

Any electrical work that is required to install this appliance MUST be carried out by a qualified electrician.

Warning:THIS APPLIANCE MUST BE EARTHED

Before making any electrical connections, ensure that:

- Electrical safety is only guaranteed when the earth system of your house is in accordance with the related local regulations.
- Do not bend, stretch or pull the supply cable to avoid electric shock.
- Ensure the power socket is suiable for the maximum power of the machine (fuses in the power circuit must be 13 amp).
- The supply voltage should be the same as that indicated in the technical specifications and the applicance rating plate.
- The appliance should be earthed and in complicance with the applicable law.
- When installed,the power socket must be within easy reach.
- If the socket outlets in your home are not suitable for the plug supplied with this unit check with a qualified electrician for replacement.
- To avoid the risk of overloading your plug socket, the use of adapters, multiple connectors or extension cables are not recommended.
- The applicance must be connected to a 220-240 volt 50Hz AC supply by means of a three pin socket, suitably earthed and protected by a 13 amp fuse.
- Should the fuse need to be replaced , a 13 amp fuse approved to BS 1362/A must be used.
- The plug contains a removable fuse cover that must be refitted when the fuse is replaced. if the fuse cover is lost or damaged, the plug must not be used until a replacement cover has been fitted or the plug is replaced.
- A damaged plug should be cut off as close to the plug body as possible , the fuse should be removed and the plug disposed of safely.

Installing your washer-dryer

Bringing it all together

Plug replacement (UK & Ireland only)

Should you need to replace the plug;the wires in the power cable are coloured in the following way:

Blue - Neutral ' N'

Brown - Live ' L'

Green & Yellow - Earth 'E'

As the colour of the wires in the power cable may not correspond with the coloured markings identifying the terminals in your plug,and proceed as follows(Fig10):

The green & yellow wire must be connected to the terminal in the plug that is marked with the letter E or by the earth symbol.

The blue wire must be connected to the terminal that is marked with the letter N.

The brown wire must be connected to the terminal that is marked with the letter L.

If power supply cord is damaged , it must replaced by the manufacturer or its service agent or a similar qualified person in order to avoid a hazard.




Fig21


If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting** section of these instructions

Functions 4

Functions


Simple everyday use

Introduction of control panel



Program selection knob

For you to select different washing program.



If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting** section of these instructions.

Functions

Simple everyday use

Introduction of control panel

Turning the machine on
Plug in your machine. Place the laundry in the machine and add detergent and softener. Press the "on/off" button.

program selection
First, switch the program knob to select suitable program according to the types of textiles.
Second, select a proper temperature by following the care instructions on the clothes.
Last, select the proper spin speed.
Generally, the higher temperature will consume more energy; the higher spin speed will cause more noise.

PLEASE NOTE: to protect the delicate clothes, the lower spin speed shall be selected.

The main washing procedures depend on the types of the clothes to be washed as follows:

Main program
Depending on the type of textile, the following main programs are avaiblable: Each of these main programs comprise of a complete washing process, including washing, rinsing and, if required, spin cycles.

- **Cotton**
Hard-wearing textiles, heat-resistant textiles made of cotton or linen.
- **Baby Care**
Washing the baby's clothes, it can make the baby's wear cleaner. and make the rinse performance better to protect the baby skin.
- **Jeans**
Specially for jeans.
- **Mix**
Mixed load consisting of textiles made of cotton and synthetics.
- **Sport Wear**
Washing the activewear.
- **Quick**
Extra short programme approx, suitable for lightly soiled washing as a small amounts of laundry.
- **Wool**
Hand or machine-washable wool or richwool textiles. Especially gentle wash programme to prevent shrinkage, longer programme pauses (textiles rest in wash liquor).
- **Spin Only**
Extra spin with selectable spin speed.
- **Rinse&Spin**
Extra rinse with spin.
- **Dry Only**
Select it to dry clothes, the temperature is different .The drying time according to the load.
- **1Hour W/D**
For small synthetic clothes or shirts, load limitation is 1 kg (about 4 shirts). When you have an urgent appointment but no more clean shirt left in your cupboard, this program will help you.Time duration is only 1 hour including wash and dry.
Remark: Big towels or jeans is not suitable for this program, they will enlarge the time duration and affect the moisture content.
- **ECO 40-60**
Washing brightly colored clothes, it can protect the colors better. Default 40°C,not selectable, suitabale for laundry washing at about 40°C-60°C.
- **Intensive**
To increase the washing effects, washing time is increased.
- **20°C**
20°C default, can choose cold water.
- **Wash and Dry**
The standard energy program.

Functions

Simple everyday use

Introduction of control panel

- **Delay**
Set the Delay function:
1. Select a programme
2.Press the Delay button to choose the time(the delaying time is 0-24 H.)
3.Press [Start/Pause] to commence the delay operation
On/Off--Choose the Programme--Setting time--Start
Cancel the Delay function:
Press the [Delay] button until the display be 0H.It should be pressed before starting the programme. If the programme already started, should press the[On/Off] button to reset the programme.
If there is any break in the power supply while the machine is operating, a special memory stores the selected programme and when the power is restarted, press the [On/Off]button the program will continues.
- **My Cycle**
Memory the frequently used programmes
Press [♡]3sec. to memory the running programme. The default is cotton.
- **Child Lock**
To avoid mis operation by children.
On/Off--Start/Pause--Press [Temp.] and [Speed]3 sec. till buzzer beep.
Press the two button 3sec. also to be released the function.
The "Child Lock" will lock all buttons except [On/Off].
Cut off the power supply , the kid's protection is to be released.
The child lock will remain effective when the power is resumed for some models.
- **Speed**
Press the button to change the spin speed.
- **Temp.**
Press the button to regulate the temperature.
- **Mute the buzzer**
On/Off--Start/Pause--Press the [Temp.] button for 3sec.the buzzer is mute.
To act the buzzer function, press the button again for 3 seconds. The setting will be kept until the next reset.
- **Dry Level**
Press the Dry Level button continuously to choose the dry level: Extra Dry/Normal Dry/ Gentle Dry.
  - ☼ Extra Dry:Need to wear clothes immediately , we can choose this function
  - ☼ Normal Dry:The normal dry procedure
  - ☼ Gentle Dry:Only to dry slightly and then is just ok .

Functions

Simple everyday use

Program Selection Guide - 8kg washer-dryer

Procedure / Description	Washing/Drying Max. Load(kg)	Detergent Box			Delay	Max.Water Temp.(℃)	Washing Time(min)	Max.Speed(RPM)
		Case I	Case II	Softener Case				
ECO 40-60	8.0	×	●	○	○	–	3:35	1400
Sportwear	4.0	×	●	○	○	40	1:11	800
Quick	2.0	×	●	○	○	Cold	0:15	800
20°C	4.0	×	●	○	○	20	1:01	1000
Wool	2.0	×	●	○	○	40	1:07	600
Wash and Dry	8.0/6.0	×	●	○	○	–	5:00	1400
Jeans	8.0	×	●	○	○	60	1:45	1000
Spin Only	8.0	×	×	×	○	–	0:12	1000
Rinse&Spin	8.0	×	×	○	○	–	0:20	1000
Dry Only	—/6.0	×	×	×	○	–	4:14	1400
Mix	8.0/6.0	×	●	○	○	40	1:20	800
Baby Care	8.0	×	●	○	○	60	1:43	800
Intensive	8.0/4.0	×	●	○	○	40	3:48	800
Cotton	8.0/6.0	×	●	○	○	40	3:49	1400
1 Hour W/D	1.0/1.0	×	●	○	○	–	0:58	–

● Means must ○ Means optional × Means not necessary

Attention! Ensure the loading for both washing / drying should be within the max loading in the above table before start the machine. Overload may get poor result on washing / drying.

Note : Water and power consumption and programme duration may differ from the table shown, subject to changes in water pressure, water hardness and temperature, ambient temperature, type and amount of laundry, selection of auxiliary functions, and fluctuations in the supply voltage.

Functions

Simple everyday use

Concerning to EN 60456:2016/prA2019 With (EU)2019/2014, (EU)2019/2023,
The EU Wash energy efficiency class is B, Energy test program: ECO 40-60;
The EU Wash and dry energy efficiency class is E,Energy test program: Wash and Dry;
Extra Dry. Other as the default.
Half load for 8.0Kg machine:4.0Kg.
Quarter load for 8.0Kg machine:2.0Kg.

Using your washer-dryer


5

Using your washer-dryer

Getting the most from your appliance

Organising Laundry

- Read the washing label on each garment to help you sort your washing into different loads.
- Sort the laundry by colour, type of fabric and by how soiled it is. This will help you choose the correct programme and temperature for each wash.




- Do not exceed the maximum load! See the programme selection table for the maximum load for the programme you require.

Articles / clothes	Approx. weight(g)
Cotton quilt covers (single/double)	900/1500
Bed sheets (single/double)	600/900
Work clothes	1120
Large tablecloths	700
Small tablecloths	350
Tea napkins	100
Bath towels	700
Hand towels	300
Blouses	150
Cotton shirts	300
shirts	180
cotton dresses	500
Jeans	800
Jacket	800
Handkerchiefs	100
T-shirts	150
Shorts	70
Socks	50

Preparing Laundry

- Treat stains before washing.
- Some items should be put into a cleaning net before going into the washer-dryer. i.e. bras with metal wires, tights and lace clothing to prevent damage.
- Check that pockets do not contain any objects which may damage your clothes and the washer-dryer.
- Tie up any loose strings on laundry, close zippers and reverse clothing with zips inside out.
- To prevent any large, heavy objects (e.g., buckles, large buttons, etc.) from hitting the glass door, turn your clothing inside out, or remove the heavy objects. These could damage your laundry or the washer-dryer.
- Remove any surplus hair, animal fur, sand, and other materials with a brush before washing.
- If clothes have raised fabric turn them inside out.
- Clothes that are not colour fast should be washed separately.
- Insert your clothes into the washer-dryer.
- Close the washer-dryer door. Ensure that you do not trap any items of clothing between the loading door and the rubber seal.




If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting** section of these instructions.

Getting the most from your appliance

Adding Detergent and Softener

- Add detergent into the appropriate dispenser.
- Apply softener before you start washing.
- Apply detergent and softener according to the washing amount, the soiling level, the water hardness in your area and the manufacturer's instructions of these products.

⚠ Dilute viscous fabric softener and fabric conditioner with water. Prevent blockage of the overflow. Maximum level is 40ml.



- Do not use the washer-dryer when the detergent drawer is removed. It may cause a water leak or it may not work normally.
- If you forget to add detergent, you can drain the washer-dryer by running a drain only programme. Then you can add detergent and start the programme again.
- Detergent only reaches the drum when water flushes through the detergent drawer.
- To prevent powder detergent staying in the drawer, dry the inside of the drawer with a cloth.Make sure the powder isn't lumpy when you add it into the drawer.
- If the rinse cycle isn't removing all the detergent from your wash, use less detergent .
- Softener should not exceed the MAX level in the compartment.
  Wash out unused softener with a splash of water or a damp cloth after the programme has finished.


Before First Use

- Prior to the first use of the appliance, it is recommended to run a wash programme without clothes. A small amount of washing detergent should be used.

Wash Setting

Standard Washing

1. Pull the door handle and put the laundry in the drum. (Refer to Preparation to sort your laundry before it goes into the drum.) Make sure no washing gets caught in the door.
2. Close the door and press the On/Off button.
3. Turn the Programme selection dial to select your wash programme.
4. Select the temperature if desired.
5. Add detergent into the detergent drawer. The quantity of detergent will depend on the amount of laundry, the degree of soiling and the water hardness. Use the amount of detergent suggested on the packaging.
6. Press the Start/Pause button to start the washing.
7. The washer-dryer will sound when the programme is complete.



⚠ If the door is locked and you switched the washer-dryer off and then on - or if there's a power cut - it will stay locked for 1 minute.

Getting the most from your appliance

Removing Washing (Once programme is fnished)

⚠ Door remains locked for 1 minute after wash stopped.

- Open the washing machine door and remove your washing.
- Remove any foreign objects to avoid risk of rusting.
- Leave the door and detergent drawer open so that residual water can evaporate.

1.Changing the selection after the program started?

If you need to change a setting after the wash has started, press on/off, then on/off again, Re-select the program, spin speed and optional functions, and then press the Start / Pause button. (Ensure the Child Lock is off, otherwise the original program will continue.)

2.Door lock

The icon lock will light up automatically once the program start. The door lock icon will fade out as soon as the program end and the door will be allowed to open automatically.

3.Bubble Removal Function

Bubble Check Function: Redundant bubbles will occur when there is excessive detergent, which will affect wash and rinse effects. The procedure will check automatically and one bubble removal procedure will be added automatically to remove bubbles when excessive bubbles are checked.


4.End of program

It will sound for 5 seconds afterthe end of program and the display will indicate "end" icon.

Using your washer-dryer

Getting the most from your appliance

Quick start



After washing :

1. The washer-dryer will sound several times for 5 seconds.
2. It is recommend to close the water tap and pull out the power plug.
3. The machine will empty most of the condensed water from the dryer along with the washer waste water. Only very little water will be remain inside the drum / cavity. The customer can open the door for one or two hours to dry up the remaining water. It is not necessary to remove the water manually.

Care and maintenance 6

Care and maintenance

Looking after your appliance

Before your maintenance starts, please do pull out the power plug or disconnect power and close the tap.

⚠

- Do not use solvents clean to avoid that the washer-dryer, it will damage, and toxic gases are generated or exploded.
- Do not use the detergents containing PCMX to clean the washer-dryer.

Cleaning and Maintenance of Washer-dryer Cabinet

- Proper maintenance on the washer-dryer can extend its working life. The surface can be cleaned with diluted nonabrasive neutral detergents when necessary. If there is any water overflow, use the wet cloth to wipe it off immediately.
- No sharp items are allowed to strike the cabinet.

Notes: Do not use formic acid and its diluted solvents or equivalent .

Clean Internal Drum

- The rusts left inside the drum by the metal articles shall be removed immediately with chlorine-free detergents.
- Never use steel wool.

Defrost a Frozen Washer-dryer

When the temperature drops below zero and your washer-dryer gets frozen, you may:
1.Disconnect the power supply for the washer-dryer.
2.Wash the tap with warm water to loosen inlet pipe.
3.Take down inlet pipe and immerse it in warm water.
4.Pour warm water into washing drum and wait for 10 minutes.
5.Reconnect inlet pipe to the tap and check whether inlet and outlet are working normally.
Notes: when the washer-dryer is reused, make sure the ambient temperature is above 0˚C

Anti-freeze

If your washer-dryer is located in the room where it can get frozen easily, please drain the remaining water inside drain pipe and inlet pipe thoroughly.

Remove the remaining water in inlet pipe:
1.Close the tap.
2.Screw off the inlet pipe from tap and put its end into the container.
3.Start up any procedure except single Wash or Drain procedure. Water will be drained out of inlet pipe if any for about 40 seconds.
4.Reconnect the inlet pipe to tap.
Remove the remaining water in drain pump(Fig11).




Fig 11

Clean detergent drawer and grooves

1.Press down the arrow location on softener cover inside the drawer.
2.Lift the clip up and take out softener cover and wash all grooves with water.
3.Restore the softener cover and push the drawer into position.




Fig 12

Clean inlet filter

Inlet filter shall must be cleaned if there is not any or insufficient water in when the tap is opened.
Clean the tap filter:
1.Close the tap.
2.Select any procedure except "Wash" or "Drain" procedure.
3.Press the button "Start/Pause" and keep the procedure running for about 40 seconds.
4.Remove the inlet pipe from the tap.
5.Use water to wash the filter.
6.Reconnect the inlet pipe.




Fig 13




Fig 14

Washing the filter in washing machine:
1.Screw off the inlet pipe from the backside of the machine.
2.Pull out the filter with long nose pliers and reinstall it back after being washed.
3.Reconnect the inlet pipe.
4.Open the tap and make sure there is no water leakage.
5.Close the tap.






Fig 15

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting** section of these instructions.

Notes: Generally, the tap filter is washed first and then the filter in washer-dryer will be washed.
If only the filter in washer-dryer is washed, then the steps 1~3 in cleaning the tap filter shall be repeated (Fig16,17) .


Fig 16


Fig 17

⚠


Pull out the power plug to avoid electrical shock before washing.
After using the washer-dryer, remove all the clothes and close the door tightly.

Remove foreign matters
Drain Pump Filter:
Drain pump filter can filter the yarns and small foreign matters from the washings.
Clean the filter periodically to ensure the normal operation of washer-dryer.


According to the soil level within the cycles and the frequency of the cycles, you have to inspect and clean the filter regularly.
The pump should be inspected if the machine does not empty and/or spin;The machine makes an unusual noise during draining due to objects such as safety pins, coins etc. blocking the pump.

Clean the pump filter :


1.After the power is disconnected, use hand to open the filter cover(Fig18).


Fig 18

2.Turn the filter down as shown with the figure and take out sundries matters (Fig19) .


Fig 19

3.Reinstall each part back after sundries matters are removed (Fig20) .


Fig 20

Warning!
When the appliance is in use and depending on the programme selected there can be hot water in the pump. Never remove the filter during a wash cycle, always wait until the appliance has finished the cycle, and is empty. When replacing the filter, ensure it Is securely retight end so.

Technical specifcation

Model identifier: WDSAEINT86

General product parameters:

Parameter	Value		Parameter	Value	
Rated capacity (kg)	Rated capacity (b)	6.0	Dimensions in cm	Height	83
	Rated washing capacity (d)	8.0		Width	60
				Depth	54
Energy Efficiency Index	EEI_W (a)	60.0	Energy efficiency class	EEI_W (a)	B
	EEI_{WD} (b)	78.4		EEI_{WD} (b)	E
Washing efficiency index	I_W (a)	1.04	Rinsing effectiveness (g/kg dry textile)	I_R (a)	5.0
	J_W (b)	1.04		J_R (b)	5.0
Energy consumption in kWh per kg per cycle, for the washing cycle of the household washer-dryer, using the eco 40-60 programme at a combination of full and partial loads. Actual energy consumption will depend on how the appliance is used	0.545		Energy consumption in kWh per kg per cycle, for the wash and dry cycle of the household washer-dryer at a combination of full and half loads. Actual energy consumption will depend on how the appliance is used	3.600	
Water consumption in litre per cycle, for the eco 40-60 programme at a combination of full and partial loads. Actual water consumption will depend on how the appliance is used and on the hardness of the water	48		Water consumption in litre per cycle, for the wash and dry cycle of the household washer-dryer at a combination of full and half loads. Actual water consumption will depend on how the appliance is used and on the hardness of the water	90	
Maximum temperature inside the treated textile (°C) (a)	Rated washing capacity	38	Remaining moisture content (d) (%)	Rated capacity	53
	Half	38		Half	53
	Quarter	21		Quarter	53
Spin speed (rpm) (a)	Rated washing capacity	1400	Spin-drying efficiency class (a)	B	
	Half	1400			
	Quarter	1400			
Eco 40-60 programme duration (h:min)	Rated washing capacity	3:38	wash and dry cycle duration (h:min)	Rated capacity	9:30
	Half	2:48		Half	6:40
	Quarter	2:48			
Airborne acoustical noise emissions during the spinning phase for the eco 40-60 washing cycle at rated washing capacity	76		Airborne acoustical noise emission class for the spinning phase for the eco 40-60 programme at rated washing	B	
Type	[built-in/free-standing]		built-in		
Off-mode (W)	0.50		Standby mode (W)	1.00	
Delay start (W) (if applicable)	4.00		Networked standby (W) (if applicable)	N/A	
Minimum duration of guarantee offered by the supplier (c): 12					
This product has been designed to release silver ions during the washing cycle	NO				

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting** section of these instructions,

Product support

7



Product support

Help is always at hand

Troubleshooting

1. Washer-dryer does not operate ?
You can check if the door is closed tightly, power plug is inserted well and then press start/pause button.

2. Washer-dryer does not receive water ?
You can check if the water tap is opened and clean the filters of water inlet hose.

3. Washer-dryer is not draining water ?
You can check the drain hose and clean pump filter.

4. Washer-dryer is vibrating ?
You can check if the feet are adjusted well and make sure transportation screws are removed.

5. The washing result is poor ?
You can select suitable program and use more detergent.

6. No water is seen in the drum during washing ?
It is not a failure. The water is in the lower part of the drum.

7. There are residues of detergent on the clothes ?
Some detergents contain ingredients which are not soluble in water and which may form white stains on your clothes. Please adjust your machine, carry out an additional rinse, or eliminate the stains after drying, with a brush.

8. There are grey stains on the clothes ?
These stains may be caused by oil, cream or ointment. In the next washing operation, use the maximum detergent amount declared by the detergent producer.

*If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting** section of these instructions.

Product support

Help is always at hand

Help and assistance

If you require any technical guidance or find that your washer-dryer is not operating as intended, a simple solution can often be found in the **Troubleshooting** section of these instructions or online at

www.bush-support.com

If you still require further assistance, call one of our experts on **0345 257 7271*** To help give us give you a fast and efficient service please have the following information ready:

Model Ref.		You can find these on the rating plate - a small information panel (usually a sticker or metal plate) on the rear of your appliance
Serial number		
Date of purchase		This will be shown on your receipt

Local call rates applies*

Lines open 8am-7pm Monday to Saturday and 10am-4pm Sunday.

*Calls to Argos enquiry lines may attract a charge and set up fee from residential lines depending on your call plan/tarif. Mobile and other providers costs may vary, see www.bt.com/pricing for details.

For Security and training purposes, telephone calls to and from customer service centres maybe recorded and monitored. Calls from Republic of Ireland will attract international call charges.

or online at **www.bush-support.com** If you still require further assistance, call one of our experts on **0345 257 7271**.

Product support

Help is always at hand

This appliance complies with the following EEC directives:
2014/35/EU low voltage directive
2014/30/EU EMC directive

Notes on disposal:



This marking indicates that this product should not be disposed with other household wastes throughout the UK. To prevent possible harm to the environment or human health from uncontrolled waste disposal,recycle it responsibly to promote the sustainable reuse of material resources.To return your used device,please use the collection systems or contact the retailer where the product was purchased. They return and can take this product for environmental safe recycling.

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting** section of these instructions.

Product support

Help is always at hand

BUSH

Call us now and activate your 12 month guarantee

Thank you for choosing Bush. Your new product is guaranteed against faults and breakdowns for 12 months. Don't forget to register it with us today so we can provide you with our best possible after-sales service and useful updates.

www.bushregistration.co.uk

FREEPHONE*

0800 597 8548

Lines are open 8am - 8pm, 365 days a year. *Calls may be recorded and monitored.

Your Bush Guarantee

This product is guaranteed for twelve months from the date of original purchase. Any defect that arises due to faulty materials or workmanship will be repaired free of charge (or if applicable the product will be replaced or the purchase price refunded) where possible during this period by the dealer from who your purchased the unit.

The guarantee is subject to the following provisions:

- The guarantee does not cover accidental damage, misuse, cabinet parts, knobs or consumable items.
- The product must be correctly installed and operated in accordance with the instructions contained in the manual.
- It must be used solely for domestic purposes. The guarantee will be rendered invalid if the product is re-sold or has been damaged by inexpert repair.
- Specifications are subject to change without notice.
- Bush disclaim any liability for loss or damage arising from the breakdown of the product.
- This guarantee is in addition to and does not diminish your statutory or legal rights.

Important Data Protection Information

If you provide us with information about another person, you confirm that they have appointed you to act for them, to consent to the processing of their personal data including sensitive personal data and that you have informed them of our identity and the purposes (as set out in the Important Data Privacy notice displayed overleaf) for which their personal data will be processed.

You are entitled to ask for a copy of the information we hold about you (for which we may charge a small fee) and to have any inaccuracies in your information corrected.

For quality control and training purposes, we may monitor or record your communications with us.

If your personal details change, if you change your mind about any of your marketing preferences or if you have any queries about how we use your information, please let us know by contacting our Data Protection Officer, Domestic & General, Leicester House 17 Leicester Street, Bedworth, Warwickshire CV12 8JP.

Guarantor: Argos Limited - 489 - 499 Avebury Blvd. - Milton Keynes - MK9 2NW

or online at www.bush-support.com If you still require further assistance, call one of our experts on 0345 257 7271.

BUSH

Contact:

www.bush-support.com

Helpline: 0345 257 7271