Five

Overview



The high-fidelity speaker for superior sound—

- Versatile design with smart orientation sensing. For two speakers, [Trueplay tuning](#) delivers the optimal sound for left and right channels. For impressive stereo sound, When paired vertically, each one-fifty adjusts its tone for more detailed stereo separation and an even wider soundstage.
- Touch controls on the speaker let you adjust volume, play and pause, or skip through songs.
- Use the [Aux](#) port to connect your turntable or another device—simple control with the Sonos app or Apple AirPlay 2.
- Pair two Five in the left and [stereo mount](#) or use them as two [surrounds](#) for your home theater.
- Control your Sonos system with the [Sonos app](#) for Android and iOS.
- See [Setup](#) when you're ready to add Five to your Sonos system.

Controls and lights

Button	Control	Description
	**Volume control**	• Volume up (right) • Volume down (left) Press and hold to quickly change the volume. **Note:** You can also use the Sonos app to adjust volume.
	**Play/Pause**	• Press once to play or pause audio. • Press and hold to add the audio that's playing in another room.
	**Mesh/Previous song**	• Swipe right to skip to the next song. • Swipe left to go to the previous song. **Note:** You can't skip forward or go back when listening to a radio station.
	**Status light**	Displays the product's connection to WiFi, indicates when the volume is muted, and signals errors. [Learn more.](#)

Note: If you don't want to allow playback or volume adjustments using the speaker touch controls, you can disable them in the rooms settings.

Connector panel



1	**Ethernet port**	Use an Ethernet cable if you want to connect to a router, computer, or network-attached storage (NAS) device (optional).
2	**Stereo audio in (Line-in / LEF)**	Use to connect an external device, like a turntable or CD player.
3	**Join button**	Press to connect to your Sonos system during setup.
4	**AC power (mains) input**	Use only the supplied power cord during a first and power cord with your setup assistant. **Note:** Insert the power cord firmly until it is flush with the bottom of the speaker.

Select a location

You can put your speaker just about anywhere. For maximum performance, here's a few guidelines:

- Five is a subwoofer and sound for speaker and should be placed on a flat surface that is robust and stable enough to support the product's weight. Place your Five on a bookcase, on the floor, or on a table.
- Avoid placing your speaker where the vents are blocked by furniture or other objects.
- For a single Five speaker, we recommend positioning the speaker horizontally to enable stereo sound.
- Place Five across the room from where you'll be listening (at or close to your ear height for best results).
- For stereo set placement information, see [Set up stereo pair](#).
- Five is humidity resistant so you can use it in the bathroom, however it is not water resistant, so don't position it near water or leave it outside during rain storm.

Set up stereo pair

Pair two Sonos speakers in the same room for an even richer stereo effect. One speaker acts as the left channel and the other as the right channel.

Note the Sonos speakers in a stereo pair must be of the same type.

- To position the speakers 1.5 to 3 meters apart. Your favorite position should be 2.5 to 3.5 meters from the paired speakers — more distance enhances the bass, more distance improves the stereo imaging.
- Open the Sonos app and go to **Settings**.
- Choose one of the products you want to use in the stereo pair.
- Select **Set up stereo pair** to begin.

[Learn more](#)

Set up surrounds

It's easy to set two Sonos speakers as home theater rear surrounds or Sonos Arcs and your favorite non-Sonos speakers, into separate right and left channels for your home theater.

- Place each surround speaker about 1.5 ft from your favorite listening position, angling them toward the seating area.
- Go to **Settings** ⚙.
- Select a room with a soundbar and choose **Add Surrounds** to get started.

Note: If you group the room or create a stereo pair instead, you won't have surround sound.

[Learn more](#)

Surround audio settings

During setup, surround sound is optimized for your room. These settings are adjustable:

Surround Sound	Turn surround sound **On** or **Off**.
TV Level	Adjust surround volume for TV audio.
Music Level	Adjust surround volume for music.
Music Playback	**Ambient** (default) or **Full** (louder, full range). Doesn't apply to Dolby Atmos Music playback.

Line-in

Connect an audio device, like a projector, CD player, or turntable (with a built-in phono preamp) to any Sonos product that has a line-in port (Arc, Ultra, Era 300, Era 100, Amp, Port, or Five). Then go to ⚙ > **Line-In** to select the source and start playback.

Note: Era 100 Era, Era 300, and for 100 require a Sonos Line-in or Combo 2 Mk2 (sold separately). Other products may require a different type of line-in adapter depending on your audio source.

[Learn more](#)

Product settings

You can customize these products for your surroundings.

1. Go to **Settings** ⚙.
2. Select a product.

Room Name	If you move your speaker to a new room, you can change its name in **Settings**.
Turn off WiFi (not available for Sonos Era 100, Era 300, or portable products)	You can turn off your speaker's WiFi when it's connected to Ethernet to reduce its wireless signals. This reduces power consumption and can improve connectivity for wired speakers. For products like Arc and Ultra, turning off WiFi can also help if you're having trouble switching TV audio between a wired or streamed. [Learn more](#) **Note:** WiFi is turned off for Era 100 and Era 300 when connected to [Sonos Combo 2 Mk2](#) using the Ethernet connection.
EQ	Sonos products ship with preset equalization settings. You can change the sound settings (bass, treble, or loudness) to suit your personal preferences. [Learn more.](#)
Trueplay	Trueplay adapts the sound for your surroundings and content. Portable products can tune themselves automatically. [Learn more.](#)
Volume Limit	You can set a maximum volume for each room. [Learn more](#)
Status Light	Displays the speaker's connection to WiFi, indicates when the volume is muted, and signals errors. [Learn more.](#) **Note:** If the light is distracting, you can turn it off in **Settings**.
Touch Controls	You can disable the touch control on your speaker. You'll still be able to use the Sonos app to control it, and Trueplay tuning and adjusting playback or volume. [Learn more](#)
Battery Saver (portable products only)	To save battery life, you can set your portable speaker to turn off automatically instead of going to sleep. Adjust the slider in the Sonos app until it's powered down as:
	When a projector, turntable, stereo, or other audio device is connected to a Sonos product, you can adjust these line-in settings:
	• **Line-In Name:** Choose a name for the line-in device.
	• **Source level:** Adjust the line-in source level if you find the default volume either too quiet or distorted.
	• **Audio Delay:** Add a delay between the line-in source and Sonos to reduce the chance of audio and video being out of sync when you play line-in sources on grouped speakers.
	• **Autoplay:** Choose a room if you want line-in audio to start playing automatically when Sonos detects a signal on the line-in port.

Zones

Setting up zones helps you fill large spaces with sound. A zone is a two-part permanent configuration for synchronized playback between two speakers. Each speaker in a zone plays a different channel of the stereo recording. Currently, these products can be added to zones in the Sonos app: Arc Ultra, Arc, Era 300, Era 100, Five, Era 100 Era, Era One, and One SL. You can also add a sub to a zone that only contains a single Amp Multi.

Once a zone is created, all products added to it are controlled together as though they are a single item. This includes grouping with other rooms, playing music, and when connected to giving them each a unique name, like Living Room, Kitchen 2, Kitchen 3 and so on grouping them.

You can add a maximum of 32 products to a zone. Any number of outputs from a single amp counts as 1 product. A system can contain a maximum of 32 products in zones.

To ensure the best experience while using zones, we recommend setting up wired internet connections into your Sonos system. If using wireless connections (WiFi) please keep the speakers in zones close to your router.

Use the subs in zones to harmoniously group various zones and speakers together. When you engage, your scene will stay intact.

Set up a zone

Zones can be a single room, half of a room, or even multiple rooms.

1. Go to **Settings** ⚙.
2. Choose a compatible room, portable, or soundbar in the zone you want to add.
3. Select **Products**, and then select **Set Up Zone** to get started.
4. Select a room to add to the zone, and then select **Done** or **Separate Zone** in **Settings** ⚙.

Manage, edit, and separate your zones

After a zone is created, you can change the speakers in a zone or remove a zone altogether.

1. Go to **Settings** ⚙ and select a zone.
2. Under **Products**, select either **Add Zone** to add or remove speakers in the zone or **Separate Zone** to separate the speakers in the zone.

Identify speakers in a zone

If you have more than one speaker in your zone, you can check them by going to Sonos Settings, selecting the zone, and hovering the product list. In this case, speakers in a zone have a speaker icon next to them within Settings. You can check that icon to have it play a short sound and flash its LEDs so you can identify its physical location.

Accessories

Find the perfect accessory for your Sonos system—tailored to perfectly fit your Sonos products. For a full selection of Sonos-compatible stands, wall mounts, chargers and cables, see [Accessories](#) on our website.

Specifications

Feature	Description
AUDIO	
Amplifier	Six Class-D digital amplifiers use Trueplay tuned to match the acoustic signature of each speaker's drivers and the enclosure's architecture.
Tweeter	Three tweeters create the crispest and cleanest high-frequency response.
Mid-woofer	Three mid-woofers ensure you hear the full midrange of your music, delivering vocals, guitars, and more with rich bass—without distortion, even at high volumes.
NETWORKING*	
	Using Sonos S2: Connects to WiFi with any 802.11a/b/g/n/ac/ax 2.4/5 GHz broadband-capable router.
	Wi-Fi Architecture/Operation: Dual-band WiFi 6 (802.11ax) using the Sonos app.
	1. Go to **Settings**.
	2. Select **Five** from your System list.
	3. In the Product section select **Five**.
	4. Then in the Connection section Enabled/Disable WiFi.
	*Wi-Fi disable only available when **Five** has an Ethernet connection.
	Bluetooth 5.0 supports audio streaming from any Bluetooth enabled device.
Bluetooth	Press the Bluetooth button to pair with a Bluetooth device.
	Bluetooth Autoformation Deactivation: Bluetooth can be fully deactivated by pressing the Bluetooth button located on back of **Five**.
Ethernet port	One 10/100Mbps Ethernet port. You can plug a Sonos product directly into your router if your WiFi is unstable.
GENERAL	
Power supply	Auto-switching 100 - 240 V 50-60Hz 2.3A AC external circuit.
Audio line-in	Auto-detecting 3.5mm audio line-in connection. Use an accessory cable to connect an audio device.
Dimensions (W x H x D)	14.05 x 8.03 x 8.08in. (356 x 203 x 154mm)
Weight	14lb / 6.36kg
Threaded mount	None
Operating temperature	32°F to 122°F (0°C to 50°C)
Storage temperature	-4° to 140°F (-20° to 70°C)
Product finish	White matte or black matte exclusive, graphite grille
Package contents	Sonos Five, power cord, and Quickstart Guide

*Specifications subject to change without notice.

Important safety information

1. Read these instructions.
2. Keep these instructions.
3. Heed all warnings.
4. Follow all instructions.
5. Do not use this apparatus near water.
6. Clean only with dry cloth. Household cleaners or solvents can damage the finish on your Sonos products.
7. Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
8. Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus that produce heat.
9. Protect the power cable from being walked on or pinched, particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
10. Only use attachments/accessories specified by the manufacturer.
11. Unplug this apparatus during lightning storms or when unused for long periods of time.
12. The product does not have any user-serviceable parts. Do not open or disassemble or attempt to repair it yourself. Opening or removing covers may expose you to dangerous voltages or other hazards. Refer all servicing to qualified service personnel. Servicing is required when the product has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.
13. The Mains plug should be readily available to disconnect the equipment.

Hearing: To reduce the risk of fire or electric shock, do not expose this apparatus to rain or moisture.

14. Do not expose apparatus to dripping or splashing and do not place objects filled with liquids, such as vases, on the apparatus.