Era 200

ENG - SLO

Overview



- Era 200 speaker
- Era 200 Wall Mount
- Era 200 Stand
- Era 200 Stand Mount
- Quick Start Guide
- Safety and Warranty Information booklet
- Power cable
- Speaker connector panel cover

Controls and lights



Name	Function
Volume control	• Turn to increase the volume. • Turn to decrease the volume. • Press to mute the microphone. The LED indicator lights red. Press again to unmute.
Bluetooth	• Press to enter the Bluetooth pairing mode. • Press to disconnect the Bluetooth device.
Input Selector	• Press to change the input source. **Note:** The input source will change automatically when you connect a device.
Microphone mute	Press to mute the microphone. The LED indicator lights red. Press again to unmute.
Microphone mute	Press to mute the microphone. The LED indicator lights red. Press again to unmute.

Connector panel



Power input	Connect the power cable.
Reset button	• Press and hold to reset the device.
Microphone input socket	Connect the microphone cable. **Note:** Use only the microphone cable that is supplied with the device. Using other microphone cables may result in poor audio quality.
USB-C port	• Connect the USB-C cable for charging your smartphone or tablet. • Connect the USB-C cable for Bluetooth pairing with your computer. **Note:** Use only the USB-C cable that is supplied with the device. Using other USB-C cables may result in poor audio quality.

Select a location

Position your speaker on a flat surface, or mount it to the wall. Do not place your speaker:

- Near heat sources, such as radiators or heaters.
- In direct sunlight or in areas with excessive dust.
- In areas with excessive moisture.
- Where it is exposed to rain or water.
- Where it is exposed to shocks or vibrations.
- Where it is exposed to strong magnetic fields.
- Where it is exposed to ambient temperatures above 35°C (95°F) or below 5°C (41°F).

Caution: Do not block the ventilation openings on the speaker. Leave a minimum distance of 10 cm (4 inches) around the speaker for ventilation.

Power supply

- Connect the power cable to the power input on the speaker.
- Connect the power cable to a power outlet.

Bluetooth pairing

- Connect your Bluetooth device to the speaker. Refer to the user manual for your Bluetooth device for more information.
- Press the Bluetooth button on the speaker. The LED indicator flashes blue.
- Select the speaker from the list of available devices on your Bluetooth device.

Line-in

- Connect the audio cable to the line-in socket on the speaker.
- Connect the audio cable to the audio output socket on your device.
- Select the line-in input source on the speaker.

Microphone on/off

Press the mute button to mute the microphone.

- The LED indicator lights red when the microphone is muted.
- The LED indicator flashes red when the microphone is muted and you receive a call.
- The LED indicator flashes green when you receive a call.

Press the mute button again to unmute the microphone.

- The LED indicator turns off when the microphone is unmuted.

Note: The microphone is automatically unmuted when you end the call.

Voice services

Control your voice services, such as Siri or Google Assistant, with the speaker.

- Press and hold the Input Selector button to activate your voice assistant.

Note: Your voice assistant must be set up on your smartphone or tablet before you can use it with the speaker.

Note: Your voice assistant may not be available in all languages and regions.

Trueplay™

Trueplay™ tuning optimizes the audio performance of your speaker for the environment in which you are using it. Trueplay™ tuning is available for iOS devices.

- Download the Bang & Olufsen app from the App Store.
- Follow the instructions in the app to perform Trueplay™ tuning.

Note: Trueplay™ tuning is not available for all languages.

Advanced tuning

Advanced tuning allows you to adjust the audio performance of your speaker to your personal preferences.

- Download the Bang & Olufsen app from the App Store.
- Follow the instructions in the app to perform advanced tuning.

Set up stereo pair

You can connect two speakers to create a stereo pair. One speaker acts as the left speaker and the other as the right speaker.

- Connect both speakers to the same power source.
- Connect both speakers to the same Bluetooth device.
- Press the Bluetooth button on the speaker that you want to use as the left speaker. The LED indicator flashes blue.
- Press the Bluetooth button on the speaker that you want to use as the right speaker. The LED indicator flashes blue.

The speakers will automatically connect to each other and create a stereo pair.

Set up surrounds

You can connect two speakers to create a surround pair. One speaker acts as the left surround and the other as the right surround.

- Connect both speakers to the same power source.
- Connect both speakers to the same Bluetooth device.
- Press the Bluetooth button on the speaker that you want to use as the left surround. The LED indicator flashes blue.
- Press the Bluetooth button on the speaker that you want to use as the right surround. The LED indicator flashes blue.

The speakers will automatically connect to each other and create a surround pair.

Product settings

- Connectivity
- Sound
- Microphone
- Voice assistant
- Device info

Connectivity

Bluetooth	Turn Bluetooth on or off. Connect to a Bluetooth device.
Input selector	Select the input source.
Line-in	Turn the line-in input on or off. Set the line-in input to always on. The line-in input is always on, even when the speaker is in standby.
Multipoint	Connect to two Bluetooth devices at the same time.
Chromecast built-in	Turn Chromecast built-in on or off.
Wake word	Select a wake word for your voice assistant.
Network	Connect to a wireless network. Turn the wireless network on or off.
Wake-up	Turn wake-up on or off. Set the wake-up source.
Power mode	Set the power mode to Eco or Full. **Note:** Eco mode is the default setting.
Wake-up & standby	Set the wake-up and standby options.
Auto-off	Set the auto-off timer.
Voice prompts	Turn voice prompts on or off.

Sound

Trueplay™ tuning	Perform Trueplay™ tuning.
Advanced tuning	Perform advanced tuning.
Reset sound	Reset the sound settings to the factory default.

Microphone

Microphone mute	Turn microphone mute on or off.

Voice assistant

Voice assistant	Select your voice assistant.
Wake word	Select a wake word for your voice assistant.

Device info

Name	Change the name of the speaker.
Serial number	View the serial number of the speaker.
Product number	View the product number of the speaker.
Software version	View the software version of the speaker.
Update	Update the software of the speaker.
Restart	Restart the speaker.
Factory reset	Reset the speaker to the factory default settings.

Zones

You can create zones with your speakers. Each zone can play different music.

- Download the Bang & Olufsen app from the App Store.
- Follow the instructions in the app to create zones.

Set up a stand

- Connect the stand mount to the stand.
- Connect the speaker to the stand mount.

Storage with accessories

- Connect the stand mount to the stand.
- Connect the speaker to the stand mount.
- Connect the accessories to the speaker. Refer to the user manual for your accessories for more information.

Update the software

- Download the Bang & Olufsen app from the App Store.
- Follow the instructions in the app to update the software.

Factory reset the speaker

- Press and hold the Volume control for 10 seconds. The LED indicator flashes red.
- Release the Volume control. The speaker restarts.

Accessories

You can purchase accessories for your speaker.

Era 300 Stand

- Era 300 Stand
- Era 300 Stand Mount
- Era 300 Wall Mount

Era 300 Wall Mount

- Era 300 Wall Mount
- Era 300 Stand Mount

Cleaning

- Clean the speaker with a soft, dry cloth.
- Do not use liquids, cleaning agents or aerosols.

Recycling

- Dispose of the packaging in accordance with local recycling regulations.
- Dispose of the speaker in accordance with local recycling regulations.

Choose the orientation

Wall mounting

- Mount the speaker vertically.
- Position the connectors at the bottom.

Horizontal mounting (table top)

- Mount the speaker horizontally.
- Position the connectors at the back.

Mount upright



1. Drill two holes in the wall. Make sure that the distance between the holes is 200 mm (7.87 inches).
2. Insert the wall plugs into the holes.
3. Screw the screws into the wall plugs. Leave a gap of 3 mm (0.12 inches) between the screw head and the wall.
4. Hang the speaker on the screws.