
Contempo - 6 Drawer Chest

Assembly Instructions - Please keep for future reference

204/8077

228/4707



Dimensions

Width - 120.4cm
Depth - 42.4cm
Height - 66.2cm

Important – Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline:**
Argos = 0345 6403030

BK03050 - Issue 1 - 30/05/2014

Safety and Care Advice

Important – Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on pages 2 and 3.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• Do not stand or put weight on the product, this could cause damage.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor.

• Do not use extended drawers to aid standing. Do not stand on extended drawers.

• Do not over load drawers, the maximum load per drawer should not exceed 3kg.

• To prevent bowing of shelves do not over load, and always distribute weight evenly.

• If a residual aroma is experienced with your new furniture after the packaging is removed simply ensure the room is well ventilated and this will assist a speedy removal



• We do not recommend the use of power drill/drivers ***for inserting screws,*** as this could damage the unit. Only use hand screwdrivers.

• Dispose of all packaging carefully and responsibly.

• It is essential that this unit be fixed to a wall with the fittings provided.

• Parts of the assembly will be easier with 2 people.

• Please retain the product label on the back of the unit, as this information will help support any queries.

Care and maintenance - Non compliance with this information may affect your guarantee

• Dust with a clean cloth or, if required a slightly damp cool cloth. Do not use household cleaners, abrasives or polishes as permanent damage may occur.

• Do not drag the furniture or lift it by its top.

• Avoid sharp objects, contact with water and direct heat on all surfaces

• Your furniture is finished to the required colour. Avoid exposure to strong sunlight as this can change the colour. Change in appearence may also occur if items are permanently left on a surface.

• Drawers should be secured or removed before moving.

• You should get assistance when moving or lifting your furniture. Furniture consisting of more than one unit should be disassembled before attempting to move it.

• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints

• Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts.


• Regularly check and ensure that all boths and fittings are tightened properly.

Note: if required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.

Components - Panels

If you have damaged or missing components, call the **Customer Helpline: Argos = 0345 6403030**

Please check you have all the panels listed below





1 6 Drawer chest (66.2 x 120.4 x 42.4cm)


Components - Fittings

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.


A 	**B** 	**C** 
15mm Screw x 1	15mm Washer x 2	Wall strap x 1

Tools required



Phillips screwdriver
(medium)

Ruler - Use this ruler to help correctly identify the screws





The screws length is measured from the head to the point (30mm screw shown) .

Assembly Instructions

Step 1


Fixing to wall

It is recommended that the chest is fixed to a wall

Fix wall strap C to the back of the chest top using 15mm screw A and 15mm washer B.

Warning: The 15mm screw A is for fixing the wall strap C to furniture only. In addition to this you will need to choose a screw or fitting which is suitable for securing the wall strap C to the type of walls you have. If you are unsure about what type of screw to use seek professional help.

Assembly is complete.



If you need help or have damaged or missing parts, call the **Customer Helpline:**
Argos = 0345 6403030