WHITE 2 SLICE TOASTER
INSTRUCTION MANUAL



THIS IS AN ATTENDED APPLIANCE

DO NOT LEAVE THE TOASTER UNATTENDED WHEN IN USE

USER INSTRUCTIONS
Please keep these instructions

IMPORTANT SAFEGUARDS

When using electrical appliances. basic safety precautions should always be followed including the following:

- **READ ALL INSTRUCTIONS**
- Before switching on, ensure that the voltage on the rating plate is the same as in your home.
- First use the toaster for a few minutes without bread. There will be some smoke at first: this is entirely normal.
- The toaster reaches very high temperatures, particularly in the area of the openings for the bread.
- Do not use the toaster close to or under curtains or other inflammable materials the bread may burn.
- Do not leave the toaster operating without supervision.
- Use only pre-sliced bread.
- Do not place the cord or any other object over the bread openings on the toaster while it is in use.
- Do not cover the toaster while it is in use.
- Keep the toaster away from flames or hot areas.
- Keep the toaster out of reach of children.
- Do not insert utensils in the toaster.
- If the cord is damaged, to avoid hazards, it must be replaced by the manufacturer or by an Authorized Technical Service.
- The appliance is not intended for use by young children or infirm persons without supervision.
- Young children should be supervised to ensure that they do not play with the appliance.
- Do not touch hot surface.

Please note:Bread can curl during the toasting process, this can prevent the toast from being ejected. You must supervise the toasting process at all times.

- Do not operate the toaster underneath wall cupboards.
- This appliance is not intended for used by persons(including children)with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliances by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.

SAVE THESE INSTRUCTIONS

If the supply cord is damaged, It must be replaced by the manufacturer, its service agent or simpliarly qualified persons in order to avoid a hazard.

MAIN COMPONENTS



OPERATION

- Plug the toaster in, and adjust the browning control for the type of toast you require. We suggest starting at mid scale and adjust accordingly for your own preference.
- Put the bread into the toasting slot, and press down the bread carriage lever. The lever will stay down and toasting will begin. DO NOT LEAVE THE TOASTER UNATTENDED WHILE IN USE.
- Once toasted, the bread will be lifted out of the toasting chamber, as the bread carriage returns to it's starting position. The toaster will switch off automatically.
- Press the "STOP" button, if you wish to stop the toasting process at any point.
- If the bread becomes jammed in the toaster, unplug from the mains and allow the toaster to cool. Carefully remove the bread. DO NOT INSERT METAL OBJECTS INTO THE TOASTING CAVITY.
- Insert one slice of bread in the centre of each toasting slot.Ensure that the bread does not jam against the bread support wires.

CLEANING

- Ensure that the toaster is unplugged before cleaning it.
- Never place it in water or any other liquid.
- To clean. UNPLUG THE TOASTER AND ALLOW TO COOL.
- Do not insert objects into the toaster cavity.
- To clean the interior, turn the toaster upside down over the sink and shake crumbs free.

CONNECTING TO POWER

Before switching on make sure that the voltage of your electricity supply is the same as that indicated on the rating plate.
This appliance may be fitted with a non-rewireable plug. If it is necessary to change the fuse in a non-rewireable plug the fuse cover must be refitted. If the fuse cover is lost or damaged. The plug must not be used until a replacement cover is obtained. It is important that the colour of the replacement fuse cover corresponds with the colour marking on the fuse.
If the plug has to de changed because it is not suitable for your socket. or becomes damaged. It should be cut off and an appropriate plug fitted following the wiring instructions below. The plug removed muse be disposed of safely as insertion into a 13A socket is likely to cause an electrical hazard.
For your own safety read the following instructions carefully before attempting to connect this unit to the mains.


MAINS (AC) OPERATION

This unit is designed to operate on 230V~ 50 Hz only. Connecting it to other power sources may damage the unit.
The wires in this mains lead are coloured in accordance with the collowing code.

BLUE = NEUTRAL, BROWN = LIVE GREEN + YELLOW = EARTH

IMPORTANT

As the colours of the wires in the mains lead of this appliance may not correspond with the coloured markings indentifying the terminals in your plug, plioceed as follows.



The wire which is coloured blue must be connected to the terminal which is marked with the letter N or coloured black
The wire which is coloured brown must be connected to the terminal which is marked with the letter L or coloured red.
The wire which is coloured green + yellow must be connected to the terminal which is marked with the letter E.
If a 13 Amp (BS 1363) Plug is used. a 13 Amp Fuse must be fitted. or if any other type of Plug is used a 13 Amp Fuse must be fitted. either in the Plug or Adaptor, or on the Distribution Board.

CAUTION

To prevent electric shock disconnect from the mains before removing cover No user serviceable parts inside. Refer servicing to qualified service personnel.

SAFETY PRECAUTION

Do not allow this unit to be exposed. to rain or moisture.
Mains Supply: 230 Volts/50 Hz - AC only

Argos

PRODUCT GUARANTEE

This product is guaranteed against manufacturing defects for a period of



This product is guaranteed for twelve months from the date of original purchase. Any defect that arises due to faulty materials or workmanship will either be replaced, refunded or repaired free of charge where possible during this period by the dealer from whom you purchased the unit.

The guarantee is subject to the following provisions:

- The guarantee does not cover accidental damage, misuse, cabinet parts, knobs or consumable items.
- The product must be correctly installed and operated in accordance with the instructions contained in this manual.
- It must be used solely for domestic purpose.
- The guarantee will be rendered invalided if the product is re-sold or has been damaged by inexpert repair.
- Specifications are subject to change without notice.
- The manufacturer disclaims any liability for the incidental or consequential damages.
- The guarantee is in addition to, and does not diminish your statutory or legal rights.

Guarantor: Argos Ltd
489 - 499 Avebury Boulevard
Central Milton Keynes
MK9 2NW

WASTE ELECTRICAL PRODUCTS SHOULD NOT BE DISPOSED OF WITH HOUSEHOLD WASTE. PLEASE RECYCLE WHERE FACILITIES EXIST. CHECK WITH YOUR LOCAL AUTHORITY FOR RECYCLING ADVICE.