BaByliss

SHEER GLAMOUR
STYLING COLLECTION
LIMITED EDITION



Model: 5737DGU

BaByliss

SHEER GLAMOUR
STYLING COLLECTION

Powerful dryer & essential styling accessories in a spacious vanity case

FEATURES

- 2200W dryer
- Spacious vanity case
- Salon paddle brush to smooth and style
- 2 sectioning clips
- 2 jaw clips



SAFETY CAUTIONS

- This appliance should only be used as described within this instruction booklet. Please retain for reference.

IMPORTANT CHILD SAFETY

WARNING! Polythene bags over a product or package may be dangerous. To avoid danger of suffocation, keep this wrapper away from babies and children. This bag is not a toy.

WARNING! THIS APPLIANCE GETS HOT!

- **ALWAYS** keep out of reach of children (during and after use and while cooling)
- This appliance should not be used, cleaned or maintained by children.
- Always take extra care if used on children or near children
- Do not use on very young children.

IMPORTANT SAFETY INFORMATION

- **UK Only:** This appliance must not be used in the bathroom. If using the appliance in the bathroom, unplug after use as the proximity of water can be dangerous even if the appliance is switched off. For additional protection, the installation of a residual current device (RCD) with a rated residual operating current not exceeding 30mA is advisable in the electrical circuit supplying the bathroom. Ask your installer for advice.

WARNING! Do not use the appliance near water contained in basins, bathtubs or other vessels.

- Do not use the appliance in the bathroom.
- Do not immerse the appliance in water or other liquids.
- Never look directly into the barrel of the hairdryer when it is switched on.
- Always inspect the appliance before use for noticeable signs of damage, or if the appliance has been dropped.
- Do not use if the appliance or lead are damaged. In the event of damage, discontinue use immediately. Contact the Conair Customer Care Line (refer to "UK After Sales Service" section for further information). No repair should be attempted by the consumer.
- Do not leave the appliance unattended when switched on or plugged in.
- Take care that the air vents do not become blocked when the appliance is in use. Ensure the rear filter is clear of hair and other debris before use (refer to Cleaning & Maintenance section for further information).
- This appliance is equipped with a safety thermostat. In the event of overheating, the appliance will stop automatically. Should this happen, switch the appliance off, unplug and allow to cool for 10 minutes. Ensure the rear filter is clear of hair and other debris (refer to Cleaning & Maintenance section for further information). Plug the appliance into the mains and switch on. If the appliance continues to overheat, discontinue use immediately, switch the appliance off and unplug. Contact the Conair Customer Care Line (refer to "UK After Sales Service" section for further information).
- Do not place the appliance on any surface whilst in operation.
- Take care to avoid the hot surfaces of the appliance coming into direct contact with the skin, in particular the eyes, ears, face and neck.
- Careful adult supervision is required when this appliance is used on or near children. Do not use on very young children.
- This appliance should not be used by adults whose reduced physical, sensory or mental capabilities, or whose lack of experience and knowledge, might cause a hazard, unless they have been correctly instructed to understand the safe use and hazards involved and are adequately supervised.
- Allow the appliance to cool before storing away.
- After use, do not coil the lead around the appliance as this may cause damage. Instead coil loosely by the side of the appliance.
- This appliance complies with the requirements of Directives 2004/108/ EC (Electromagnetic Compatibility) and 2006/95/EC (Electrical Safety of Domestic Appliances), amended by Directive 93/68/ EC (CE Marking).

5737DGUIB 15/291.indd 1 7/2/15 11:37 AM

IMPORTANT!

- This appliance should only be used as described within this instruction booklet. Please retain for reference.

INSTRUCTIONS FOR USE

- Plug the dryer into a suitable mains supply.
- Ensure hair is towelled dry and combed through to remove tangles.
- There are 3 heat (I II III) & 2 speed settings (0 I II).
- Use the high heat and speed settings for initial drying and the lower heat and speed settings to finish drying and for styling.
- Use the cool shot button on warm hair to “set” a curl or wave.
- For additional control when styling, attach the concentrator nozzle and using the lower heat and speed settings, direct the airflow along the surface of the hair to be dried.
- After use, switch off and unplug the appliance. Allow to cool before storing away.

CARE OF YOUR DRYER

- Do not use the dryer at a stretch from the power point. Stretching the connection between the lead and the dryer can be dangerous.
- Always keep the rear of the dryer away from your hair during use to prevent hair ingress.
- Always unplug after use. Smooth out the lead to remove kinks and prevent damage.
- Do not wrap the lead around the dryer, instead coil it loosely by the side.
- Make sure the dryer is used on the correct voltage.

CLEANING & MAINTENANCE
Cleaning the filter

To keep your hairdryer in the best possible condition and maintain optimum performance, the rear filter should be cleaned on a regular basis.

- Ensure the appliance is switched off, unplugged and cool.
- To remove the filter, simply turn it gently then lift away from the dryer.
- Using a soft brush, clean any hair and other debris from the filter.
- Replace the rear filter before using the dryer again.

UK WIRING INSTRUCTIONS

The wires in the mains lead are coloured in accordance with the following code:

- BLUE = NEUTRAL
- BROWN = LIVE

As the colours of the wire in the mains lead of this appliance may not correspond with the colour marking identifying the terminals on your plug, proceed as follows:

The wire which is coloured BLUE must be connected to the terminal which is marked with the letter N.
The wire which is coloured BROWN must be connected to the terminal which is marked with the letter L.
Neither the BLUE nor BROWN wires should be connected to the terminal which is marked with the letter E or the ⏚ symbol.

This appliance is supplied fitted with a BS1363 mains plug and a BS1362 13A fuse. If this plug is removed from the appliance please ensure it is disposed of safely as a disconnected plug is dangerous if reconnected to the mains. If any other type of plug is used, a 13A fuse must be fitted.

SAFE DISPOSAL



The symbol on the product or on its packaging indicates that this product may not be treated as household waste. Instead it should be handed over to an appropriate collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. For more detailed information about the recycling of this product, please contact your local council office or your household waste disposal service.

UK GUARANTEE

This appliance is guaranteed for consumer use for 3 years. Please keep your receipt as proof of purchase to validate the guarantee. This guarantee covers defects under normal use from date of purchase and ceases to be valid in the event of alteration or repair by unauthorised persons. If the appliance does not perform satisfactorily due to defects in materials or manufacture, it will be repaired or replaced through the Conair UK After Sales Service. Conair reserve the right to amend terms and specifications without prior notice.
This guarantee in no way affects your statutory rights.

UK AFTER SALES SERVICE

For further advice on using the appliance or should you need to return your product, please contact the Conair Customer Care Line on 03705 133191 (09:00 to 17:00 Monday to Friday) or email your enquiry to ukinfo@conair.com

The return address is:

Customer Care Centre
Conair Logistics
Unit 4 Revolution Park
Buckshaw Avenue
Buckshaw Village
Chorley
PR7 7DW

Please enclose your returns number, name and address details, together with a copy of proof of purchase and details of the fault.

BaByliss

SHEER GLAMOUR
STYLING COLLECTION

5737BCU IB15294.indd 2 7/2/15 11:37 AM