MY FIRST SKATES

Fitting & User Instructions

543/4389

Safety Information

Important - Please read these instructions fully before assembly or use

Important


Age: 3+ Years

Protective equipment should be worn such as a helmet, gloves, knee and elbow pads.
Never use in roadways, near steps or steep inclines or near pools or open bodies of water.
After use, please wipe product with mild detergent.
Do not leave this product in high temperature, intense sunlight or dusty areas.
Store in dry place.
This item should be used with caution since skill is required to avoid falls or collisions causing injury to user or third parties.
To be used under supervision of an adult.
There is braking device at the front of skate and it functions when it touches the ground.
If you want to stop skating, raise the rear of skate and let the brake touch the ground.

Fitting Instructions


Step 1

Press down on the buckle to release the ankle strap.
Turn the skate over to loosen the wingnut on the underside.




Step 2

Adjust the size of the skate to fit your childs shoe,
then tighten the wingnut.



Step 3

When your childs foot is firmly inside the skate,
push the strap into the buckle to secure the skate.



Produced for CHAD VALLEY TOYS:
Argos Ltd
489-499 Avebury Boulevard,
Central Milton Keynes, MK9 2NW
Visit www.argos.co.uk/chadvalley