
BUSH

Instruction manual

SPK312



You'll soon be enjoying your new Bluetooth Stereo Speaker.

It all begins here, with your instructions. Don't worry, there's nothing too technical coming up. Just simple, step-by-step guidance to get you up and running quickly. Sound good? Then let's get started.

Help and Guidance

We're here to help you get the most from your Bluetooth Stereo Speaker. Should you require any guidance, a simple solution can often be found online at:

www.argos-support.co.uk


If you still require further assistance, call one of our experts on **0345 604 0105.**

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting**

BUSH

Contents

Safety Information	**2-4**
Functions & Controls	**5**
Accessories included	**5**
User Instructions	**6**
Power ON/OFF	6
Bluetooth	6
Power bank	6
Operations	6-7
LED indicator Status	7
Caution	8
Troubleshooting	**8**
Rechargeable battery removal	**9**
Specifications	**9**
Product support	**10-12**



Product Codes
SPK312

Safety Information

Important – Please read these instructions fully before installation

- Read all the instructions carefully before using the unit and keep them for future reference.

- Retain the manual. If you pass the unit onto a third party make sure to include this manual. Check that the voltage marked on the rating label matches your mains voltage.

Damage

- Please inspect the unit for damage after unpacking.
- Do not continue to operate the unit if you are in any doubt about it working normally, or if it's damaged in any way- switch off, withdraw the mains plug and consult your dealer.

Location of Unit

- The unit must be placed on a flat stable surface and should not be subjected to vibrations.
- Do not place the unit on sloped or unstable surfaces as the unit may fall off or tip over.The mains unit and should be easily accessible. socket must be located near the unit.

Temperature

- Avoid extreme degrees of temperature, either hot or cold. Place the unit well away from heat sources such as radiators or gas / electric fires.

- Avoid exposure to direct sunlight and other sources of heat.

Naked Flames

- Never place any type of candle or naked flame on the top of or near the unit.

Moisture

- To reduce the risk of fire, electric shock orproduct damage, do not expose this unit to rain, moisture,dripping or splashing. No objects filled with liquids, such as vases, should be placed on the unit.
- If you spill any liquid into the unit, it can cause serious damage. Switch it off at the mains immediately . Withdraw the mains plug and consult your dealer.

Safety Information

Important – Please read these instructions fully before installation

Ventilation

- To prevent the risk of electric shock or fire hazard due to overheating, ensure that curtains and other materials do not obstruct the ventilation vents.
- A minimum distance of 5cm around the unit should be maintained to allow for sufficient ventilation.

Safety

- Always disconnect the unit from the mains supply before connecting/disconnecting other devices or moving the unit.
- Unplug the unit from the mains socket during a lightning storm.
- In the interests of safety and to avoid unnecessary energy consumption,never leave the unit switched on while unattended for long periods of time, e.g.overnight, while on holiday or while out of the house. Switch it off and disconnect the mains plug from the mains socket.

Interference

- Do not place the unit on or near appliances which may cause electromagnetic. interference.If you do, it may adversely affect the operating performance of the unit, and cause a distorted sound.

Service

- To reduce the risk of electric shock, do not remove screws. The unit does not contain any user-serviceable parts. Please leave all maintenance work to qualified personnel.
- Do not open any fixed covers as this may expose dangerous voltages.


Maintenance

- Ensure to unplug the unit from the mains socket before cleaning.Do not use any type of abrasive pad or abrasive cleaning solutions as these may damage the unit's surface.
- Do not use liquids to clean the unit.

Safety Information

Important – Please read these instructions fully before installation





The lightning flash with arrowhead symbol, within an equilateral triangle, is intended to alert the user to the presence of uninsulated “dangerous voltage” within the unit’s enclosure that may be of sufficient magnitude to constitute a risk of electric shock.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the manual accompanying the unit.

CE This appliance complies with the following EU directives: 2006/95 /EEC Low voltage directive, 2004/108/EC EMC directive,2002/96/ EC WEEE directive.

This product is intended for use within the UK. This equipment complies with the essential requirements for the Radio Equipment and Telecommunications Terminal Equipment Directive 1999/5/EC.

Functions & Controls


Customer Helpline: 0870 600 3030

Please familiarize yourself with the parts and accessories listed below

Accessories included

- 1 x SPK312
- 1 x Micro USB cable
- 1 x Instruction manual

Overview of controls



1. Knob Switch (Power ON/OFF [Press and hold];
   Vol-/Vol+ [Turn left / right])

2. AUX IN (Connect the mobile phone via the 3.5mm Audio cable directly)

3. Micro USB INPUT Socket (Connect the provided micro USB cable to your computer for charging up the speaker)

4. Battery charging indicator

5. USB OUTPUT (Charge the mobile phone)

6. Mode indicator

7. Microphone

User Instructions

Power ON/OFF


- Press and hold the knob switch to turn the unit on.The unit will beep. The LED indicator will blink in red once, then light up in blue color.
- Press and hold the knob switch to turn the unit off. The LED indicator will disappear.

Bluetooth

1. Turn on the Bluetooth function of your Bluetooth device.
2. Turn on the speaker, it will beep.
3. Press and hold the knob switch button twice continuously and quickly to activate Bluetooth pairing. The unit will beep,then the LED indicator will flash blue until it pairs. When successfully paired, the unit will beep once and the LED indicator will regularly flash blue at 5-seconds intervals (approx.).
4. Search for the unit with your Bluetooth device and you should see “SPK312”. Enter password “0000” if requested.

Power bank

- Connect the charging cable of your mobile phone to the USB OUTPUT as shown below. It would start charging.



Note: 1. Make sure the product is turned on and fully charged during use.
2. Please PAUSE or OFF the bluetooth connec tion when charge your mobile phone.

Operations

To	Press / Hold	Effect
Increase Volume	Turn right the knob switch	Louder
Decrease Volume	Turn left the knob switch	Quieter
Answer Call (during playback)	Press once the knob switch	Answer call & stop playback
End Call (during playback)	Press once the knob switch	End Call
Reject Call (any time)	Press the knob switch for about 1 second	Reject call
Use Speaker for call (during call)	Press the knob switch for about 1 second	Switch to unit’s mic and speaker
Use mobile phone for call (during call)	Press the knob switch for about 1 second	Switch to mobile phone

User Instructions

Operations

Call functions only applicable if mobile phone is paired with the speaker and both are switched on.

When the minimum volume or maximum volume is reached, the unit will beep.

- To successfully answer a call, ensure your mobile device supports Bluetooth HFP.
- Ensure your Bluetooth device is configured to take full advantage of the unit's functions. Please refer to your Bluetooth device's manual for detailed instructions.
- When using the AUX IN function, you need to use your media device for all operations.

LED Indicator Status

The below table provides a summary of the LED indicator statuses:

Unit Mode	LED Color	LED Action
On	Red (Mode indicator)	Blinks once
Standby, without pairing	Blue (Mode indicator)	Blinks twice every other 1.5 seconds
Pairing	Blue (Mode indicator)	Blinks rapidly
Connected to Bluetooth Device	Blue (Mode indicator)	Blinks twice every other 5 seconds
AUX IN	Red & Blue (Battery indicator)	Solidly lit & Blinks as the Bluetooth mode
Charging	Red (Battery indicator)	Solidly lit
Charging complete	Blue (Battery indicator)	Solidly lit

User Instructions

Caution

The unit has a built-in rechargeable Li-polymer battery.The battery is charged automatically when the micro USB INPUT socket is connected with your computer or USB charger.

- The speaker needs to be fully charged once a month.
- It takes 11 - 12 hours (approx.) to fully charge the battery.
- A fully charged unit has up to more than 12 hours of playback time.
- Do not overcharge the battery as it may shorten its life.
- To prolong battery life & sound quality, do not use while charging.

Troubleshooting

In the unlikely event of difficulties with your appliance please follow the troubleshooting guide below.
If the problem persists, contact the retailer if the machine is still under guarantee.
Customer **helpline: 0345 604 0105**

Menu	Description / Solution
No power.	• Make sure that the unit is switched ON at the rear. • The battery may be exhausted. Connect the USB cable and plug into a USB port of a computer which is turned on.
Loud hum or noise is heard.	• The plugs and sockets are dirty. Wipe them with a cloth slightly moistened with an appropriate non-abrasive cleaning solution.
Cannot answer calls	• Ensure your mobile phone supports Bluetooth HSP/HFP. • Check the mobile phone and unit are connected.
I cannot find "SPK312" on my Bluetooth device.	• Ensure the Bluetooth function is activated on your Bluetooth device.

Rechargeable battery removal

In order to preserve the ecology please dispose of this unit properly so that it can be recycled.


Do not dispose of to unsorted waste.

For more detailed information about recycling of this product or battery, please contact your local Civic Office or your household waste disposal service.

If need to disassembly the battery, please follow the steps as follow:

NOTE: The instruction for maintenance person reference only. Special tools may required.

1. Pull out the plug
2. Remove the bottom
3. Remove the iron net
4. Pull the diaphragm
5. Remove the knob and PCB.
6. Open the shell
7. Remove the battery



Specifications

Model	SPK312
Output Power	5W x2
Bluetooth	Bluetooth 3.0 + EDR (A2DP V1.2/HFP V1.6)
Dimension	177 (L) x 70 (w) x 65 (d) mm

Features and speacifications are subject to change without prior notice.

Product support

Help is always at hand

Help and assistance

If you require any technical guidance or find that your Bluetooth Stereo Speaker is not operating as intended, a simple solution can often be found in the **Troubleshooting** section of these instructions or online at **www.argos-support.co.uk**

If you still require further assistance, call one of our experts on **0345 604 0105**. To help give us give you a fast and efficient service please have the following information ready:

Model Ref.		You can find these on the rating plate - a small information panel (usually a sticker or metal plate) on the rear of your product.
Serial number		
Date of purchase		This will be shown on your receipt

Local call rates applies*

Lines open 8am-7pm Monday to Saturday and
10am-4pm Sunday.

*Calls to Argos enquiry lines may attract a charge and set up fee from residential lines depending on your call plan/tariff. Mobile and other providers costs may vary, see www.bt.com/pricing for details.

For security and training purposes, telephone calls to and from customer service centres may be recorded and monitored. Calls from Republic of Ireland will attract international call charges.

section of these instructions, or online at **www.argos-support.co.uk** If you still require further assistance, call one of our experts on **0345 604 0105**.

Product support

Help is always at hand

Disposal



The symbol on the product or its packaging indicates that this product may not be treated as household waste. Instead it should be handed over to the applicable collection point for the recycling of electrical and electronic equipment. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. For more detailed information about recycling this product, please contact your local council office, your household waste disposal service or the shop where the product was purchased.

If you are creating instructions, you may find the following links helpful:

www.environmentlaw.org.uk

www.hse.gov.uk/waste/waste-electrical

Declaration of Conformance

Hereby, Argos Ltd, declares that this Band II LPD device is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. The complete declaration of conformity can be obtained by contacting http://www.argos-support.co.uk/

If you require any technical guidance or find that your product is not operating as intended, a simple solution can often be found in the **Troubleshooting**

Product support

Help is always at hand

BUSH

Call us now and activate your 12 month guarantee

Thank you for choosing Bush. Your new product is guaranteed against faults and breakdowns for 12 months. Don't forget to register it with us today so we can provide you with our best possible after-sales service and useful updates.

www.bushregistration.co.uk

FREEPHONE*

0800 597 8548

Lines are open 8am - 8pm, 365 days a year. *Calls may be recorded and monitored.

Your Bush Guarantee

This product is guaranteed for twelve months from the date of original purchase. Any defect that arises due to faulty materials or workmanship will be repaired free of charge (or if applicable the product will be replaced or the purchase price refunded) where possible during this period by the dealer from who your purchased the unit.

The guarantee is subject to the following provisions:

- The guarantee does not cover accidental damage, misuse, cabinet parts, knobs or consumable items.
- The product must be correctly installed and operated in accordance with the instructions contained in the manual.
- It must be used solely for domestic purposes. The guarantee will be rendered invalid if the product is re-sold or has been damaged by inexpert repair.
- Specifications are subject to change without notice.
- Bush disclaim any liability for loss or damage arising from the breakdown of the product.
- This guarantee is in addition to and does not diminish your statutory or legal rights.

Important Data Protection Information

If you provide us with information about another person, you confirm that they have appointed you to act for them, to consent to the processing of their personal data including sensitive personal data and that you have informed them of our identity and the purposes (as set out in the Important Data Privacy notice displayed overleaf) for which their personal data will be processed.

You are entitled to ask for a copy of the information we hold about you (for which we may charge a small fee) and to have any inaccuracies in your information corrected.

For quality control and training purposes, we may monitor or record your communications with us.

If your personal details change, if you change your mind about any of your marketing preferences or if you have any queries about how we use your information, please let us know by contacting our Data Protection **Officer, Domestic & General, Leicester House** 17 Leicester Street, Bedworth, Warwickshire CV12 8JP.

Guarantor: Argos Limited - 489 - 499 Avebury Blvd. - Milton Keynes - MK9 2NW

section of these instructions, or online at **www.argos-support.co.uk** If you still require further assistance, call one of our experts on **0345 604 0105**.

BUSH

Contact:
www.argos-support.co.uk
Helpline: 0345 604 0105