
SASHA End Table

Assembly Instructions- please keep for future reference

609/5600
609/5617
609/6283



Dimensions

Width - 45cm
Depth - 45cm
Height - 45cm

Important – Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 0845 640 0800**

Issue 4 - 10/07/11

Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- Check you have all the components and tools listed below and opposite.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.
- Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly may be easier with 2 people.




- We do not recommend the use of power drill/drivers ***for inserting screws*** , as this could damage the unit. Only use hand screwdrivers.
- Dispose of all packaging carefully and responsibly.

Care and maintenance


- Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Components - Panels

Please check you have all the panels listed below



A Top panel x 1
45 x 45 x 5 cm



B Foot x 4
5 x 5 x 40 cm

Components - Fittings

If you have damaged or missing components, call the **Customer Helpline: 0845 640 0800**

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

a

Metal crew x 4
ø 7 x 70 mm

b




Foot mat x 4

Assembly Instructions


Step 1

Screw 4 x metal screw ⓐ into top panel A a little and then screw 4 x foot B through the screw onto top panel A as shown.

Note: the leg should be in right position after assembly and assembled tight enough, otherwise the top will be unstable.



Attach the 4 x Foot mat ⓑ onto the feet as shown. assembly is complete.



Sasha End Table


Assembly Instructions - Please keep for future reference

609/5600

609/5617

609/6283

404/2411



Dimensions

Width - 45cm

Depth - 45cm

Height - 44.5cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline:**
Argos = 0345 6400800

Version 3 Date: 19/03/15

Safety and Care Advice

Important – Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on the following pages.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• During assembly do not stand or put weight on the product, this could cause damage.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor.

• Parts of the assembly will be easier with 2 people.



• To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.

Care and maintenance

• Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.

• From time to time check that there are no loose screws on this unit.

• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Handy Hints


• Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts

• Regularly check and ensure that all bolts and fittings are tightend properly.


Components - Panels

If you have damaged or missing components, call the **Customer Helpline: Argos = 0345 6400800**

Please check you have all the panels listed below



1 Table top (45 x 45cm)



2 Leg x 4 (40 x 4.5cm)


Components - Fittings

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. in some cases more fittings may be supplied than are required.

A  72mm Screw x 4		

Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions


Step 1


Attaching legs

a: Fasten Screw Ⓐ into the Leg 2 up to half length(36mm).

Note: Please ensure screws are tightly secured.


a:






b: Fix the Legs 2 onto the Table top 1.

b:






Step 2

Finishing the unit

With help, place the unit in the intended position.



Assembly is complete.

If you need help or have damaged or missing parts, call the **Customer Helpline:**
Argos = 0345 6400800