正面

285 mm

10FT SNOWY FLOCKED TREE

Assembly Instruction – Please keep for future reference | **7829961**



Dimensions

Width - 170cm

Depth - 170cm

Height - 302cm

Important – Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 03456400800**

⚠ Safety and Care Advice

Important – Please read these instructions fully before starting assembly

- **PRODUCT IS INTENDED FOR INDOOR USE ONLY**
- This product is not designed for permanent or long-term use.
- Do not use this product for any other purpose than its intended use.
- Do not allow the product near/ in contact with a source of heat or flame, e.g. gas or electric heaters, fireplaces, candles or other similar heat sources.
- Unplug the light chain (if any) when leaving the house, when retiring for the night, or if unattended.
- This product is for decoration use only, not to be used by children as a toy. Watch over them when near the tree.
- Ensure the tree is stable, place on a firm and level surface, away from where it may be knocked. Do not overload with excessively heavy decorations.
- Artificial trees are made from small fibres and have small parts which may pose a choking hazard detached from the branches. Keep out of reach of small children and pets.
- Before using or re-using, inspect the product carefully. Dispose of the products if any parts are damaged and have sharp points and edges.

Installation - Selecting a Location

- Decide on an appropriate location for your product, make sure that you have plenty of space, a level surface and a clean dry area for assembly and location. Always try to assemble the product as close as possible to the intended location.

Components

Please check you have all parts listed below

- 5 x tree sections
- 1 x metal stand

No tools required

Assembly Instructions

1) Choose a location where the tree is to be displayed. Take the stand and pull the legs out to create an "X" as **Fig.1** Place it on a flat surface.



Fig. 1

420 mm

反面

2) Insert the pole with tapered end of the tree bottom into the tree stand and tighten the 3 screws on the stand.
3) Insert the second tree section into the tree bottom and push down into position. Insert the third tree section into second tree section and push down into position. Insert the fourth tree section into third tree section and push down into position. The branches are hinged and will fold down easily. As shown **Fig. 3**
4) Insert the tree top into the third tree section and push down into position. As shown **Fig. 2**




Fig. 2

Fig. 3

5) Finally shape the tree by arranging the tips on the branches to give the desired effect. Some tree styles have "side branches" attached to the main branch stem that require additional shaping as shown in **Fig.4**. After shaping the tree, the finished look should be natural and full.




Fig.4

Storage

Before storing the product, carefully remove the product from wherever it is placed to avoid undue strain or stress on the product conductors, connections and wires.

- If you've attached the light string to the tree, unplug it from the power supply and remove the lights from the tree.
- Remove all decorations from the tree.
- Gather the branches upwards and secure them in place.
- Gently lift off the top and middle sections. Loosen the screw on the stand, lift the tree bottom section out and flatten the metal stand.
- Carefully place the tree in its box and tape it shut. STORE THE PRODUCT IN A COOL AND DRY LOCATION PROTECTED FROM SUNLIGHT AND WHERE THE TEMPERATURE DOES NOT EXCEED 40˚.

Trouble Shooting

If you need help or have damaged or missing parts call the customer helpline: 03456 400800

Made in China for Habitat, Argos Limited.
Sainsbury's Supermarkets Ltd, London,
EC1M 6HA, UK. Argos (N.I.) Ltd and
Sainsbury's (NI) Ltd. Forestside Shopping Centre,
Upper Galwally, Belfast, BT8 6FX, UK.

habitat.co.uk/help/contact-us