
Double Covered Wardrobe

Assembly Instructions - Please keep for future reference

875/5591

875/5618



Dimensions
Width - 117cm
Depth - 50cm
Height - 160cm

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts,call the **Customer helpline: 08456 400800**

Issue 2 - 26/03/10

Safety and Care Advice

Important - Please read these instructions fully before starting assembly

- Check you have all the components and tools listed on page 2.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.
- Do not stand or put weight on the parts this could cause damage.
- Assemble the unit as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.
- If using power tools, please follow the safety instructions supplied with the tools.



- We do not recommend the use of power drill/ drivers ***for inserting screws***, when assemling the wardrobe as this could damage the unit.

Only use hand screwdrivers.

- ***Warning:*** Before drilling, check the wall for hidden pipes and cables.
- Dispose of all packaging carefully and responsibly.
- ***Warning:*** Max loading weight for whole product 8 KGS.


Care and maintenance

- Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Components - Parts

If you have damaged or missing parts, call the **Customer helpline: 08456 400800**

Please check you have all the panels listed below



1 Corner x 4



2 Thin rods x 4 (116.5cm)




3 Hanging rod x 1 (116.5cm)



4 Male rod x 4 (79.5cm)



5 Notched rod x 4 (79.5cm)




6 Cover x 1

Components - Fittings


Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly.

In some cases more fittings may be supplied than are required.

A 	B 	
Screw x 2	Wall plug (for solid walls only) x 2	

Tools required



Measure



Screw driver

Assembly Instructions

Step 1


Assemble the top Panel and bottom panel.

Note: It would be useful to ask someone to help you at this stage.

a: Bottom Panel

Attach thin rods [2] and male rods [4] to the corner [1] as shown.


a:



b: Top Panel

Attach hanging rod [3], notched rods [5] and thin rods [2] to the corner as shown.

b:



Assembly Instructions

Step 2


Fitting the Cover

Note: It would be useful to ask someone to help you at this stage.

a: Fitting the cover 6 into the Bottom Panel.

Note: Release the zippers of the cover so that the rods are exploded.


a:



Fitting the panel

b: Position the top assembly onto the bottom assembly


b:



c: Lift the cover over the top of the completed frame fitting corners. Evenly slide the cover down to the base.

Note: It is recommended that two people fit the cover over the frame.

c:



Assembly Instructions

Step 3

Fixing to wall

It is recommended that the wardrobe is fixed to a wall.

Note:

The correct type of fixing must be used for your wall,seek professional advice if in doubt.


Mark the fixing hole on the wall and remove the wardrobe. Drill a hole and insert a wall plug Ⓑ.

Warning:

Before drilling, check the wall for hidden pipes and cables.

Reposit ion the wardrobe and fix the wall strap using screw Ⓐ.

The assembly is now complete.



If you need help or have damaged or missing parts, call the **Customer Helpline: 08456 400800**

A Guide to - Wall Mounting & Fixings

Important note:

If plastic wall plugs are supplied with your product:



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.

Failure of the product due to using incorrect fixings is the responsibility of the installer.

Important: When drilling into walls always check that there are no hidden wires or pipes etc.

Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.

Hints:

1: General rule: Always use a larger screw and wall plug if you are not sure.

2: Ensure you use the recommended drill bit to match the wall plug and hole size.

3: Ensure you drill the hole horizontally, do not force the drill or enlarge the hole.


4: Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.

5: Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No.1 **"General Purpose" wall plug**




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

No.2 **"Plasterboard" wall plug**




For use when attaching light loads on to plasterboard partitions.

No.3 **"Cavity Fixing" wall plug**




For use with plasterboard partitions or hollow wooden doors.

No.4 **"Cavity Fixing-Heavy Duty" wall plug**




For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

No.5 **"Hammer Fixing" wall plug**



For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No.6 **"Shield Anchor" wall plug Heavy loads**



For use with heavier loads such as TV & HiFi speakers and satelite dishes etc.

Care & Maintenance

Safety: Always check the fitting and location to ensure your safety in and around the home.

Fitting: From time to time check the fitting to ensure the wall plugs or screws do not become loose.