

WIRELESS | SANS FIL
UNIVERSAL | UNIVERSEL

LS30

GAMING HEADSET
CASQUE **GAMING**

USER GUIDE

©2016 Lucid Sound, Inc. 2150 Palomar Airport Rd., Suite 201, Carlsbad, CA 92011 U.S.A. Lucid Sound, Lucid Gaming, the Lucid Sound logo, and the Lucid Gaming logo are trademarks of Lucid Sound, Inc., its subsidiaries, and affiliates. The shape and design of this product are a trade dress of Lucid Sound, Inc., its subsidiaries and affiliates. All rights reserved. All other product names and images are trademarks or registered trademarks of their respective owners. Made in China. Product features, appearance and specifications may be subject to change without notice. Please retain this information for future reference.

UNIVERSAL GAMING HEADSET

(L)



Game Volume

Game Mute
Rising tone = unmuted
Falling tone = muted

Power LED
Solid = ON/Connected
Slow Blink = Searching
Fast Blink = Battery Low

Power Button

USB Charging Port

Mobile/Xbox Input

Microphone Port

(R)

Chat Volume

Microphone Mute
Rising tone = unmuted
Falling tone = muted
LED on boom mic
illuminates when muted.



EQ Preset Select
1 beep for Normal
2 beeps for Bass Boost
3 beeps for Treble Boost

CABLES/PARTS

Xbox Chat Cable/ Mobile 3.5mm Cable

Xbox 360 Chat Adapter

USB Charging Cable

Optical Cable

Boom Mic



Mic Port Cover

BASE STATION



Status LED
Solid = ON/Connected
Slow Blink = Searching

Optical Input

CHARGING



Connect the small end (micro-USB) of the charging cable to the headset. Connect the other end to a USB port. The LED on the headset will pulse while charging and turn solid when charging is complete.

When battery has less than 15% power remaining, unit beeps twice every 10 minutes.

MICROPHONE



The LS30 includes an optional boom microphone. When this microphone is removed, an internal microphone is activated.

To connect the boom microphone, simply insert it into the port on the bottom of the headset.

CONNECTING TO CONSOLE

For: PS4, PS3, Xbox One, and Xbox 360



STEP 1.

Connect the wide end of the optical cable to the optical port on the rear of the Console. Early Xbox 360 Consoles may require an HDMI Audio Adapter (not included).



STEP 2.

Connect the thin end of the optical cable to the optical port on the side of the Base Station.



STEP 3.

Plug the Base Station into a USB port on the Console.

PLAYSTATION 4 SETUP

1. Go into **Settings > Sound and Screen > Audio Output Settings > Primary Output Port** and select 'Digital Out (Optical)'.
2. Make sure that **only** 'Linear PCM 44.1kHz and 'Linear PCM 48kHz' are checked.
3. Go into **Settings > Audio Output Settings > Audio Format (Priority)** and select 'Linear PCM.'
4. Go into **Settings > Devices > Audio Devices** and set both the 'Input Device' and 'Output Device' to 'USB Headset(Lucid Sound LS30).
5. Set the Output to Headphone to 'Chat Audio'.
6. Set the 'Volume Control (Headphones)' to maximum.

PLAYSTATION 3 SETUP

1. Go into **Settings > Sound Settings > Audio Output Settings > Optical Digital.**
2. Make sure that **only** 'Linear PCM 2 CH. 44.1kHz' and 'Linear PCM 2 CH. 48kHz' are checked.
3. Go into **Settings > Accessory Settings > Audio Device Settings** and set the 'Input Device' and 'Output Device' to 'Lucid Sound LS30'.

XBOX ONE SETUP



Controller with 3.5mm port

1. Always turn on the headset before turning on the controller.
2. Connect one end of the Xbox One chat cable to the 3.5mm port on the headset and the other end to the 3.5mm port on the Controller.
3. On the Xbox One, go into **All settings > Kinect & devices > Devices & accessories** and choose the Xbox One Wireless Controller in use.
4. Select 'Volume' and set 'Headset volume' to maximum and 'Mic monitoring' to minimum.
   Make sure that 'Headset mic' is turned to 'On.'
5. If it appears, set 'Headset chat mixer' all the way to the right for 100% chat.
6. On the Xbox One, go into **All settings > Display & sound.** Under 'Audio Output' select 'Optical audio' and choose 'Stereo uncompressed.'



Using Stereo Headset Adapter

1. If the Xbox One Controller does not have a 3.5mm port, an Xbox One Stereo Headset adapter is required (not included).
2. Connect one end of the Xbox One chat cable to the 3.5mm port on the headset and the other end to the 3.5mm port on the Stereo Headset Adapter.
3. Adjust the game/chat balance on the Stereo Headset Adapter to 100% chat and increase the volume on the adapter to maximum.
4. On the Xbox One, go into **All settings > Display & sound.** Under 'Audio output' select 'Optical audio' and choose 'Stereo uncompressed.'

XBOX 360 SETUP



1. Connect one end of the Xbox chat cable to the 3.5mm port on the headset and the other end to the Xbox 360 adapter. Then connect the adapter to the 2.5mm port on the Controller.
2. Go into **Settings > System > Console Settings > Audio** and select 'Digital Stereo.'

PC / MAC SETUP

1. Connect the dongle to a USB port on the computer and power on the headset.
2. In the computer's sound settings, set the default sound output to "Lucid Sound PC Gaming Audio Interface" for game audio.
3. In the chat program being used, choose "Lucid Sound PC Chat Audio Interface" for both the Input and Output.

MOBILE

1. Connect one end of the mobile cable to the 3.5mm input on the headset and the other end to the 3.5mm output on the mobile device.
2. The headset will only work in passive (OFF) mode. (note that the volume, EQ, and mute features will not function).

Model No: LS30RX **IC:** 21203-06302
Model No: LS30TX **IC:** 21203-06301

This device complies with Industry Canada licence-exempt RSS-247 standard. Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this device must accept any interference, including interference that may cause undesired operation of the device.

IC Radiation Exposure Statement:
This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0.5 cm between the radiator and your body.

Lucid Sound, Inc.
Made in China

United States

Lucid Sound, Inc. warrants this product to be free from defects in materials and workmanship for the warranty period. This non-transferable, 1-year limited warranty is only to you, the first end-user purchaser. If a defect covered by this warranty occurs AND you provide proof of purchase, Lucid Sound, Inc., at its option, will repair or replace the product at no charge (excluding shipping to Lucid Sound).

The Lucid Sound, Inc., 1-year limited warranty is available to customers in the United States. Your sole and exclusive remedy is repair or replacement of your Lucid Sound product. In no event shall Lucid Sound's liability exceed the original purchase price of the product. This warranty does not apply to: (a) normal wear and tear or abusive use; (b) industrial, professional or commercial use; (c) if the product has been tampered with or modified.

To receive warranty service, please contact us at: **lucidsound.com**

Australia

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a 1 year replacement warranty in which you are entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

What you must do:
If a defect has appeared within 30 days from the date of purchase, the product may be returned to the retailer for a replacement.

If a defect has appeared after 30 day from the date of purchase, you must initiate a repair by following the online repair process at www.lucidsound.com.au/support.
Once all details are completed, you will receive a return authorisation number.

Then label and ship your LucidSound headset – including the return authorisation (RA) number, freight prepaid, to Lucid Sound's authorised repair centre.

LucidSound
C/o Tecworks International Pty Ltd
Unit 1 / 12 Tollis Place
Seven Hills NSW 2141
Please ensure the return authorisation (RA) number is prominently displayed on the outside of your packaging.

The cost incurred to return the product to the retailer or to the authorised repair centre as part of a Warranty claim are your responsibility.

What we will do:
During the Warranty Period, we will, at our option, repair or replace the product or any defective parts. We will also bear the reasonable costs of standard return shipping. If this cannot be done, then we will refund the purchase price to you.

AU wholesale distributor:
Bluemouth Interactive Pty Ltd, Level 2, 2 Darling Street, South Yarra, Victoria, 3141
Email: support@bluemouth.com.au