General Instructions

Please retain product label and instructions for future reference

01SHPWOR1010DDOW-V2

10X10 SHIPLAP WORKSHOP WITH DOUBLE DOOR, OPENING WINDOW, T&G ROOF & FLOOR



All building's should be erected by two adults



Winter = High Moisture = Expansion
Summer = Low Moisture = Contraction



2mm Drill bit

For ease of assembly, you **MUST** pilot drill all screw holes and ensure all screw heads are countersunk.



CAUTION
Every effort has been made during the manufacturing process to eliminate the prospect of splinters on rough surfaces of the timber. You are strongly advised to wear gloves when working with or handling rough sawn timber.

BEFORE YOU START PLEASE READ INSTRUCTIONS CAREFULLY

- Check the pack and make sure you have all the parts listed.
- When you are ready to start, make sure you have the right tools at hand (not supplied) including a Phillips screwdriver, Stanley knife, wood saw, step ladder and drill with 2mm bit.
- Ensure there is plenty of space and a clean dry area for assembly.

TIMBER

As with all natural materials, timber can be affected during various weather conditions. For the duration of heavy or extended periods of rain, swelling of the wood panels may occur. Warping of the wood may also occur during excessive dry spells due to an interior moisture loss. Unfortunately, these processes cannot be avoided but can be helped. It is suggested that the outdoor building is sprayed with water during extended periods of warm sunshine and sheltered as much as possible during rain or snow.

Our buildings are pre treated with a water based treatment**; this only helps to protect the product during transit and for upto 3 months against mould. To validate your guarantee and ensure longevity of the product, it is ESSENTIAL the building is treated with a wood preserver within the first three months of assembly and thereafter in accordance with the manufactures recommendations. Care must be taken to ensure the product is placed on a suitable base.

BUILDING A BASE

When thinking about where the building and base is going to be constructed:
Ensure that there will be access to all sides for maintenance work and annual treatment.

Ensure the base is level and is built on firm ground, to prevent distortion. Refer to diagrams for the base dimensions, The base should be slightly smaller than the external measurement of the building, i.e. The cladding should overlap the base, creating a run off for water. It is also recommended that the floor be at least 25mm above the surrounding ground level to avoid flooding.

TYPES OF BASE

- Concrete 75mm laid on top of 75mm hard-core.
- Slabs laid on 50mm of sharp sand.

Whilst all products manufactured are made to the highest standards of Safety and in the case of childrens products independently tested to EN71 level, we cannot accept responsibility for your safety whilst erecting or using this product.

Refer to the instructions pages for you specific product code

****Protim Aquatan T5 (621)****

Your building has been treated with **Aquatan**.

Aquatan is a water-based concentrate which is diluted with water, the building as been treated by the correct application of Aquatan solution and then allowed to dry.

Aquatan is a decorative finish to colour the wood, which is applied industrially to timber fence panels and garden buildings.

Aquatan *undiluted* contains: boric acid, sodium hydroxide 32% solution, aqueos mixture of sodium dioctyl sulphosuccinat and alcohols: 2, 4, 6-trichlorophenol.

For assistance please contact customer care on: 01636 880514

Mercia Garden Products Limited,
Sutton On Trent,
Newark,
Nottinghamshire,
NG23 6QN

www.merciagardenproducts.co.uk

01SHPWOR1010DDOW-V2


Please retain product label and instructions for future reference

Overall Dimensions:
Length = 3114mm
Width = 3179mm
Height = 2485mm


Base Dimensions:
Length = 3010mm
Width = 2980mm

Before assembly please make sure you have a suitable base ready to erect your building


MADE IN GREAT BRITAIN



Nail Bag



Building content




1. Front Gable Right
2. Front Gable Left
3. Front Gable Top
4. Back Gable Right
5. Back Gable Left
6. Plain Side Qty 2
7. Window Side Qty 2
8. Floor Qty 4
9. Roof Panel Qty 2

10. Door QTY 2




11. Truss Block - 160mm Qty 2
12. Gable Block - 342mm
13. Tower Catch Block - 118mm Qty 2
14. Truss



15. Door Gable Rail - 1332mm Qty 2
16. Door Gable Strip - 2552mm
17. Cover Trim - 1757mm Qty 11
18. Plain Gable Strip - 2387mm Qty 1
19. Cover Strip - 2800mm Qty 3
20. T Hinge Qty 6
21. Finial Qty 2
22. Casement stay QTY 2
23. Hasp & Staple Lock
24. Felt
25. Butt hinge QTY 4
26. Tower Bolt QTY 2
27. Plain Gable Board
28. Window QTY 2
29. Door Cloaking Strip

Pre Assembly


Remove transportation blocks from the bottom of each panel before beginning assembly. Each Panel should have two blocks.




Step 1 Door Gable Assembly

Lay the Front Gable Right and Front Gable top on a level floor place them next to each other, ensure they are level at the top then fix together using 2x50mm screws. Stagger the screws so they do not collide.

2 x 50mm screws








Step 2

Lay the Front Gable Left next to the Front Top Gable, ensure they are level at the top then fix together using 2x50mm screws. Stagger the screws so they do not collide.

2 x 50mm screws








Line the Door Gable Strip up to the assembled gable at the corners as shown in the illustration and fix in place using 40mm screws.

5x40mm Screws







Step 3 Plain Gable Assembly

Lay the Back Left Gable and Back Right Gable on a level floor place them next to each other, ensure they are level at the top and bottom then fix together using 10x50mm screws. Stagger the screws so they do not collide.

12 x 50mm screws






Turn the gable section over and secure the top board in place using 3x30mm screws. Ensure to screw into the framing, pre-drilling to avoind splitting the board.

3 x 30mm screws





Step 4

Place floor on firm and level base, ensure base has suitable drainage free from areas where water can collect. (See front page on base requirements).

Attach the floors using 32 x 40mm screws

32 x 40mm screws





Step 5

a Fix the corners with 50mm screws as shown in diagram.


b Do not secure the building to the floor until the roof is fitted.

Position the panels so there is equal spacing between the floor and cladding on all 4 sides

3x50mm Screws








Step 6


Fix the remaining window side and the splain side at the corner with 50mm screws as shown in diagram.

6x50mm Screws











Step 7

Fix the remaining plain side with 50mm screws as shown in diagram.

3x50mm Screws










Step 8

Fix the Door Gable (refer to steps 1 and 2 if you have not already assembled this) at the corners with 50mm screws as shown in diagram.

6x50mm Screws









Step 9

Fit the Door Gable Rail between the Front Gable Left and Right. Fix to the floor using 3x50mm screws. Ensure screws line up with the framing.


3x50mm Screws






Measure the length of the door gable rail and cut down a strip match.

Fix in place using 2x30mm screws.





***Cut down trims to fit**

Step 10

Using x3 strips (***No. 20***) cut two trims at **1783mm** and one strip at **1445mm**.

Place the smaller strip (***1445mm***) centrally above the door aperture (*allowing a space of 10mm between the strip and the top of the door opening*) and fix into position using 3x30mm screws.

Align the larger strips (***1783mm***) either side of the first smaller strip and fix each one into position using 3x30mm screws. This will allow a space of approximately 10mm between the trims and the opening.


****Please note: This 10mm gap allows the doors to sit onto the gable NOT into the aperture.***


Fix the T Hinges onto the front of the doors; aligning each hinge to the framing on the back of each door. Secure the doors onto the assembled gable as shown in the illustration. Ensuring that the screws go through the cladding and into the framing behind.


51x30mm Screws











Step 11

Place a Truss central to where two panels join. Align the top of the truss with the top of the sides as shown in the diagram.

Tip - Use a piece from the fixing kit as a guide.

Pencil mark the truss position and remove truss.

Place the truss blocks up to the pencil mark and fix using 2x70mm screws per block.

Place the truss back into position on top of the support block and secure using 100mm screw each side from the top down through the truss and into the block.











4x70mm Screws
2x100mm Screws







Step 12

Place a roof sheet ontop of the plain gable and truss making sure the roof sheet sits into the gables and fix using 40mm screws. Ensure there is an equal amount of overhang on either side of the roof.

12x40mm Screws






Step 13

Place the second roof sheet ontop of the truss and ensure that it butts up to the one already fixed. Following the same method outlined in step 12.

12x40mm Screws









Step 14

Once the roof is fixed attatch the building to the floor with 50 mm screws.

36 x 50mm Screws







Step 15

Cut four strips of felt and place onto the roof. See below for sizes.


Place the felt flat onto the roof in the order that is stated on the diagram below.


Once the sheets are laid out fix them onto the roof with tacks 100mm apart.


Felt Strip Sizes
3210mm

170 x felt tacks









Step 16


Fit the cover trims to the building and secure in place with 40mm screws as shown.
Fit the Plain Gable Strip where the two back gables join using 4x40mm screws.
Pre drill to avoid splitting.


28x40mm Screws



Pre drill hole







Step 17

Fit the fascias to the roof over the felt and secure in place with 40mm screws as shown.

Pre drill to avoid splitting.


Measure and trim down to size.

16x40mm Screws




Pre drill hole





***Cut down trims to fit**




Step 18


Place the Cloaking Strip to the rear of one of the doors. Fixing in position screwing through the door into the cloaking strip with 3x30mm screws.

Align the tower bolts onto the vertical framing of the slave door, secure the bolts to the top and bottom using 6x30mm black screws per tower bolt.


Mark the position of the bolt & drill a hole above and below for the bolt to catch in to.

15x30mm Black Screws





Step 19




*SCREW COUNT PER WINDOW


Place the cover strip 11mm above the window gap in the window panel and fix with 3x30mm screws per strip.

Measure and trim before fitting.


3x30mm Screws



***Cut down trims to fit**




Opening Window



If you would like the windows to be opening use the butt hinges to attach the opening window strip and the opening window together. Use 30mm screws to fix the butt hinge to the Window Strip and 16mm screws to fix it to the Opening Window.

6x30mm Screws
6x16mm Screws

Fixed Window



If you want to fix the opening windows, instead of fixing butt hinges to the opening window, use 4x30mm screws to attach the opening windows to the window panel as shown in the diagram.

4x30mm Screws

Step 20


To fix the lock in place. Screw the Staple to the Door Gable or Slave door.


Making sure the Hasp is in line with the staple and screw into the Door or Master door.

To lock the Door, place the Hasp over the Staple and twist into the lock position as shown.

8x30mm screws.










Step 21

Fix the casement stay to the opening window then align the fixings onto the window panel frame. Ensure the casement stay fits into fixings when closed before screwing them down using 12 x 20mm screws.



6x20mm screws per casement stay




AFTER TREATMENT:
score around protective
cover on glazing and
carefuly peel
covering back


It is ESSENTIAL that you apply wood
treatment immediately after the building
has been assembled.