
Capella - 5 Drawer Chest

Assembly Instructions - Please keep for future reference

262/0804
266/7788
267/5660
254/9703
227/4061
247/7284
266/5735
274/3877



Dimensions
Width - 63cm
Depth - 39cm
Height - 90.4cm

MADE IN BRITAIN

Important - Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 03456 400800**

Issue 8 - 15/01/15

Safety and Care Advice

Important - Please read these instructions fully before starting assembly

• ***Warning:*** This unit weighs approximately 27kgs.
Please lift with care.

• Check you have all the components and tools listed on pages 2 and 3.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Parts of the assembly will be easier with 2 people.

• Make sure you have enough space to layout the parts before starting.

• Do not stand or put weight on the product, this could cause damage.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor (use opened out unit carton).



• We do not recommend the use of power drill/drivers ***for inserting screws***, as this could damage the unit. Only use hand screwdrivers.

• **Safety note:** It is recommended that this unit is secured to a wall using the overbalance protector kit supplied or, an alternative fixing method of your choice.

• Dispose of all packaging carefully and responsibly.

Care and maintenance

• Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.

• From time to time check that there are no loose screws on this unit.


• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Note: If required the next page can be cut out and used as reference throughout the assembly. Keep this page with these instructions for future reference.


Components - Panels

If you have damaged or missing components, call the **Customer Helpline: 03456 400800** *quoting the reference numbers below*

Please check you have all the panels listed below




1 Left Side *(D1011A)*
(904 x 390mm)




2 Right Side *(D1012A)*
(904 x 390mm)



3 Top *(D1008A)*
(596 x 369mm)



4 Rail *(D1009A)*
(596 x 103mm) x 3



5 Drawer Front *(D1010A)*
(592 x 157mm) x 5




6 Left Drawer Side *(W370-124LH)*
(370 x 124mm) x 5




7 Right Drawer Side *(W370-124RH)*
(370 x 124mm) x 5



8 Drawer Back *(W564 - 124)*
(564 x 124mm) x 5



9 Drawer Base *(T575 - 367)*
(575 x 367mm) x 5




10 Back *(X828A)*
(622 x 807mm)

Components - Fittings


If you have damaged or missing components, call the **Customer Helpline: 03456 400800** *quoting the reference numbers below*

Please check you have all the fittings listed below


Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

A 

Wooden dowel *(F22)* x 10

B 

Metal dowel *(F901)* x 20

C 

Nail *(F51)* x 16

D 

Large locking nut *(F900)* x 10

E 

Small locking nut *(F3)* x 10

F 

Knock-in Peg *(F171)* x 20

G 

25mm Screw (*F50)* x 10

H 


9mm Screw *(F74)* x 10

I 


9mm Screw (*F73)* x 20

J 

Drawer runner *(F1004)* x 10

K 

Handle *(F930)* x 5


L Strap 

 Screw  Washer x 2

Overbalance protector kit *(F269)* x 1


M 

Wedgefix *(F639)* x 20

N 

Plastic Nail *(F91)* x 4

Tools required




Rule



Cross-head screwdriver



Scissors




Hammer



Eye protection (when using a hammer or drill)

Ruler - Use this ruler to help correctly identify the screws



Assembly Instructions


If you have damaged or missing components, call the **Customer Helpline: 03456 400800** *quoting the reference numbers below*

Step 1

Prepare the drawer fronts

Screw 2 metal dowels B into the holes shown on the back of each drawer front 5.

Note: Tighten the metal dowels up fully against the panels.




Step 2

Prepare the drawer sides

Insert a small locking nut E into the hole shown on the left drawer side 6 and right drawer side 7.

Note: The arrow on the locking nut **must** point towards the hole in the edge of the panel.

Note: Due to the manufacturing process, the holes for the locking nut can be on either surface of the drawer sides.



Step 3


Attach the drawer sides to the drawer fronts

Push the left drawer sides 6 and right drawer sides 7 onto the back of the drawer fronts 5.

Turn the small locking nuts E on the left drawer side 6 and right drawer side 7.

Note: Turn the locking nuts E clockwise to secure panels - more than 1/2 a turn.

Note: The locking nuts can be on either surface of the drawer sides. Make sure that the small groove is on the inside, as shown.




Assembly Instructions

Step 4

Fit the drawer base

Slide the drawer base 9 down the grooves in the drawer sides 6 and 7 and down into the groove in the drawer front 5.




Step 5

Fit the drawer back

Fit the drawer back 8 between the drawer sides 6 and 7.

Make sure that the drawer base 9 fits into the groove in the drawer back 8.


Hold the drawer back 8 in position and tap the knock-in pegs F through the holes in the drawer sides 6 and 7.



Step 6

Attach the handle


Attach a handle K to each drawer front 5 using 2 screws G.



Step 7

Fit the wedgefixes


Turn the large drawer assemblies over and slide 4 wedgefixes M into the front and back grooves, as shown, and tighten up the screws.



Step 8


Prepare the left side

a: Place 5 runners J on the left side 1 . Slide back the top of the runner and use the 1st hole from the front to fit the 1st screw I.




b: Slide the runner back the other way and fit the 2nd screw I into the corresponding hole in the left side 1.

Tap 2 plastic nails N into the bottom edge of the side 1.




c: Screw 5 metal dowels B into the left side 1.



Step 9


Prepare the right side

a: Place 5 runners J on the right side 2. Slide back the top of the runner and use the 1st hole from the front to fit the 1st screw I.




b: Slide the runner back the other way and fit the 2nd screw I into the corresponding hole in the right side 2.

Tap 2 plastic nails N into the bottom edge of the side 2.



c: Screw 5 metal dowels B into the right side 2.



Assembly Instructions

Step 9


Prepare10the top

Tap 4 wooden dowels (A) into the top [3] as shown.

Note: Wooden dowels **must not** stick out from the edge by more than 10mm or they may damage other panels.

Insert 4 large locking nuts (D) into the top [3] as shown.


Note: The arrow on the locking nut **must** point towards the hole in the edge of the panel.



Step 11

Join the right side and top

Push the top [3] onto the right side [2] as shown.



Use a screwdriver to tighten the 2 large locking nuts (D) fitted to the top [3].


Note: Turn the large locking nuts (D) as far as they will go - more than 1/2 a turn.

Step 12

Prepare the rails

Tap 2 wooden dowels A into each of the rails 4.

Insert 2 large locking nuts D into each of the rails 4.




Step 13

Fit the rails

Push the rails 4 onto the right side 2 as shown.

Use a screwdriver to tighten the 3 large locking nuts D fitted to the rails 4.




Note: Support these rails until the left side has been fitted in the next step.

Step 14

Fit the left side

Push the left side 1 onto the assembly.



Use a screwdriver to tighten the 5 large locking nuts D fitted to the top 3 and the rails 4 .


Step 15

Fit the back

a: Square up the unit by making sure that measurement **x to x equals y to y.**

b: Place the back 10 onto the unit. Nail C around the outside edges of the back 10.

a: The measurement from top corner X to bottom corner X must be equal to the measurement from top corner Y to bottom corner Y



Note: Nails should be spaced about 150mm apart.

Stand the unit up for the next step.

Warning: The unit is heavy. Lift with care.

Step 16

Fit the overbalance protector kit and the drawers

To prevent possible overbalancing we recommend that this unit is secured to a suitable wall by fitting of the overbalance protector kit L to the unit, or an alternative fixing method of your choice.


Wall fixings are not supplied as they will need to suit the wall type.


Note: Take care when drilling the wall that you do not drill into any pipes, wires etc.
If in doubt, consult an expert.

Starting with the bottom drawer, slide both the runners J forward and locate the drawer sides 6 and 7 between them, lining up the holes in the drawer wrap with the 2nd 'threaded' holes in the runners J.


Working from the inside of the drawer, insert 2 screws H through the drawer sides and out into the 2nd threaded hole in the runner.

Assembly is complete





Note: Do not overtighten the screws.
If they catch on the runner you may need to loosen them slightly.



If you need help or have damaged or missing parts, call the **Customer Helpline: 03456 400800**
and quote the reference numbers on the component pages.
Argos Ltd, 489-499 Avebury Boulevard, Central Milton Keynes, MK9 2NW