

ASSEMBLING INSTRUCTIONS

CAUTION :

THIS ITEM IS MADE OF LAMINATED PARTICLE BOARD AND MEDIUM DENSITY FIBRE BOARD TO BE ASSEMBLED ON A DRY, SOFT, SMOOTH AND CLEAN SURFACE . DO NOT USE DETERGENT OR CHEMICAL. AVOID DAMP AND DIRECT SUNLIGHT.

STEP 1	CHECK YOUR HARDWARE	H-ST116
	FLAT HEAD SCREW M6 X 40	4 PCS
	WOOD DOWEL M8 X 25	32 PCS
	WOOD DOWEL M6 X 25	6 PCS
	HOUSING D:15/12.5MM	16 PCS
	HOUSING D12/9.5MM	4 PCS
	EURO BOLT	20 PCS
	PAN HEAD SCREW 3.5 X 13MM	8 PCS
	L-BRACKET	2 PCS
	SCREW CAP	4 PCS
	ALLEN KEY	1 PC

TOOLS REQUIRED:

	HAMMER		SCREW DRIVER
--	--------	--	--------------

STEP 2

WOOD DOWEL M8 X 25

WOOD DOWEL M6 X 25

STEP 3

EURO BOLT

STEP 4

PAN HEAD SCREW 3.5 X 13MM

L-BRACKET

HOUSING D:15/12.5MM

TURN TO LOCK

STEP 5

HOUSING D12/9.5MM

DETAIL A

TURN TO LOCK

STEP 6

HOUSING D:15/12.5MM

DETAIL A

TURN TO LOCK

STEP 7

PAN HEAD SCREW 3.5 X 13MM

L-BRACKET

STEP 8

FLAT HEAD SCREW M6 X 40

STEP 9

STEP 10

FLAT HEAD SCREW M6 X 40

STEP 11

HOUSING D:15/12.5MM

DETAIL A

TURN TO LOCK

STEP 12

SCREW CAP

DETAIL A

STEP 13