

ASSEMBLING INSTRUCTIONS

CAUTION :

THIS ITEM IS MADE OF LAMINATED PARTICLE BOARD AND MEDIUM DENSITY FIBRE BOARD TO BE ASSEMBLED ON A DRY, SOFT, SMOOTH AND CLEAN SURFACE . DO NOT USE DETERGENT OR CHEMICAL. AVOID DAMP AND DIRECT SUNLIGHT.

STEP 1	CHECK YOUR HARDWARE	H6343
	SCREW #9 X 1 1/2"	12 PCS
	SCREW M3.5 X 25	4 PCS
	SCREW M3.5 X 12	24 PCS
	HOUSING D:12/9.5MM	8 PCS
	HOUSING D:15/12.5MM	17 PCS
	EURO BOLT	25 PCS
	WOOD DOWEL M8 X 25	24 PCS
	SCREW M3.5 X 14	16 PCS
	SQUARE KNOB	4 PCS
	TRUSS HEAD SCREW M4 X 22	4 PCS
	SCREW M3 X 20	4 PCS
	CORNER BLOCK	4 PCS
	METAL RUNNER	2 SETS
	METAL HINGES	4 SETS

TOOLS REQUIRED :

	HAMMER		SCREW DRIVER
--	--------	--	--------------

STEP 2

WOOD DOWEL M8 X 25

DETAIL A

1 2 4 5 12 13

6 7 9 10

DETAIL A

STEP 3

DETAIL A

1 2 3 5 9 10 16

EURO BOLT

DETAIL A

STEP 4

DETAIL A

1 2

DETAIL B

RIGHT VIEW

5

LEFT VIEW

5

DETAIL C

DETAIL D

SCREW M3.5 X 12

METAL RUNNER

DETAIL A

DETAIL B

DETAIL C

DETAIL D

STEP 5

HOUSING D:15/12.5MM

DETAIL A

1 2 9 10

TURN TO LOCK

STEP 6

DETAIL A

14

DETAIL B

15

TRUSS HEAD SCREW M4 X 22

SCREW M3.5 X 14

SQUARE KNOB

DETAIL A

DETAIL B

STEP 7

HOUSING D:12/9.5MM

DETAIL A

17

18

16

TURN TO LOCK

STEP 8

18

20

16

STEP 9

19

17

18

SCREW #9 X 1 1/2"

STEP 10

DETAIL A

17

18

SCREW M3.5 X 12

METAL RUNNER

DETAIL A

STEP 11

TRUSS HEAD SCREW M4 X 22

DETAIL A

16

SQUARE KNOB

STEP 12

SCREW M3.5 X 25

13

11

STEP 13

SCREW #9 X 1 1/2"

11

4

STEP 14

TOP

5

4

SCREW #9 X 1 1/2"

STEP 15

SCREW #9 X 1 1/2"

TOP

5

STEP 16

HOUSING D:15/12.5MM

TOP

DETAIL A

11

12

4

1

TURN TO LOCK

STEP 17

HOUSING D:15/12.5MM

TOP

DETAIL A

7

5

TURN TO LOCK

STEP 18

HOUSING D:15/12.5MM

TOP

DETAIL A

7

2

11

12

4

1

TURN TO LOCK

STEP 19

8

2

5

1

STEP 20

HOUSING D:15/12.5MM

3

2

5

1

TURN TO LOCK

STEP 21

8

8

5

1

CORNER BLOCK

DETAIL A

SCREW M3 X 20

STEP 22

SCREW M3.5 X 14

METAL HINGES

FOR DOOR ADJUSTMENT (BACKWARDS OR FOREWORDS)

FOR DOOR ADJUSTING THE DOORS GAP

1

14

2

15

DETAIL A

STEP 23

16

16