

ASSEMBLING INSTRUCTIONS

CAUTION :

THIS ITEM IS MADE OF LAMINATED PARTICLE BOARD AND MEDIUM DENSITY FIBRE BOARD TO BE ASSEMBLED ON A DRY, SOFT, SMOOTH AND CLEAN SURFACE . DO NOT USE DETERGENT OR CHEMICAL. AVOID DAMP AND SUNLIGHT.

STEP 1	CHECK YOUR HARDWARE	8332	STEP 5	HOUSING D:12/9.5MM	STEP 6	STEP 7	
	SCREW #9 X 1 1/2"	12 PCS					
	SCREW M3.5 X 12	36 PCS					
	HOUSING D:12/9.5MM	12 PCS					
	HOUSING D:15/12.5MM	13 PCS					
	EURO BOLT	25 PCS					
	WOOD DOWEL M8 X 25	13 PCS					
	WOOD DOWEL M6 X 25	14 PCS					
	SQUARE KNOB	3 PCS					
	TRUSS HEAD SCREW M4 X 20	3 PCS					
	SCREW M3 X 20	4 PCS					
	CORNER BLOCK	4 PCS					
	METAL RUNNER	3 SETS					
TOOLS REQUIRED : HAMMER SCREW DRIVER			STEP 8 				STEP 9
STEP 2 			STEP 10 				STEP 11
STEP 3 			STEP 12 				STEP 13
STEP 4 			STEP 14 				STEP 15