


# Bathroom Cabinet

Assembly Instructions- please keep for future reference

833/3566



## Dimensions

Width - 45cm

Depth - 15cm

Height - 55cm

**Important** – Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline: 0845 640 0800**



## Safety and Care Advice

**Important – Please read these instructions fully before starting assembly**

- Check you have all the components and tools listed on pages 1 and 2.
- Remove all fittings from the plastic bags and separate them into their groups.
- Keep children and animals away from the work area, small parts could choke if swallowed.
- Make sure you have enough space to layout the parts before starting.

- Do not stand or put weight on the product, this could cause damage.
- Assemble the item as close to its final position (in the same room) as possible.
- Assemble on a soft level surface to avoid damaging the unit or your floor.
- Parts of the assembly will be easier with 2 people.




- We do not recommend the use of power drill/drivers **for inserting screws**, as this could damage the unit. Only use hand screwdrivers.
- Dispose of all packaging carefully and responsibly.

### Care and maintenance


- Only clean using a damp cloth and mild detergent, do not use bleach or abrasive cleaners.
- From time to time check that there are no loose screws on this unit.
- This product should not be discarded with household waste. Take to your local authority waste disposal centre.

# Components - Panels


Please check you have all the panels listed below




**1** Top x 1  
(45(w)cm x 13.5(d)cm)




**2** Bottom x 1  
(45(w)cm x 13.5(d)cm)




**3** Left side x 1  
(52(h)cm x 13.5(d)cm)




**4** Right side x 1  
(52(h)cm x 13.5(d)cm)




**5** Back right x 1  
(52(h)cm x 16(w)cm)




**6** Shelf x 2  
(15.8(w)cm x 12(d)cm)



**7** Internal shelf x 2  
(25.2(w)cm x 12(d)cm)



**8** Back x 1  
(52.8(h)cm x 26.3(w)cm)
















**9** Door x 1  
(28(w)cm x 55(h)cm)

# Components - Fittings

If you have damaged or missing components,  
call the **Customer Helpline: 0845 640 0800**

Please check you have all the fittings listed below


**Note:** The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.

<b>A</b>  35mm Male camlock x 10	<b>B</b>  Female camlock x 10	<b>C</b>  30mm Wooden dowel x 6
<b>D</b>  Hinge x 2	<b>E</b>  10mm Screw x 9	<b>F</b>  Shelf bracket x 8
<b>G</b>  Magnetic catch x 1	<b>H</b>  14mm Screw x 2	<b>I</b>  Magnetic catch plate x 1
<b>J</b>  35mm Screw x 4	<b>K</b>  Washer x 4	<b>L</b>  45mm Screw x 4
<b>M</b>  Rawl plug x 4		

## Tools required



Phillips screwdriver  
(medium & large)



Drill (for wall drilling only)

Ruler – Use this ruler to help correctly identify the screws




# Assembly Instructions

## Step 1


Insert 5 x male camlock **A** and 1 x 30mm wooden dowel **C** into underside of top **1** and top side of bottom **2** as shown.

Fix magnetic catch **G** to underside of top **1** using 2 x 14mm screw **H** as shown (see **a:**).




## Step 2

Insert 4 x female camlock **B** into left side **3** and right side **4** as shown.



## Step 3


Insert 2 x female camlock **B** into rear of back side **5** as shown.



# Assembly Instructions


## Step 4

Insert 2 x 30mm wooden dowel **C** into 2 x shelf **6** as shown.




## Step 5

Fix 2 x shelf **6** to back right **5** using 2 x 35mm screw **J** as shown.



## Step 6


Fix assembly completed in Step 5 to right side **4** using 2 x 35mm screw **J** as shown.



## Step 7

Connect left side **3** and assembly completed in Step 6 to bottom **2** as shown.


Tighten female camlocks with a screwdriver as shown (see **b:**).



# Assembly Instructions

## Step 8


Slide back panel **8** into slots of left side **3** and right side **4** as shown.



## Step 9

Connect top **1** to top of assembly completed in Step 8

Tighten female camlocks in left side **3** and right side **4** with a screwdriver as shown (see Step 7 **b**).




# Assembly Instructions

## Step 10

Fix door **9** to unit as shown using 2 x hinge **D** and 8 x 10mm screw **E** as shown (see **C**).


Fix magnetic catch plate **I** to inside of door using 1 x 10mm screw **E**.



## Step 11

Insert 8 x shelf bracket **F** into holes inside unit at desired height.

Set 2 x internal shelf **7** onto shelf brackets as shown.





# Assembly Instructions

## Step 12

Fix unit to wall using 4 x 45mm screw **L**, 4 x washer **K** and 4 x rawl plug **M** as shown.

**Note:** see the back cover for more information on wall mounting and the suitable use of the supplied rawl plugs.




**Warning:**  
Before drilling,  
check wall for  
hidden pipes  
and cables.



**Warning:**  
The unit is  
heavy; seek  
assistance from  
another person.

**Assembly complete.**







# A Guide to Wall Mounting & Fixings

## Important note:

If plastic wall plugs (rawl plugs) are supplied with your product, e.g.:



- these are only suitable for use in masonry walls.

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.

Failure of the product due to using the incorrect fixings is the responsibility of the installer.



**Important:** when drilling into walls always check that there are no hidden wires or pipes etc.

**Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.**


### Hints:

- 1: General rule: always use a larger screw and wall plug if you are not sure.
- 2: Ensure you use the recommended drill bit to match the wall plug and hole size.
- 3: Ensure you drill the hole horizontally; do not force the drill or enlarge the hole.
- 4: Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.
- 5: Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

## Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

### No.1 "General Purpose" wall plug




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

### No.3 "Cavity Fixing" wall plug




For use with plasterboard partitions or hollow wooden doors.

### No.5 "Hammer Fixing" wall plug




For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

### No.2 "Plasterboard" wall plug




For use when attaching light loads onto plasterboard partitions.

### No.4 "Cavity Fixing - Heavy Duty" wall plug



For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

### No.6 "Shield Anchor" wall plug - heavy loads



For use with heavier loads such as TV and HiFi speakers and satellite dishes etc.



## Care & Maintenance

**Safety:** always check the fitting and location to ensure your safety in and around the home.

**Fitting:** from time to time check the fitting to ensure the wall plugs or screws do not become loose.

If you need help or have damaged or missing parts, call the **Customer Helpline: 0845 640 0800**