

SAVE THESE IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions before using this appliance.

These instructions are also available on our website. Please visit www.hot-europe.com



WARNING: Do not use this appliance near bathtubs, showers, basins or other vessels containing water.

WARNING: This appliance must not be taken into the bathroom.

This appliance can be used by children aged from 8 years and above, and by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.

Children shall not play with the appliance.

Cleaning and user maintenance shall not be made by children without supervision.

If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard.

WARNING: Do not leave the appliance unattended. Do not allow bare skin or the eyes to come into contact with any heated surface on the appliance when in use. Do not place the appliance on any heat-sensitive surfaces when hot or plugged into the mains. Always unplug the appliance when not in use.

WARNING: Do not use this appliance on synthetic hair or wigs.

NOTE: Use on dry hair only.

WARNING: Should this product malfunction, do not attempt to repair it. This appliance has no user-serviceable parts or components.

This product carries the CE mark and is manufactured in conformity with the Electromagnetic Directive 2014/30/EU, the Low Voltage Directive 2014/35/EU, the ROHS Directive 2011/65/EU and the Energy and using Products Directive 2009/125/EC.

GUARANTEE AND SERVICE SECTION:

Your Revlon appliance is guaranteed against defects under normal use for 4 years from the original date of purchase. If your product does not perform satisfactorily because of defects in materials or manufacture, within the warranty period, it will be replaced. Please retain your receipt or other proof of purchase for all claims within the warranty period. The guarantee becomes void if the proof of purchase is not presented. For all claims within the warranty period please contact our Support Team.

This guarantee does not cover defects which have occurred due to misuse, abuse, or are caused by failure to follow the instructions contained within this manual. This does not affect your consumer statutory rights. The manufacturing date is given by the 4 digit Batch Number marked on the rear of the product. The first 2 digits represent the week of manufacture, and the last 2 digits represent the year of manufacture. Example: 3418 - product manufactured week 34 of the year 2018.

For product support, please visit us at:

www.hot-europe.com/support

Or contact us by phone:

+44 (0) 115 965 7430

For product information, visit us at:

www.revlonbeautycare.com



This appliance complies with EU legislation 2012/19/EU on end of life recycling. Products showing the 'Crossed Through' wheeled bin symbol on either the rating label, gift box or instructions must be recycled separately from household waste at the end of their useful life.

Please DO NOT dispose of appliance in normal household waste. Your local appliance retailer may operate a 'take-back' scheme when you are ready to purchase a replacement product, alternatively contact your local government authority for further help and advice on where to take your appliance for recycling.

120-240V – 50-60Hz 50W

The REVLON® trademark is used under license from Revlon, by Helen of Troy Limited.

Made in China.

European Headquarters

Kaz Europe Sàrl, Place Chauderon 18, CH-1003 Lausanne, Switzerland.

HOT (UK) Ltd, 1-4 Jessops Riverside, 800 Brightside Lane, Sheffield, S9 2RX United Kingdom.

©2018 Revlon. All rights reserved. (AW011251)

AW ISSUE No#: 1 Date: 01.16.18

REVLON®



**SALON ONE-STEP
STRAIGHT AND
SHINE
XL HEATED BRUSH**

RVST2168UK



OPERATING INSTRUCTIONS

This appliance is intended for household use only.
The appearance of this appliance may differ from the illustration.
Only use this appliance for its intended purpose as described in this manual.

ADVANCED CONDITIONING IONIC TECHNOLOGY™ - Super Ion Generator is designed to give maximum frizz control, delivering a constant stream of ions for brilliant shine and manageability.

ADVANCED 3X CERAMIC COATING - Provides superior even heat distribution for fast styling results.

MULTI-DIMENSIONAL COMBS AND DETANGLING BRISTLES - Gently glide through hair and get close to the roots, protecting hair from over-styling and locking in moisture, delivering silky, smooth results.

SMART HEAT MEMORY SYSTEM - State-of-the-art design automatically recalls the last temperature as your preferred heat setting.

OPERATING THE IONIC GENERATOR - Immediately after turning on the styler, you'll hear the gentle crackling of millions of ions that are quickly neutralizing frizz and maximizing sheen for strand softness and manageability. The Ionic Generator releases a flow of powerful static-fighting ions that help to smooth and straighten your hair for a polished, brilliant shine.

STYLING - Plug the power supply cord into a mains socket. To turn the appliance on press the "On / Off" Button. The digital display will turn on and display the temperature setting. To increase the heat setting, press the "+" button. The LCD screen will display the temperature setting. To lower the heat setting, press the (-) button. Once the temperature is selected the temperature setting will blink for 30 seconds. Once the temperature becomes solid the appliance is ready to use. For best results follow the temperature guidelines below:

Hair Type	Temperature °C
Fine thin hair	120 - 140
Medium to wavy hair	140 - 170
Curly to thick hair	170 - 190
Coarse, hard-to-style-hair	190 - 210

Your appliance will remember the previously selected heat temperature the next time the unit is turned on.
IMPORTANT: The high-performance heater in this unit contains an oil-based protective coating that will burn off during the first few minutes of initial use and may emit smoke and/or an odor. You may also hear a humming noise during use. This is normal and is not a cause for concern.

STYLING TIPS - The Salon One-Step Heated Brush should be used only on clean, dry hair. Dry hair completely before styling. Before using this appliance, detangle hair by brushing or combing. Style hair as desired by brushing hair with Salon One-Step Straight and Shine™ XL Heated Brush. No need to section your hair. The ceramic comb and detangling bristles glide easily throughout your hair, including the back of your head. Use the Ribbed Exterior Housing to create flips or curl under ends. To create more volume and body, simply wrap hair around housing. The ribbed exterior will guide hair, creating the desired volume.

AUTOMATIC SHUT-OFF - Your appliance has an Automatic Shut-off feature. Should you forget to turn off the appliance, it will automatically shut off after one hour.

AUTOMATIC WORLDWIDE DUAL VOLTAGE - This appliance will automatically adjust to the correct voltage.

CLEANING - Always unplug the appliance from the mains after use and allow it to cool before cleaning. To clean, wipe the appliance and plates with a damp cloth. Make certain the appliance is completely dry before using. Keep heated surfaces clean and free of dust, dirt, styling sprays and gels.

STORAGE - Always unplug when not in use.

Allow the appliance to cool before storing. Always store in a dry location. Do not pull or twist the cord. Do not wrap the cord around the appliance, as this may cause the cord to wear prematurely and break. Regularly check the power cord for wear and damage (particularly where it enters the appliance and the plug).

FEATURES

- A. DETANGLING BRISTLES
- B. CERAMIC COMBS
- C. SAFETY GUARD
- D. THUMB REST
- E. HEAT READY INDICATOR
- F. LCD DIGITAL TEMPERATURE DISPLAY
- G. ON/OFF BUTTON
- H. PROFESSIONAL SWIVEL CORD
- I. WORLDWIDE VOLTAGE
- J. SOFT-FEEL™ HANDLE
- K. SEPARATE TEMPERATURE BUTTONS
- L. IONIC GENERATOR
- M. 11.5CM STYLING CURVED SURFACE

