


What's in the box



Fire tablet




USB-C cable
(for power)




Power adapter

Fire HD 8 Plus overview



1. Volume up/down
2. Power button
3. Microphone
4. USB-C port
5. Headphone jack
6. Rear camera
7. Speakers
8. Front camera
9. microSD slot (card sold separately)


Getting started




3. Follow the on-screen prompts to connect to a wifi network, then sign into an existing account or register to create a new account.

Charging your tablet

Option 1: USB-C



Option 2: Wireless charging



(Wireless charging stand sold separately)

For troubleshooting tips and Amazon Customer Service, visit www.amazon.com/devicesupport.