


HAB JERICHO SOLID MANGO DINING TABLE

Assembly Instructions - Please keep for future reference

Cat. Number: 1482830

Dimensions

L x W x H
120 X 120 X 75cm



Important - Please read these instructions before assembly

If you help or damaged or missing parts, email:
customerservices@habitat.co.uk or call: 0344 499 4686

habitat 



Safety and Care Advice

Product Detail

Cat Number - 1482830


Dimension - L x W x H

120 X 120 X 75cm

IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.

Keep children and animals away from the work area, small parts could choke if swallowed.

Assemble the item as close to its final position [in the same room] as possible.



We do not recommend the use of power drill/ drivers for inserting screws, as this could

Make sure you have enough space to layout the parts before starting.

Assemble on a soft level surface to avoid damaging the unit or your floor.

damage the unit. Only use hand screwdrivers.

This product has been constructed to be used in the domestic environment only and not for commercial purposes.

Parts of the assembly will be easier with 2 people.

Dispose of all packaging carefully and responsibly.

General care and maintenance

Only clean using a damp cloth and mild detergent. Do not use abrasive cleaners.

From time to time check that there are no loose screws, nuts or bolts. If there are please re-tighten.

This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Use a dry cloth to clean the product, furniture polish is not recommended.

Glue safety - Take care when using glue, Please follow the advice below

Skin contact: Remove contamination by washing with soap and water procedure should also be followed prior to eating and drinking.

Eye contact: Rinse immediately with clean water for 15 minutes and seek medical advice.

If swallowed: Seek medical advice immediately.

Additional Guidance


1. Assemble all parts and bolts loosely during assembly. only once the product is complete should you fully tighten the bolts.
2. Regularly check and ensure that all bolts and fittings are tightened properly.
3. Age recommendation for upper bunk 6+
4. Maximum user weight 110kg.
5. This product is compliant 12521.

Sainsbury's Argos is a trading name of both: Argos Limited, Registered office: 789-499 Avebury Boulevard, Milton Keynes, United Kingdom, Mk9 2NM, registered number: 01081551 (England and Wales); and Sainsbury's Supermarket Limited, Registered office: 33 Holborn, London, EC1N 2HT, registered number: 03261722 (England and Wales). companies are subsidiaries of J Sainsbury's plc.

1

Fitting

L Key Bolt Large



6 x 16mm, 6+1pcs

L Key




5x32mm, 1pc

2


Hardware

Wooden Top



1pc

Bottom frame



1pc

Parts Description:


A - Wooden Top

B - Bottom frame


Step 1 : Place Wooden Top in upside down position and attach bottom frame, align both frames with Allen Bolts holes and secure with Allen Bolts as shown in below image.

Step 2 : Move Dining Table in upright position, Product is ready to use.

Note : Match the sticker code from base to top and align the pre drilled holes as illustrated (AA,BB,CC,DD).



Assembly is completed and product is ready to use.



Step 2