Lenovo Tab P11

User Guide

Lenovo TB-J606F

Lenovo TB-J606L

All information labeled with * in this guide refers only to the WLAN+LTE model (Lenovo TB-J606L).

Basics

Before using this information and the product it supports, be sure to read the following:

- *Safety, Warranty & Quick Start Guide*
- *Regulatory Notice*
- "Important safety and handling information" in "Appendix".

The *Safety, Warranty & Quick Start Guide* and the *Regulatory Notice* are available on the website at http://support.lenovo.com.

Note: All pictures and illustrations in this document are for your reference only and may differ from the final product.

Lenovo Help

Looking for help? The Lenovo Help app can offer you support for getting direct access to Lenovo's web assistance and forums*, frequent Q&A*, system upgrades*, hardware function tests, warranty status checks*, service requests**, and repair status**.

Note:

**** requires data network access.***

***** is not available in some countries.***

You have two ways to get this app:

- Search for and download the app from Google Play.



- Scan the following QR code with a Lenovo Android device.



Technical specifications

Model	Lenovo TB-J606F	Lenovo TB-J606L
CPU	Qualcomm® Snapdragon™ 662	Qualcomm® Snapdragon™ 662
Battery	7500mAh	7500mAh
Wireless communication	Bluetooth 5.1; WLAN 802.11 a/b/g/n/ac; GPS/GLONASS/A-GPS	Bluetooth 5.1; WLAN 802.11 a/b/g/n/ac; GPS/A-GPS/GLONASS; FDD-LTE/TDD-LTE/WCDMA/GSM

Note: Lenovo TB-J606L supports LTE Bands 1,2,3,4,5,7,8,20,28,38,40,41 but in some countries LTE is not supported. To know if your device works with LTE networks in your country, contact your carrier.

Home screen

The home screen is the starting point for using your device. For your convenience, the home screen is already set up with some useful apps and widgets.



> ***Note: Your device's features and the home screen may be different depending on your location, language, carrier, and device model.***

You can customize your home screen at any time.

- **Home screen**
  On the default home screen, there is a **Google** Search bar and some useful apps.
- **Home Settings**
  Press and hold anywhere on the home screen except the icons. Tap , and then modify Home settings.
- **Add a widget to a home screen**
  Press and hold anywhere on the home screen except the icons. Tap , press and hold the widget you want to add, then drag it to where you want to place it, and release.
- **Change the wallpaper**
  Press and hold anywhere on the home screen except the icons, tap **Wallpapers**, and then choose your preferred wallpaper.
  Go to **Settings** > **Display** > **Wallpaper** and choose your preferred wallpaper.
- **Move an app to another screen**
  Press and hold an app that you want to move, drag it to where you want to place it, then release.
- **Uninstall an app**
  1. Press and hold the app that you want to uninstall.
  2. Drag to , and then release and tap **OK**.

Note: Some of the system apps cannot be uninstalled.

Navigation bar

Screen buttons

There are three buttons at the bottom of the screen by default.


- Go back button: Tap ◀ to go back to previous page.
- Home button: Tap ● return to the home screen.
- Switch apps button: Tap ■ to display all the recent apps. You can do any of the followings:
  - Tap one app to start it.
  - Swipe an app window up to close it.
  - Swipe an app window down to lock or unlock it.
  - Tap **Clear all** to stop running all unlocked apps.

Set up navigation bar

Go to **Settings** > **Display** > **System navigation**, you can select **Gesture navigation**, **2-button navigation** or **3-button navigation**.

Notifications and Quick Settings

The Notifications panel informs you of new messages, bluetooth sharing, and activities in progress such as file downloading. The Quick Settings panel allows you to access frequently-used settings such as the WLAN switch.




You can do any of the following:

- To see notifications, swipe down from the top of the screen.
- To close the Notifications panel, swipe up from the bottom of the screen.
- To dismiss a notification, swipe left or right across the notification.
- To dismiss all notifications, tap **CLEAR ALL** at the bottom of the Notifications panel.
- To open the Quick Settings panel, swipe down from the top of the screen twice.
- To quickly turn common functions on and off,click the appropriate icon.

- To close the Quick Settings panel, swipe up from the bottom of the screen.

Split screen



Click the ■ in the navigation bar to view the list of recently used apps, long press the app icon above the screen, and then tap ▭ **Split screen**, and then select another one app to achieve the split screen.
Note: Not all applications support split screen mode.

- **Split screen settings**
  In split screen mode, you can do the following:
  - **Adjust the split screen size**
    Slide the | in the middle of the two screens to adjust the split screen size.
  - **Replace the second application**
    Tap ▭ to choose another apps.
- **Exiting split screen mode**
  You can exit split screen mode：
  - Choosing an app that doesn't support split screen mode.
  - Sliding the | to the edge of the screen.


Force shutdown/reboot

Press and hold the Power button for about 8 seconds until the device turns off, press and hold the Power button for about 10 seconds to reboot.

Productivity Mode

The productivity mode supports multiple windows on the screen at the same time if the productivity mode is enabled. The productivity mode is off by default.

Set up the productivity mode



- **Turn on the productivity mode**
  - Go to **Settings** > **Productivity Mode** to turn on the switch.
  - Connect to physics keyboard or mouse to enable the productivity mode automatically.
- **Turn off the productivity mode**
  - Go to **Settings** > **Productivity Mode** to turn off the switch.
  - Remove the physics keyboard or mouse.


Customized navigation bar



When entering the productivity mode, the navigation bar changes to the productivity mode navigation bar.

- **Application icon management**
  - Icon • • • will exist on the navigation bar if it can not display the whole application icon.
  - Drag the app icon to adjust the order.
- **Close application**
  - Long press the app icon and drag the app icon upwards until **Close application** appears.
  - Long press or right click the app icon and then tap **CLOSE APPLICATION**.
- **Pin the application to system navigation**
  - Long press or right click the app icon and then tap **PIN TO SYSTEM NAVIGATION**.
- **Shortcuts options**
  - Long press or right click the app icon and then tap shortcuts options.

Multi-windows



When entering productivity mode, you can adjust the window size and window location. The optimal number of windows displayed at the same time are three to five windows.

Open an app, you can do any of the followings:
Note: Some apps may affect the user experience in productivity mode.

- Double tap the title bar to switch between the window mode and the full screen mode.
- Drag the side of a window to adjust its size. The traceable area shows a highlighted border. If the windows size reaches its smallest, the border shows a warning color.
  Note: Some apps cannot support this feature.
- To move a window, tap and hold the title bar and then drag it to anywhere you want.

Using the keyboard

After the keyboard is connected to the tablet, you can use the keyboard to input to enhance the user experience.

Multi-User

Multi-User Preferences

There are three user types:

- **Owner:** An owner has full control over all user permissions and manages all user accounts.
- **Guest:** There is only one Guest account. A Guest has restricted access to the device.
- **New User:** There can be multiple user accounts, and the additional users can share the device with the owner.

Creating new user accounts

Tap **Settings** > **Accounts** > **Multiple users** > **Add user or profile** to create user accounts.
Select **Add** > **User** to create additional users, and then follow the on-screen instructions.

Switching between user accounts


- Swipe down from the top of the screen, and then tap the users icon to switch between different user accounts.
- On the lock screen interface, select the user icon you want to switch to, then tap and switch to the other account.

Deleting a user account

Tap **Settings** > **Accounts** > **Multiple users**, and tap the  icon located beside the account you would like to delete, then tap **DELETE**.

Camera

To open the Camera app, go to **Camera**.



Taking photos and videos

You can take photos and record videos with your device's built-in camera.

- Tap to take a photo.
- Tap to switch between the front and the rear camera.
- Tap to configure the other camera settings.
- Tap to delay shooting.
- Tap to set a filter.
- Tap to set flash settings.
- Tap **Video** to switch to video, and tap to record a video.

Taking screenshots

Press and hold the **Power** and the **Volume down** buttons at the same time to take a screenshot.

Viewing pictures and videos

Photos and videos are stored in your device's internal storage. You can view your photos and videos by using the following methods:

- Tap the photo just taken when using the **Camera** app, and then tap  to go to **Google Photos**.
- Open the **Google Photos** app or the Files app to view your photos and videos.

Network

You need to set up a wireless network before connecting to the Internet.

- Set up a WLAN network.
- *Set up a mobile network.
- Set up a VPN network.

You can also share your mobile network with others.

- *Set up a hotspot.

Setting up a WLAN network

Go to **Settings > Network & internet > WLAN**. Turn on the WLAN switch and tap a WLAN hotspot in the list to connect to the Internet. When you are connecting to a secure hotspot, you need to enter a password to connect.

*Setting up a mobile network

Go to **Settings > Network & internet > Mobile network**.

Note: You need a valid SIM card with data service. If you don't have a SIM card, contact your carrier.

Setting up a VPN network

VPNs are used within organizations to allow you to communicate private information securely over a non-private network. You may need to configure a VPN, for example, to access your work email. Ask the network's administrator for the settings necessary to configure a VPN for your network.

1. Go to **Settings > Network & internet > VPN**.
2. Tap + to edit the VPN profile, including the name, type, and server address, and then tap **SAVE**.
3. Tap the VPN server name, enter the username and password, and then tap **CONNECT** to connect to the VPN network.
4. Tap ⚙ to edit or delete the VPN.

Setting up a hotspot

You can use a personal hotspot to share an Internet connection with a computer or other device.

Go to **Settings > Network & internet > Hotspot & tethering** and do the following:


*Tap **WLAN hotspot** to configure the hotspot.

You can also use **Bluetooth tethering** or ***USB tethering**.

Note: Tell your friends the Network name and password and then they can connect to your network.

Internet

You can browse the web if your device is connected to a wireless network or a cellular network.
To open the browser app, go to **Chrome**.



Visiting websites

You can use the **Chrome** app to visit websites.

- **Type a web address**
  You don't need to type the full web address of an "http://" website to access it.
  To visit "http://www.lenovo.com", simply type "www.lenovo.com" into the address bar and Tap .
- **Search for keywords**
  You can also type keywords into the address bar to search for webpages.
  You can set a search engine in > **Settings** > **Search engine**.
- **Add a new webpage**
  Tap > **New tab** to add a new webpage tab.
  Tap > **New incognito tab** to visit a website without leaving any traces of your visit.
- **Close a webpage**
  Tap to close a webpage tab.
- **Refresh a webpage**
  Tap to refresh a webpage.

Tap ← to return to the previous webpage.

Tap → to go forward to a recent webpage.

Saving webpages

You can save images and webpages in your device's internal storage.

- **Save images**

  Press and hold the image, then tap **Download image**.
- **Bookmark webpages**

  Tap ☆ to add a webpage to **Bookmarks**.

  Tap ⋮ > **Bookmarks** to view bookmarks.

Setting accessibility preferences


Tap ⋮ > **Settings** > **Accessibility** to set the **Text scaling**, **Force enable zoom, Simplified view for web pages** and **Captions**.

Gmail

You can send and receive emails if your device is connected to a wireless network.
To access the **Gmail** app, go to **Gmail**.

Setting up a Gmail account

You can sign into Gmail if you have a Gmail account. If not, you will need to create a Gmail account.
You can also sign in with email accounts provided by other companies.



Using Gmail


After setting up your gmail account, you can use the **Gmail** app to send and receive emails.

Maps

You need to select the following settings before you can use **Maps**.
Go to **Settings > Location** and enable location access for Google apps, the default is on.

Finding a location

Type the address that you want to find, then press **Search here**.




You can also tap to speak the address you want to search for.

Current location

Tap to see your current location.
Then tap **Explore nearby** to check what is nearby.

Planning a route

Tap and type in "**Your location**" and "**Choose destination**", or just choose the starting point as "**Your location**".
Choose the travel mode: by car, by bus, by bike or on foot.



10:00 AM
Your location
Choose destination
Take the shortcut
Save home and work for faster directions
SIGN IN
ZHOUSONGCUN
周宋村
Barbecue Gigot
烤羊腿
LAOYANZHUANGCUN
老烟庄村
XIZHANG
HUZHAI
西漳浒寨
ZHANGHUZHAICUN
漳浒寨村
Sichuan Food
川味小炒
Tiangu 7th Rd
Xi'an Hi-tech Zone
Huanpu Industrial Park
西安高新区环普产业园
HONGMIAO
红庙
HONGMIAOCUN
红庙村
Haokoufu
好口福餐饮
XIAOCAOLICUN
小曹里村
Keji 8th Rd
ONGJIAOCUN
东焦村
HUANGSHA
MOUNTAIN
黄沙岭
Nanzheng Ave
Traveling Bestone
International Travel...
ZHAKOUCUN
闸口村
BEILING
北岭
Zhangba W Rd
Sichuan Flavor
Fried Dishes
川味炒菜
ZHANGBAXICUN
丈八西村
Jinye Rd
Mingxuan Complex Shop
明宣综合商店
©2021 Google

Sync

You can transfer data between your device and computer such as music, pictures, videos, documents, Android application package (APK) files, and so on.

Connecting your device to your computer

Connect your device and computer using a USB cable.
Slide down from the top of the screen. You will see "**Charging this device via USB**" in the notifications bar.
Tap **Charging this device via USB** to view other options.



Selecting the computer connection mode

You can select one of the following options:

- **File Transfer**: Select this mode if you want to transfer files between your tablet and computer.
- ***USB tethering**: For shared network.
- **MIDI**: Select this mode if you want MIDI-enabled apps on your device to work with MIDI software on the computer.
- **PTP**: Select this mode if you only want to transfer only photos and videos between your tablet and computer.
- **No data transfer**: Select this mode if you want to charge your phone only.

Lenovo Precision Pen 2

You can use the Lenovo Precision Pen 2 in place of your fingers for a better experience, such as working with specific applications to write or draw on the screen. Use the pen included with the device, or purchase an additional one.
Use Lenovo Precision Pen 2, need to go to **Settings** > **Smart navigation**, turn on the smart navigation function.

Pen buttons

The pen includes an upper button and a lower button, making it convenient to use with your tablet.


- Tap the upper button to go back to the home screen.
- Tap the lower button to bring up the smart navigation menu.

Bamboo Paper



Tap to open the **Bamboo Paper** app in the smart navigation menu. You can add new notes, edit notes, share your notes in the **Bamboo Paper** app.


Managing the note list



After entering the home page, you can swipe left or right to view the note list and do any of the following:

- Tap  to create a new note.
- Tap  to generate a WILL/PDF file and share with others.
- Tap  to delete a note.
- Tap  to change the cover, change the paper type, or rename the note.

Editing the note



After entering the editing page, you can edit your notes using your hand or with your pen.

-  : Edit with the pen, or tap to switch to editing with your fingers.

- : Choose the pen type.
- : Choose the color.
- : Use the eraser to erase any writing on the screen.
- : Full screen.
- : Select a sharing channel such as **Gmail** or **Bluetooth** to share this page with others.
- : Select a picture and add it to your note.
- : Go back to the home page.
- / : Go back/Go forward.
- / : Page down/Page up.

Settings

Setting the language

1. Go to **Settings** > **System** > **Languages** & **input** > **Languages** > **Add a language**.
2. Select the language that you want to add.
3. Press and hold  to drag the added language to the first line.

Setting screen lock

Go to **Settings** > **Security** > **Screen lock**, and select screen lock mode.

Setting sound

Go to **Settings** > **Sound**. Here you can set the **Media volume**, **Alarm volume**, **Notification volume**, and other sound settings.

Setting face recognition

Go to **Settings** > **Security** > **Face-recognition**, follow the on-screen instructions to set up your device.

Battery protection mode

Battery protection mode prevents charging for extended periods, which exposes the battery to high temperatures and high voltage that may cause it to age faster. Once turned on, charging is paused when the battery level reaches 60%.
Go to **Settings** > **Battery** > **Battery protection mode** to turn on battery protection mode.

Eye Protection and Safety Information

Eye protection

When eye protection mode is enabled, the screen will have an amber tint, which reduces blue light. This allows you to read or view the screen more comfortably in dimly lit environments.
Go to **Settings > Display > Eye protection mode**, and tap **Status / *TURN ON NOW** to turn it on.
Color Temperature adjustment: Enter **Eye protection mode** and slide the **Intensity** slider to adjust as needed.

Safety Information

Please use the device in a well-lit area, and when using the device, keep it at a suitable distance from your eyes. To avoid eyestrain, take a break from looking at the screen after a period of time.

Factory reset

Factory reset will erase all data from your tablet's internal storage. Please back up important data on the device before resetting your tablet. Go to **Settings** > **System** > **Reset options** > **Erase all data**

(**factory reset**), then tap **Erase all data** to reset to the manufacturer's default settings.



Appendix

Important safety and handling information

To avoid personal injury, property damage, or accidental damage to the product, read all of the information in this section before using the product. For additional tips to help you operate your device safely, go to http://www.lenovo.com/safety.

Handle your device with care

Do not drop, bend, or puncture your device; do not insert foreign objects into or place heavy objects on your device. Sensitive components inside might become damaged.
Your device screen is made of glass. The glass might break if the device is dropped on a hard surface, is subjected to a high impact, or is crushed by a heavy object. If the glass chips or cracks, do not touch the broken glass or attempt to remove it from the device. Stop using the device immediately and contact Lenovo technical support for repair, replacement, or disposal information.
When using your device, keep it away from hot or high-voltage environments, such as electrical appliances, electrical heating equipment, or electrical cooking equipment. Use your device only in the temperature range of 0°C (32°F) to 40°C (104°F) (storage -20°C (-4°F) to 60 °C (140°F)) to avoid damage.
Don't expose your device to water, rain, extreme humidity, sweat or other liquids.

Do not disassemble or modify your device

Your device is a sealed unit. There are no end-user serviceable parts inside. All internal repairs must be done by a Lenovo-authorized repair facility or a Lenovo-authorized technician. Attempting to open or modify your device will void the warranty.

Built-in rechargeable battery notice

Do not attempt to replace the internal rechargeable lithium ion battery. There is risk of explosion if the battery is replaced with an incorrect type. Contact Lenovo Support for replacement.

Plastic bag notice

DANGER:
Plastic bags can be dangerous. Keep plastic bags away from babies and children to avoid danger of suffocation.

Adapter information

- **Prevent your device and AC adapter from getting wet.**
  Do not immerse your device in water or leave your device in a location where it can come into

contact with water or other liquids.

- **Use approved charging methods only.**
  Note: Please only use standard Lenovo power adapters. The use of third-party power adapters will affect the charging speed, resulting in abnormal charging and potential damage to the equipment.
  - Connect a standard power adapter to a suitable power outlet.
  - Use a standard data cable to connect the device to a PC or a device that complies with USB 2.0 or higher.

Charging devices might become warm during normal use. Ensure that you have adequate ventilation around the charging device. Unplug the charging device if any of the following occurs:

- The charging device has been exposed to rain, liquid, or excessive moisture.
- The charging device shows signs of physical damage.
- You want to clean the charging device.

Warning:
Lenovo is not responsible for the performance or safety of products not manufactured or approved by Lenovo. Use only approved Lenovo ac adapters and batteries.

EU ErP (EcoDesign) Directive (2019/125/EC) - External Power Adapters (Regulation (EU) 2019/1782)

Lenovo Products are designed to work with a range of compatible power adapters. Access https://www.lenovo.com/us/en/compliance/eu-doc to view the compatible power adapters. For the detailed power adapter specifications for your computer, go to https://support.lenovo.com.

Alkaline battery warnings

When replacing the alkaline batteries, only use a compatible type or an equivalent to the one recommended by the manufacturer. Alkaline batteries can explode when they are used, handled, or disposed of improperly. When disposing of alkaline batteries, comply with all relevant local battery disposal ordinances and regulations. In addition:

- Do not disassemble or short-circuit batteries.
- Insert the batteries correctly according to the +/- symbols for their polarity.
- Remove batteries from the product when not in use.
- Do not recharge alkaline batteries.
- Do not dispose of batteries in fires.
- Do not allow metal objects to come in contact with the battery terminals.
- Do not mix new batteries with used batteries, or mix batteries of different types (such as alkaline with carbon zinc).

For proper battery installation and removal, follow the manufacturer's instructions for this product. Keep batteries away from small children. If swallowed, consult a physician immediately. If the batteries are leaking, avoid letting the battery fluid come into contact with your skin and eyes. If battery fluid has already come in contact with your skin, wash your skin with clean water. If battery fluid has already come in contact with your eyes, avoid rubbing your eyes. Consult your physician immediately.

Caution about high volume usage

Warning: exposure to loud noise from any source for extended periods of time may affect your hearing. The louder the sound, the less time is required before your hearing could be affected. To protect your hearing:

- Limit the amount of time you use headsets or headphones at high volume.

- Avoid turning up the volume to block out noisy surroundings.
- Turn the volume down if you can’t hear people speaking near you.

If you experience hearing discomfort, including a sensation of pressure or fullness in your ears, ringing in your ears or muffled speech, you should stop listening to the device through your headset or headphones and have your hearing checked.



To prevent possible hearing damage, do not listen at high volume levels for long periods.

Take care when using your device in a motor vehicle or on a bicycle

Always prioritize your safety and the safety of others. Follow the law. Local laws and regulations might govern how you can use mobile electronic devices, such as your device, while you drive a motor vehicle or ride a bicycle.

Dispose according to local laws and regulations

When your device reaches the end of its useful life, do not crush, incinerate, immerse in water, or dispose of your device in any manner contrary to local laws and regulations. Some internal parts contain substances that can explode, leak, or have adverse environmental effects if disposed of incorrectly. See “Recycling and environmental information” for additional information.

Keep your device and accessories away from small children

Your device contains small parts that can be a choking hazard to small children. Additionally, the glass screen can break or crack if dropped on or thrown against a hard surface.

Protect your data and software

Do not delete unknown files or change the name of files or directories that were not created by you; otherwise, your device software might fail to work.
Be aware that accessing network resources can leave your device vulnerable to computer viruses, hackers, spyware, and other malicious activities that might damage your device, software, or data. It is your responsibility to ensure that you have adequate protection in the form of firewalls, antivirus software, and anti-spyware software and keep such software up to date.
Keep electrical appliances away from your device. These include electric fans, radios, high-powered speakers, air-conditioners, and microwave ovens. The strong magnetic fields generated by electrical appliances can damage the screen and the data on the device.

Be aware of heat generated by your device

When your device is turned on or the battery is charging, some parts might become hot. The temperature that they reach depends on the amount of system activity and the battery charge level. Extended contact with your body, even through clothing, could cause discomfort or even a skin burn. Avoid keeping your hands, your lap, or any other part of your body in contact with a hot section of the device for any extended time.

Electronic emission notices

FCC Compliance Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection

against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult an authorized dealer or service representative for help.

Lenovo is not responsible for any radio or television interference caused by unauthorized changes or modifications to this equipment. Unauthorized changes or modifications could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Responsible Party:
Lenovo (United States) Incorporated
1009 Think Place - Building One
Morrisville, NC 27560
Telephone: 1-919-294-5900

ISED Caution

This device complies with Innovation, Science and Economic Development Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:
(1) This device may not cause interference, and
(2) this device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes:
(1) l'appareil ne doit pas produire de brouillage, et
(2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.

Japanese VCCI Class B statement

この装置は、クラスB情報技術装置です。この装置は、家庭環境で使用することを目的としていますが、この装置がラジオやテレビジョン受信機に近接して使用されると、受信障害を引き起こすことがあります。 取扱説明書に従って正しい取り扱いをして下さい。VCCI-B

Japan compliance statement for products that connect to power mains rated at less than or equal to 20A per phase

日本の定格電流が 20A/相 以下の機器に対する高調波電流規制
高調波電流規格 JIS C 61000-3-2 適合品

Environmental, recycling, and disposal information

General recycling statement

Lenovo encourages owners of information technology (IT) equipment to responsibly recycle their equipment when it is no longer needed. Lenovo offers a variety of programs and services to assist equipment owners in recycling their IT products. For information on recycling Lenovo products, go to http://www.lenovo.com/recycling.

Important battery and WEEE information



Batteries and electrical and electronic equipment marked with the symbol of a crossed-out wheeled bin may not be disposed as unsorted municipal waste. Batteries and waste of electrical and electronic equipment (WEEE) shall be treated separately using the collection framework available to customers for the return, recycling, and treatment of batteries and WEEE. When possible, remove and isolate batteries from WEEE prior to placing WEEE in the waste collection stream. Batteries are to be collected separately using the framework available for the return, recycling, and treatment of batteries and accumulators.
Country-specific information is available at http://www.lenovo.com/recycling.

Battery recycling information for Brazil

Declarações de Reciclagem no Brasil
Descarte de um Produto Lenovo Fora de Uso Equipamentos elétricos e eletrônicos não devem ser descartados em lixo comum, mas enviados à pontos de coleta, autorizados pelo fabricante do produto para que sejam encaminhados e processados por empresas especializadas no manuseio de resíduos industriais, devidamente certificadas pelos orgãos ambientais, de acordo com a legislação local. A Lenovo possui um canal específico para auxiliá-lo no descarte desses produtos. Caso você possua um produto Lenovo em situação de descarte, ligue para o nosso SAC ou encaminhe um e-mail para: reciclar@lenovo.com, informando o modelo, número de série e cidade, a fim de enviarmos as instruções para o correto descarte do seu produto Lenovo.

Recycling information for Japan

Recycling and disposal information for Japan is available at http://www.lenovo.com/recycling/japan.

Recycling information for India

Recycling and disposal information for India is available at http://www.lenovo.com/social_responsibility/us/en/sustainability/ptb_india.html.

Battery recycling marks

- The battery recycling information of Taiwan



- Battery recycling information for the United States and Canada



US & Canada Only

- Battery recycling information for the European Union

EU



ENERGY STAR model information



ENERGY STAR® is a joint program of the U.S. Environmental Protection Agency and the U.S. Department of Energy aimed at saving money and protecting the environment through energy efficient products and practices.

Lenovo is proud to offer our customers products with the ENERGY STAR qualified designation. You might find an ENERGY STAR mark affixed on the computer or displayed on the power settings interface. Lenovo tablets of the following model name, if carrying an ENERGY STAR mark, have been designed and tested to conform to the ENERGY STAR program requirements for tablets.

Lenovo TB-J606F and Lenovo TB-J606L

By using ENERGY STAR qualified products and taking advantage of the power-management features of the tablet, you can help reduce the consumption of electricity. Reduced electrical consumption can contribute to potential financial savings, a cleaner environment, and the reduction of greenhouse gas emissions.

For more information about ENERGY STAR, go to http://www.energystar.gov.

Export classification notice

This product is subject to the United States Export Administration Regulations (EAR) and has an Export Classification Control Number (ECCN) of 5A992.c. It can be re-exported except to any of the embargoed countries in the EAR E1 country list.

Troubleshooting

Insufficient memory prompt appears during app installation

Please free up some memory and try to install again.

The touch screen does not work or is not sensitive

Please press and hold the power button until the device turns off. Then switch it on again in the normal

way.

Device does not power on or the system crashes

Please charge the battery for half an hour and then press and hold the power button until the device turns off. Then switch it on again in the normal way.

The device cannot access the internet via a wireless network

Restart the wireless router or go to Settings and restart WLAN.

The device cannot wake up from sleep mode

Please press and hold the power button until the device turns off. Then switch it on again in the normal way.