




How to replace an oven dial




Parts of the dial assembly



1. Ensure you have the correct parts to reassemble. The dial (1), the spring (2) and the collar (3).

Oven dial and spring




2. Place the spring on to the dial shaft. Make sure to fit the smaller end on first.

Oven dial with spring in place




3. Push the spring as far into the back of the dial as possible.

Oven dial aligned with back ring




4. Align the collar with the dial. There may be a notch in both the collar and dial shaft to align.

Oven dial and back ring together



5. Push the collar and dial together to assemble the pieces.

Control pin cutaway and dial shaft



6. Align the dial assembly with the oven control pin cutaway and firmly push the dial onto it.