
DH-CS03说明书
120x170 折页 8P 100克双胶纸 黑色印刷

challenge®

Model No. DH-CS03
07 LTR MINI DEHUMIDIFIER
INSTRUCTION MANUAL



Important: Please read these instructions carefully before first using this product and retain for future reference.


IMPORTANT SAFETY INSTRUCTIONS


Read through all the instructions carefully before starting to use the appliance. Keep this manual in a safe place for future reference.

- This appliance must be used for its intended purpose only and operated as instructed in this user manual.
- This appliance can be used by children aged 8 years and above and persons with reduced physical, sensory, or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play
- with the appliance. Cleaning and user maintenance shall not be made by children without supervision.
  Children should be supervised to ensure they do not play with the appliance.
- To protect against electrical shock do not immerse cord, plugs, or the main body in water or other liquids.
- Check the appliance before each use for signs of wear or damage. If damaged, discontinue from use immediately and do not use until the appliance has been inspected and approved for use by a qualified service person.
- The product is not to be used if it has been dropped or there are visible signs of damage.
- It the supply cord is damaged, it must be replaced by the manufacturer, its service agent, or a similarly qualified persons in order to avoid hazard.

- Never attempt repairs yourself. Repairs to electrical appliances should only be performed by a qualified electrician. Improper repairs may place the user at serious risk and will invalidate the guarantee, take the appliance to a qualified repair agent.
  This appliance is designed for indoor; household use only.
- Unplug the appliance when not in use, when moving the appliance and
- before cleaning.
  Do not place the appliance on an unsteady surface.
- Do not cover the appliance as this can block the air flow and cause
- overheating.
  This appliance should only be used with the supplied
- adaptor.

PARTS AND CONTROLS





Using your Mini Dehumidifier

- Place the dehumidifier on a steady surface making sure the inlet and outlet grilles are free from obstruction.
- Connect the DC power jack of the supplied DC/AC power adaptor to the DC power socket on the back of the dehumidifier, then connect the AC plug to the appropriate mains cable.
  NOTE: care should be taken with the positioning of the appliance due to the mains cable creating a trip hazard.

Select the power button at the top of the machine to turn the dehumidifier on, press again to switch off.

The LED light feature turns on automatically when the dehumidifier is switched on. Select the light button to cycle through the 7 colour options or to switch the light off.

Press and hold the light button for 2s to turn on/off the blue indicator at the top of the machine

NOTE: When the water tank is full, the red warning light at the base will flicker and sound 3 beeps. The appliance will then switch off automatically.
- After use unplug the dehumidifier and empty the water tank.
  NOTE: Do not use in temperatures less than 8°C or higher than 40°C

Emptying the water tank.

- Before emptying the water tank, switch off and unplug from the mains.
  Unlock the base by turning the base anti clockwise.
- Discard the collected water down a drain.
- Refit the water tank, connect the power cord to the mains and switch
- on to continue dehumidifying.

CLEANING INSTRUCTIONS.

- Before cleaning the appliance, switch off and unplug from the mains. Clean the exterior surface of the appliance with a soft, lightly damp
- cloth, then dry the appliance with a soft, clean cloth.
  Always empty the water tank, clean and dry the tank when not in use
- to prevent mould.

STORAGE.

- When not in use, clean and dry the dehumidifier before storing away in the original or similar sized box.
- Store the appliance in a safe, clean, and dry place, away from direct sunlight and out of reach of children.

TECHNICAL SPECIFICATION.

Challenge 0.7L Dehumidifier	
Model number	DH-CS03
Input rated voltage	DC 9V
Output rated wattage	23W
Cable type	AC/DC Adaptor
Water tank capacity	0.7 Liters
Dimensions	130 x 130 x 213mm
Weight	0.8kg
Operating temperature	Between 8°C to 40°C

UK CA CE

Produced in China for Argos Limited, London, EC1N 2HT, UK.
Argos (N.I.) Ltd, Forestside Shopping Centre, Upper Galwally, Belfast, BT8 6FX, UK.

RECYCLING ELECTRICAL PRODUCTS

You should now recycle your waste electrical goods and in doing so help the environment. This symbol means an electrical product should not be disposed of with normal household waste. Please ensure it is taken to a suitable facility for disposal. Visit www.recycle-more.co.uk, click on “bank locator” and enter your postcode to find your nearest recycling site.

Argos

PRODUCT GUARANTEE

This product is guaranteed against manufacturing defects for a period of



Year

This product is guaranteed for twelve months from the date of original purchase.
Any defect that arises due to faulty materials or workmanship will either be replaced, refunded or repaired free of charge where possible during this period by the dealer from whom you purchased the unit.

The guarantee is subject to the following provisions:

- The guarantee does not cover accidental damage, misuse, cabinet parts, knobs or consumable items.
- The product must be correctly installed and operated in accordance with the instructions contained in this manual.A replacement copy of this manual can be obtained from www.argos-support.co.uk
- It must be used solely for domestic purpose.
- The guarantee will be rendered invalid if the product is re-sold or has been damaged by inexpert repair.
- Specifications are subject to change without notice.
- The manufacturer disclaims any liability for the incidental or consequential damages.
- The guarantee is in addition to and does not diminish your statutory or legal rights.

Guarantor:Argos Ltd
London
EC1N 2HT
www.argos-support.co.uk