
habitat

APIA CONSOLE TABLE



Spare Parts

www.argos-support.co.uk

Help@ClickSpares.co.uk

0370 112 1928

Customer Support

0345 640 2020

Issue 1 - Mar. 2024

⚠ Safety and Care Advice

Product Details

Nature / 5020638

IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• This product has been constructed to be used in the domestic environment only andnot for commercial purposes.


• Assemble the item as close to its final position (in the same room) as possible. Due to the large size and weight of this item, ensure full access around all sides for construction until fully built.

• Assemble on a soft level surface to avoid damaging the unit on your floor.

• Parts of the assembly will be easier with 2 people.

• Dispose of all packaging carefully and responsibly.

• We do notrecommend the use of power drill/drivers for inserting screws as this coulddamage the unit.



Care and maintenance

• Only clean using a damp cloth and mild detergent. Do not use abrasive cleaners.

• From time to time check that there are no loose screws, nuts or bolts. If there are please retighten.

• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

Additional Guidance

• Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts.
• The assembled product must be fixed/secured to a wall which is in good condition using the screws and wall plugs provided.

WARNING
IN ORDER TO PREVENT OVERTURNING THIS PRODUCT MUST BE USED WITH THE WALL ATTACHMENT DEVICE PROVIDED

Serious or fatal crushing injuries can occur from furniture tipping over.
To help prevent this item of furniture tipping over:


• Use the wall attachment device provided.
• Do not let children climb or hang on drawers, doors or shelves.
• Place the heaviest items in the lower drawers or shelves.
• Do not place TV's or other heavy objects on top of this product, unless it has been specifically designed to support them.
• Never open more than one drawer at a time.

An attachment device is provided with your product, however you will need to source suitable fixings for your wall type. If in doubt, please consult a qualified tradesperson.
Always ensure the wall to be drilled is free from hidden electrical wires, water and gas pipes.


Habitat, Argos limited and Sainsbury's Supermarkets Ltd, London EC1N 2HT, UK. Argos(N.I.) Ltd and Sainsbury's (NI) Ltd.
Forestside Shopping Centre, Upper Galwally, Belfast, BT8 6FX, UK

Fittings (Shown to scale)


Bag 1




Tools required




Phillips screwdriver (small & medium)




Phillips screwdriver (small & medium)




Mallet




Pencil



Ruler/tape measure




Eye protection (when using a hammer or glue)




Power Drill


Panels




1 Side panel x 1
(815 x 355 x 30mm)




2 Side panel x 1
(815 x 355 x 30mm)




3 Drawer frame x 1
(650 x 335 x 89mm)



4 Drawer x 1
(620 x 320 x 58mm)




5 Pole x 1
(φ20 x 669mm)




6 Shelf panel x 1
(650 x 339 x 30mm)


1



G




Wall Bracket & Screws x 1



2


I



Plastic baffle x 1




J


Felt Strip x 2





Rotate Product


3

A  65mm Screw x 2	B  Vertical nut x 2	C  35mm Screw x 2
D  Nut x 2	E  Screw x 1	F  L-wrench x 1







4

A  65mm Screw x 2	B  Vertical nut x 2	F  L-wrench x 1



5


A  65mm Screw x 4	B  Vertical nut x 4	C  35mm Screw x 2
D  Nut x 2	E  35mm Screw x 1	F  L-wrench x 1




Rotate Product


6


H



Wall Plug & Screws x 1







WARNING!

BEFORE DRILLING, CHECK WALL FOR HIDDEN PIPES AND CABLES.

WARNING!


IN ORDER TO PREVENT OVERTURNING THIS PRODUCT MUST BE USED WITH THE WALL ATTACHMENT DEVICE PROVIDED.

7


J




Felt Strip x 2



8



9



Assembly is complete.

A Guide to Wall Mounting &Fixings

Important note:

If plastic wall plugs (rawl plugs) are supplied with your product, eg:



- these are suitable for use in masonry walls

If you are in any doubt about the correct wall plugs for your wall, seek professional advice.

Failure of the product due to using the incorrect fixings is the responsibility of the installer.

Important: when drilling into walls always check that there are no hidden wires or pipes

Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.


Hints:

1. General rule: always use a larger screw and wall plug if you are not sure.
2. Ensure you use the recommended drill bit to match the wall plug and hole size.
3. Ensure you drill the hole horizontally; do not force the drill or enlarge the hole.
4. Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure wall plugs are inserted beyond the thickness of the ceramic tiles to avoid the tiles splitting or cracking.
5. Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types of walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone or wood.

No. 1 “General Purpose” wall plug




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case. For light loads, general purpose wall plugs can be used.

No. 3 “Cavity Fixing” wall plug




For use with plasterboard partitions or hollow wooden doors.

No. 5 “Hammer Fixing” wall plug




For use with walls stuck with plasterboard. The hammer fixing allows it to be fixed to the wall rather than the plasterboard. Always check the fixing is secure to the retaining wall.

No. 2 “Plasterboard” wall plug




For use when attaching light loads onto plasterboard partitions.

No. 4 “Cavity Fixing - Heavy Duty” wall plug



For use when fitting or supporting heavy loads such as shelving, wall cabinets and coat racks.

No. 6 “Shield Anchor” wall plug - heavy loads



For use with heavier loads such as TV and HiFi speakers and satelite dishes etc.

Care & Maintenance

Safety: Always check the fitting and location to ensure your safety in and around the home.

Fitting: From time to time check the fitting to ensure the wall plugs or screws do not become loose.