SONY

5-056-356-**23**(1)

Sound Bar

Reference Guide

https://rd1.sony.net/help/ht/208283c/h_zz/

©2024 Sony Corporation
Printed in Malaysia
https://www.sony.net/

* 5 0 5 6 3 5 6 2 3 * (1)

BRAVIA Theatre Bar 8 Model: YY2082C

Before using the unit, be sure to access the following URL and read the End User License Agreement (EULA). The content of the agreement also applies to speakers (available separately) connected to the unit (unless those speakers have a separate license agreement).
https://rd1.sony.net/help/vs/el22/h_zz/

Model: YY2082C

The term “product” in this document refers to the unit or its accessories.

Do not install the product in a confined space, such as a bookcase or built-in cabinet.

To reduce the risk of fire, do not cover the ventilation opening of the unit with newspapers, tablecloths, curtains, etc. Do not expose the unit to naked flame sources (for example, lighted candles).

To reduce the risk of fire or electric shock, do not expose this product to dripping or splashing, and do not place objects filled with liquids, such as vases, on the product.

The unit is not disconnected from the AC power source (mains) as long as it is connected to the wall outlet, even if the unit itself has been turned off.

Install the unit so that the power cord can be unplugged from the wall socket immediately in the event of trouble.

CAUTION
Do not cover ventilation openings.
This unit is not intended to be used on soft surfaces (like bedding, blankets etc.).

For Remote Commander
CAUTION
Risk of explosion if battery is replaced by an incorrect type.
Dispose of used batteries according to local rules and regulations.

Do not expose the batteries (battery pack or batteries installed) to excessive heat, such as sunshine, fire or the like, for a long time.

This product has magnet(s) which may interfere with pacemakers, programmable shunt valves for hydrocephalus treatment, or other medical devices. Do not place this product close to persons who use such medical devices. Consult your doctor before using this product if you use any such medical device.

The nameplate and important information concerning safety are attached in the following locations:
• the bottom of the unit

For details on the effects of contact with the human body from the mobile phone or other wireless devices connected to the unit, refer to the instruction manual of the wireless device.

Reduction in the Use of Hazardous Substances in Electrical & Electronic Equipment (Applicable in Republic of India)
This product and its components, consumables, parts or spares comply with the hazardous substances restriction of India’s E-Waste (Management) Rules. The maximum allowable concentrations of the restricted substances are 0.1% by weight in homogenous materials for Lead, Mercury, Hexavalent Chromium, Polybrominated Biphenyls (PBB) and Polybrominated Diphenyl Ethers (PBDE), and 0.01% by weight in homogenous materials for Cadmium, except for the exemptions specified in Schedule II of the aforesaid Rules.

For customers in Australia or New Zealand

This product must be installed and operated with at least 20 cm separation between the radiating element and the human body (excluding extremities: hands, wrists, feet and ankles).


This unit has been tested and found to comply with the limits set out in the EMC regulation using a connection cable shorter than 3 m.

You are cautioned that any changes or modifications not expressly approved in this manual could void your authority to operate this unit.

Using the Bar Speaker Mounted on a Wall

Refer to the Help Guide for information on the components and steps required to mount the bar speaker on a wall.

https://helpguide.sony.net/ht/208283c/v1/en/contents/010_Mounting_the_Bar_Speaker_on_a_Wall.html



Ⓐ Distance between the screws (commercially available) for wall installation: 876 mm
Ⓑ Gap between the wall installation screw head and wall: 3.5 mm to 4.5 mm
Ⓒ Wall mounting bracket (supplied)
Ⓓ Screw (supplied)

Notes

- Make sure to use the supplied wall mounting brackets when mounting the bar speaker on a wall. Do not mount the bar speaker directly on a wall. The temperature inside the bar speaker rises considerably, which may cause damage or malfunction.
- Hang the bar speaker horizontally on a reinforced wall.
- Ask a Sony dealer or licensed contractor to install the speakers securely and with full consideration of safety.
- Sony shall not be held responsible for any accidents or damage caused by improper installation, lack of installation stability, misuse, or natural disaster.
- For safety, at least two persons should work together to mount the bar speaker.
- Prepare screws (not supplied) suitable for the wall material and hardness. Depending on the wall material, screws that are not suitable may damage the wall.
- Fasten the screws securely into the wall beam.

Licenses

- This product contains software that Sony uses under a licensing agreement with the owner of its copyright. We are obligated to announce the contents of the agreement to customers under requirement by the owner of copyright for the software. Please access the following URL and read the contents of the license.
  https://rd1.sony.net/help/ht/sl/24a/
- The software included in this product contains copyrighted software that is licensed under the GPL/LGPL and other licenses which may require access to source code. You may find a copy of the relevant source code as required under the GPL/LGPL (and other licenses) at the following URL.
  You may obtain the source code as required by the GPL/LGPL on a physical medium from us for a period of three years after our last shipment of this product by applying through the form at the following URL.
  This offer is valid to anyone in receipt of this information.
  https://oss.sony.net/Products/Linux/
  Please note that Sony cannot answer or respond to any inquiries regarding the content of this source code.
- The Spotify Software is subject to third party licenses found here:
  https://www.spotify.com/connect/third-party-licenses.
- Dolby, Dolby Vision, Dolby Atmos, and the double-D symbol are registered trademarks of Dolby Laboratories Licensing Corporation.
  Manufactured under license from Dolby Laboratories. Confidential unpublished works.
  Copyright © 2012–2021 Dolby Laboratories. All rights reserved.
- For DTS patents, see http://patents.dts.com.
  Manufactured under license from DTS, Inc. or DTS Licensing Limited. DTS, DTS:X, and the DTS:X logo are registered trademarks or trademarks of DTS, Inc. in the United States and other countries.
  © 2021 DTS, Inc. ALL RIGHTS RESERVED.
- Services offered by third parties may be changed, suspended, or terminated without prior notice. Sony does not bear any responsibility in these sorts of situations.

Precautions

- Before operating the unit, check that the operating voltage is identical to your local power supply. The operating voltage is indicated on the nameplate on the bottom of the unit.
- The supplied AC power cord (mains lead) is designed exclusively for this unit. It should not be used in combination with any other devices.
- Completely disconnect the AC power cord (mains lead) from the AC outlet (mains) if it is not going to be used for an extended period of time. When unplugging the AC power cord (mains lead), always grip the plug. Never pull the cord itself.
- AC power cord (mains lead) must be changed only at a qualified service shop.

On placement

- Do not place the unit near heat sources or in a place subject to direct sunlight, excessive dust, or mechanical shock.
- Use caution when placing the unit on a surface that has been specially treated (with wax, oil, polish, etc.), as staining or discoloration of the surface may result.
- The speakers of this unit are not of magnetically shielded type. Do not place magnetic cards on the unit or near it.
- Do not place metal objects other than a TV around the unit. Wireless functions may be unstable.

How to care for the unit

- Any dust or dirt on the fabric part should be gently removed with a soft cloth.
  – Scratching the dirt off with the fingernails or applying excessive force may damage the fabric.
  – Do not use cleaning brushes, etc., as such tools may damage the fabric depending on the tool material.
  – If the fabric part is heavily soiled, wipe it with a soft cloth lightly dampened with a neutral detergent, then wipe it again with a soft dry cloth.
  Use of detergents or cleaners other than neutral detergent may cause color fading or fabric damage.
- Wipe the cabinet with a soft cloth dampened with a mild detergent. Do not use abrasive pads, cleansers, or solvents like alcohol or benzene.

On BLUETOOTH® communications

- Microwaves emitting from a BLUETOOTH device may affect the operation of electronic medical devices. Turn off this unit and other BLUETOOTH devices in the following locations, as it may cause an accident:
  – in hospitals, near priority seating in trains, locations where inflammable gas is present, near automatic doors, or near fire alarms.

Notes on transferring/disposing

- Be sure to reset the unit, deleting private information and setting information before transferring/disposing.
  If the unit is transferred or disposed without resetting, private information may be inspected by a third person and abused.
  For details of the resetting method, refer to Help Guide.

Other notes

- Place the unit in a location with adequate ventilation to prevent heat buildup and prolong the life of the unit.
- Should any solid object or liquid fall into the unit, unplug the unit and have it checked by qualified personnel before operating it any further.
- When connecting the unit to the Internet, use the router (ADSL modem or optical line termination device with the router function supplied with the Internet provider, or Wi-Fi access point). If you connect to the Internet without using the router, a security problem may occur. If you are not sure that the wall outlet for the network line has the router function, ask your manager of the apartment house or Internet provider.
- If you have any questions or problems concerning this unit that are not covered in this manual, please consult your nearest Sony dealer.

Trademarks

- Spotify and Spotify logos are registered trademarks of Spotify AB.*
  * Spotify service may not be available in some countries/regions. Please visit support.spotify.com for more information.
- The BLUETOOTH® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Sony Group Corporation and its subsidiaries is under license.
- Wi-Fi®, Wi-Fi Protected Access® and Wi-Fi Alliance® are registered trademarks of Wi-Fi Alliance.
- Wi-Fi CERTIFIED™, WPA™, WPA2™, and WPA3™ are trademarks of Wi-Fi Alliance.
- The terms HDMI™, HDMI High-Definition Multimedia Interface, HDMI Trade dress and the HDMI Logos are trademarks or registered trademarks of HDMI Licensing Administrator, Inc.
- LDAC and LDAC logo are trademarks of Sony Group Corporation or its affiliates.

All other trademarks and registered trademarks are trademarks or registered trademarks of their respective holders. In this manual, ™ and ® marks are not specified.

Specifications

Sound Bar (YY2082C)

Amplifier section

POWER OUTPUT (rated)
Front L + Front R speaker blocks: 33 W + 33 W (at 6 ohms, 1 kHz 1 % THD)
Center + Center speaker blocks: 33 W + 33 W (at 6 ohms, 1 kHz 1 % THD)
Front tweeter L + Front tweeter R speaker blocks: 33 W + 33 W (at 4 ohms, 10 kHz 1 % THD)
Center tweeter speaker block: 33 W (at 6 ohms, 10 kHz 1 % THD)
Top L + Top R speaker blocks: 33 W + 33 W (at 6 ohms, 1 kHz 1 % THD)
Side L + Side R speaker blocks: 33 W + 33 W (at 6 ohms, 1 kHz 1 % THD)
POWER OUTPUT (reference)
Front L/Front R speaker blocks: 45 W (per channel at 6 ohms, 1 kHz)
Center/Center speaker blocks: 45 W (per channel at 6 ohms, 1 kHz)
Front tweeter L/Front tweeter R speaker blocks: 45 W (per channel at 4 ohms, 10 kHz)
Center tweeter speaker block: 45 W (at 6 ohms, 10 kHz)
Top L/Top R speaker blocks: 45 W (per channel at 6 ohms, 1 kHz)
Side L/Side R speaker blocks: 45 W (per channel at 6 ohms, 1 kHz)

Wireless LAN section

Communication system
IEEE 802.11 a/b/g/n/ac
Frequency band
2.4 GHz, 5 GHz

BLUETOOTH section

Communication system
BLUETOOTH Specification version 5.2
Frequency band
2.4 GHz band (2.400 0 GHz - 2.483 5 GHz)

USB section (For service use only)

FOR SERVICE port
Type A (For connecting USB memory)

HDMI section

Connector
Type A (19pin)

General

Power
220 V - 240 V AC, 50 Hz/60 Hz
Power consumption
On: 60 W
[Network/Bluetooth Standby] is set to ON: 2.3 W or less
[Network/Bluetooth Standby] is set to OFF: 0.5 W or less
When [Signal Pass Through] is set to [Off], or when [Signal Pass Through] is set to [Auto] and the connected TV is turned off.
Dimensions (approx.) (w/h/d)
Not including projection portion
Sound Bar: 1 100 mm × 64 mm × 113 mm
Sound Bar with the Wall mounting bracket: 1 100 mm × 65.4 mm × 123 mm
Sound Bar with the Foot: 1 100 mm × 76.2 mm × 113 mm
Mass (approx.)
Sound Bar: 4.7 kg
Sound Bar with the Wall mounting bracket: 5 kg
Sound Bar with the Foot: 4.7 kg

Wireless transmitter/receiver section

Communication system
Wireless Sound Specification version 4.0
Frequency band
5 GHz

Included items

Sound Bar (1)
Remote control (1)
Battery (2)
WALL MOUNT TEMPLATE (1)
Wall mounting bracket (2), Screw (2)
Foot (2)
HDMI cable (4K, 8K transmission supported) (1)
TV center speaker mode cable (1)
AC power cord (mains lead) (1)
Documents (1 set)

Design and specifications are subject to change without notice.

COMPATIBLE WITH