

Setting Up the Console

Applies to: [Nintendo Switch](#)

1. Connect the AC adapter

2. Set up the console

When you start up the console for the first time, you'll be asked to choose some settings. Attach both Joy-Con controllers to the console and follow the on-screen instructions.




More settings can be chosen later.

If something you don't understand pops up while you're choosing your settings, please view the following pages.

- [Connecting to the internet](#)
- *What is a time zone?*
- *Connecting to a TV*
- *Linking to a Nintendo Account*
- *Setting Parental Controls*
- *Help choosing settings*

Changing your settings

You can change these settings at any time from System Settings on the HOME Menu.



[3. Play!](#)