

Thank you for purchasing this **Group 0-1-2 car seat**. If you require assistance **E.** Adjuster (x2) with this product or if you wish to change an accessory, please contact our cusomer service department.

SAFETY INSTRUCTIONS

PLEASE READ THESE INSTRUCTIONS CAREFULLY BEFORE BEGINNING THE IN-STALLATION. IF THE SEAT IS NOT INSTALLED CORRECTLY, YOUR CHILD'S SAFETY MAY BE AT RISK. DO NOT USE THIS CHILD SEAT ON A PASSENGER SEAT FIT-TED WITH AN AIR BAG!

The seat may be installed in a front-facing or rear-facing position with a 3-point safety belt to UN/ECE No.16 standard or equivalent. Do not use it on side-facing or rear-facing seats. Always remember to fasten and correctly adjust the child's harness and never start the car without first checking that the seat is properly fixed to the passenger seat as shown in these instructions. It is important to check that the straps of the seat belt are fully tightened and that the harness lap strap is positioned as low as possible to support your child's pelvis. Check that the seat belt and harness straps are not twisted. For maximum protection, there must be no slack between the car seat and the passenger seat. Please refer to the method recommended in these instructions. The seat must not be modified in any way and no elements should be added. It is recommended that you replace this car seat if it has been subjected to a severe impact following an accident or in case of wear. You should regularly check that the harness is not showing signs of wear; check in particular the harness points, the seams and the adjustment devices. Never leave your child unattended in the seat. Check that no part of the seat is trapped in the door or in a fold-down passenger seat. If your car has a fold-down rear seat, check that it is correctly locked in the vertical position. Direct exposure to the sun increases the temperature inside vehicles. For this reason, you are advised to cover the child's car seat when not in use in order to revent the elements, in particular the fixations, from getting hot and burning the child. Do not use your car seat without its cover and only replace it with a cover that has been recommended by the manufacturer. In an emergency, the child must be able to be freed quickly. The buckle, which can be easily opened, must therefore not be covered. Teach your child not to play with the buckle. Always remember to check that there are no scraps of food or other remains in either the harness buckle or the central adjuster. Luggage and other heavy or sharp objects must be fixed down in the car. Objects that are not attached may

• For a front-facing position (Gr. 1, from 9 to 18 kg), the harnesses are fed injure a child in the event of an accident. In winter, make sure that the child is not wearing over-bulky clothes.

The correct type of safety belt to use with your car

Your car seat must **ONLY** be installed on a passenger seat fitted with a 3-point safety belt (1). NEVER install your car seat on a passenger seat fitted with a from 0 to 10 kg) 2-point safetu belt (2)!

Your Gr. 0-1-2 car seat (3)

This is a Group 0-1-2 car seat that is designed for children weighing between 0 and 25 kg.

- A. Cover
 B. Pillow (some models only)
- C. Shoulder pad (x2)
- D. Infant reducer cushion (some models only)

- G. Shell
- H. Harness buckle
- I. Belt guides for rear-facing use

Adjusting the harnesses

Make sure that the harness of your car seat is adapted to the height of uour child before starting to install the seat in your car. The harnesses can be adjusted to 4 different heights and must be positioned as close as possible to your child's shoulders (4).

ver positions are **ONLY** intended for use in group 0, for a child weighing from 0 to 10 kg in a rear-facing position. If your child's shoulders are between two levels in a rear-facing configuration, choose the lower of the two.

• The two upper positions are **ONLY** intended for use in group 1, for a child weighing from 9 to 18 kg in a front-facing position. If your child's shoulders are between two levels in front-facing configuration, choose the higher of the two.

To adjust the height of the harnesses, remove the upper section of one of the harness straps by pivoting the metal anchor located behind the back rest and then pulling it through the slots of the shell and cover (5). Repeat the operation on the upper section of the second strap. Feed the ends of the harness straps through the slots at identical level in both the

cover and the shell, according to the chosen configuration:

• For a rear-facing configuration (Gr. 0, from 0 to 10 kg), the harnesses are fed through one of the two lower positions (6) and then up to the third position to be secured inside the shell (7) (8). Make sure that the metal anchor is correctly oned and that the ends of the harness straps are not twisted.

IMPORTANT: Whichever of the two lower positions you have chosen, make sure that the metal anchors of the harnesses are well secured through the slots of the

through one of the two upper positions (9) and are secured directly behind the position chosen, at the back of the shell (10) (11) Make sure that the metal anchor is correctly positioned and that the ends of the harness straps are not

Installing the car seat in a rear-facing position (Gr. 0,

DANGER! DO NOT USE THIS CHILD'S CAR SEAT ON A PASSENGER SEAT FIT-**TED WITH AN AIR BAG!**

Fasten the vehicle seat belt (12). Place the car seat in a rear-facing position on either the front seat or the rear seats of your vehicle (13). Feed the waist strap of the seat belt through the guides located under the base of the car seat (14). Pull and feed the diagonal part of the seat belt through the guides located behind the back rest of the car seat. The diagonal strap passes through the upper guide on the side nearest the belt winder and through the lower guide on the side nearest the seat belt buckle (15). Place the car seat so that only the back of its base is in

contact with the seat of the vehicle (16). Make sure the belt is not twisted and the slots of the base and the cover (30) pull it as tightly as possible (17).

IMPORTANT: once the car seat has been installed, the vehicle seat buckle must not be touching the waist strap guide located under the base of the car seat. If it does, choose another place in the vehicle. If in doubt, please contact our cusomer service department

Place your child in the car seat, following the instructions in the section entitled Installing your child in the car seat with a harness'.

Installing the car seat in a front-facing position (Gr. 1, from 9 to 18 kg)

Place the car seat in a front-facing position on the rear seat of the vehicle. Pull on the vehicle seat belt until it is completely loose. Feed the two straps of the belt through the opening in the shell (18), bringing them out through the opposite opening. The belt should pass between the shell and the car seat cover. Fasten the seatbelt **(19)**. Place the car seat so that only the front of its base is in contact with the seat of the vehicle (20). On the side nearest the belt winder, pull up the diagonal belt through the slot located on the side of the shell (21). Make sure the pelt is not twisted and pull it as tightly as possible (22).

MPORTANT: once the car seat has been installed, the vehicle seat buckle must not touch the opening through which the belt passes on the side of the car seat If it does, choose another place in the vehicle. If in doubt, please contact our

Place your child in the car seat, following the instructions in the section entitled 'Installing your child in the car seat with a harness'.

Installing your child in the car seat with a harness (Gr.

per section of the harnesses, grasp the lower section and pull simultaneously (23). Press on the red button in the centre to open the harness buckle (24). Open out the harnesses (25) and place your child in the car seat. Put the harness connectors together and insert them into the buckle, making sure you hear a 'click' at 30° in soapy water. Do not use bleach, do not iron, do not machine wash or (26). Pull on the adjusting strap of one of the harnesses until it is properly tightened against your child (27). Repeat the operation with the adjusting strap of the second harness.

MPORTANT: A correctly adjusted harness is essential for your child's protection. There should not be more than finger's width between the harness and your

Removing the harness

Put the harness buckle ends together and close the buckle in order to assemble the various parts of the harness and the crotch strap. This will enable you to store the harness more easily for future use. Remove one of the upper sections of the harness by pivoting the metal anchor located behind the back of the shell and then pulling it through the slots of the back rest and cover (28). Repeat the operation with the second upper strap section.

located under the base of the car seat and then pulling it through the slots of the other equivalent standards. base and the cover (29). Repeat the operation with the second lower section, Remove the crotch strap by pivoting the metal anchor and then feeding it through

Simply reverse this procedure when you wish to put back your car seat

Installing the car seat in a front-facing position (Gr. 2, from 15 to 25 kg)

Make sure that you have removed the harness of the car seat before starting the installation. Follow the instructions in the section entitled 'Removing

Place the car seat in a front-facing position on the rear passenger seat of your vehicle and sit your child in the car seat. Pull on the seat belt until it is completely loose. Thread the seat belt through the openings on the side of the shell and cover of the car seat (31). Pull on the belt and threaded through the openings on the opposite side of the shell and cover (32). Fasten the seatbelt (33). On the side nearest the belt winder, pull up the diagonal belt through the slot located on the side of the shell (34). Place the car seat so that only the front of its base is in contact with the seat of the vehicle (35). Make sure the belt is not twisted and pull it as tightly as possible (36). Check that the diagonal lies across your child's shoulder, clear of their neck.

IMPORTANT: once the car seat has been installed, the vehicle seat buckle must not touch the opening through which the belt passes on the side of the car seat. If it does, choose another place in the vehicle. If in doubt, please contact our

Storing the instructions

ructions to hand, by sliding them between the cover and the shell of uour car seat (37).

Maintenance information

All the fabric parts are removable. To take off the cover, first remove the harness lowing the instructions in the section entitled 'Removing the harness' (38). Minor stains can be cleaned using a sponge and soapy water or hand-washed

tumble dry. To put the cover back on, start with the top of the shell (39), then the sides (40) and finally the lower part (41).

WARNING

• This car seat is a 'Universal' child restraint system. It has been approved in ac cordance with regulation No.44/04 and is suitable for general use in vehicles and is compatible with the majority (some exceptions) vehicle seats

• It is more likely that the seat is perfectly compatible if the vehicle manufacturer states that its vehicles are suitable for 'Universal' child restraint systems.

 This restraint sustem is classified as 'Universal' in accordance with the strictest approval criteria, whereas earlier models do not correspond to these new provi

 It can only be adapted to vehicles with 3-point safety belts that are either fixed Remove one of the lower sections of the harness by pivoting the metal anchor or have a roller mechanism and that have been approved to UN/ECE No.16 or