cuggl

7224092



woodland bouncer

IMPORTANT! READ CAREFULLY AND KEEP FOR FUTURE REFERENCE.

Produced in China for Argos Limited, London, EC1N,UK.
Argos (N.I.) Ltd,
Forestside Shopping Centre, Upper Galwally, Belfast, BT8 6FX, UK.

argos.co.uk/help/contact-us

IMPORTANT! READ CAREFULLY AND KEEP FOR FUTURE REFERENCE

⚠WARNING

FALL HAZARD: Babies have suffered skull fractures falling while in and from bouncers when not used properly.

- **NEVER** leave the child unattended.
- Use bouncer **ONLY** on the floor.
- **NEVER** use on an elevated surface. Only use on the floor.
- **NEVER** lift or carry baby in bouncer.

SUFFOCATION HAZARD: Babies have suffocated when bouncers tipped over on soft surfaces and/or when bouncers have been used as a sleep product.

- **NEVER** use on a bed, sofa, cushion, or other soft surface.
- Stay near and watch baby during use. This product is not safe for sleep or unsupervised use. If baby falls asleep, remove baby as soon as possible and place baby on a firm, flat sleep surface such as a crib or bassinet.

TO PREVENT FALLS AND SUFFOCATION:

- **ALWAYS** use restraints and adjust to fit snugly.
- **STOP** using bouncer when baby starts trying to sit up or has reached 20 lb (9 kg), whichever comes first.
- Never let the child sleep in this product.
- **NEVER** use as an infant carrier for automobile or airline travel.
- **NEVER** attach any additional strings or straps to product.

IMPORTANT

- Adult assembly required.
- Please read all instructions before assembly and use of the product.
- Care should be taken in unpacking and assembly.
- Examine product frequently for damaged, missing, or loose parts.
- DO NOT use if any parts are missing, damaged, or broken.
- This product does not replace a cot or a crib. Should the child fall asleep, then it should be placed in a suitable cot or crib.
- DO NOT use replacement parts other than those approved by the manufacturer or distributor.


Care and Cleaning


Seat pad – Remove from frame. Fasten buckles on seat restraint and seat pad. Fasten all hookand-loop patches to the corresponding patch. Machine wash with cold water, gentle cycle. No bleach. Tumble dry, using low heat.


Frame – Wipe the metal frame with soft, clean cloth and mild soap.

Parts List and Drawing


No.	Qty.	ENGLISH
		Description
1	(1)	Base frame tube
2	(1)	Left base frame member
3	(1)	Right base frame member
4	(1)	Left backrest tube
5	(1)	Right backrest tube
6	(1)	Footrest wire
7	(1)	Seat pad


7
3
6
5
1
4
2



1
3
1
2
x2


2
4
5


3




4




5




6




7




8






9




10





Using the Seat Restraint

1




2





Storage and Travel



To disassemble the bouncer for storage:
Use a small Phillips screwdriver to depress the release button on the inside of each connecting hub on the bouncer. Remove the footrest tube and base frame tubes from each connecting hub.

cuggl

Toys • Activity Gyms • Bouncers • Rockers • Swings
Activity Centers • Walkers • Door Jumpers

argos.co.uk/help/contact-us

Instruction sheet version: 00
Instruction sheet version date: 27/12/2024

Produced in China for Argos Limited, London, EC1N,UK.
Argos (N.I.) Ltd, Forestside Shopping Centre,
Upper Galwally, Belfast, BT8 6FX, UK.

argos.co.uk/help/contact-us



17436_WWN_IS122724