

User Guide

blink



Simple Setup

1. Download the app.

Visit the App Store, Google Play Store


2. Launch the App.

Open the app on your iOS or Android device


3. Follow in-app instructions.

The Blink app will walk you through creating an account and setting up your new Blink system.

Detailed setup instructions can be found on page 5.



System Requirements



Blink connects to the Internet via a wireless connection.

Wi-Fi Network Requirements

In order for Blink to connect to your home Wi-Fi network, it must meet the following requirements.

- Your Wi-Fi network broadcasts at 2.4GHz (802.11 b/g/n)
- Your network does not block port 443.
- Your network upload speed is at least 2 Mbps.

iOS Requirements

To set up Blink using an iOS device, it must be running iOS 8.1 or later. The following devices support that:

- iPhone (4S or newer)
- iPad (2nd gen or newer)
- iPad Mini (1st gen or newer)
- iPod Touch (5th gen or newer)

Android Requirements

To set up Blink on an Android device, it must be running Android 4.4 (KitKat) or later.

Package Contents

Sync Module

The Sync Module is the central hub of your Blink system. This connects to your WiFi network and your Blink cameras.

Package Includes:

Micro USB Cable & USB Wall Adapter



Indoor Camera

Our Indoor camera operates on 2 AA Lithium batteries and with standard use can last up to two years before needing to be replaced.

(Alkaline or Rechargeable are not recommended and standard use is defined as 40,000 seconds of Live View and Motion Clips over a 2 year period).

Package Includes:

Indoor Camera
2 x AA Lithium Batteries
Mounting Bracket & Screw



Setup

This is an overview of the setup process. Once you've downloaded the Blink app, create your account and follow these instructions.




Tap the Blink logo to begin.

1. Tap the Blink logo to begin.




2. Tap the Add a system button.



3. Set a name for the system like "Home" or "Office".



Tap the Sync Module



4. Tap add a Sync Module.



Before you begin you will need:

- Your Sync Module serial number located on the bottom of the unit.
- The name and password of the Wi-Fi that Blink will use. Verify that your phone is connected to that Wi-Fi before continuing.
- Good Wi-Fi signal strength. Place your Sync Module close to your router to ensure a stable connection.



5. Read guide then tap "Ready" when you have the necessary information.



6. Enter your Sync Module's serial number located on the bottom of the unit.



Setup Cont'd.

Cancel Add Sync Module

Plug in your Sync Module and wait 30 seconds. The lights should match the pattern: Blinking Blue, Steady Green.



Do the lights on your Sync Module match the pattern above?

Yes No

7. Plug your Sync Module into power and wait 30 seconds until you see a solid green and flashing blue light.

Cancel Add Sync Module Help

Tap the Home button.

Tap Settings, then "Wi-Fi".


Tap BLINK-0087 as shown below.



Tap the Home button then tap Blink.

Tap "Help" above to see a video.

8. Leave the Blink app and go to Settings>WiFi. Connect to the Blink-#### network. It's normal to see "Security Recommendation" or "Connected, no Internet".



9. After a successful connection, navigate back to the Blink App.

Cancel Add Sync Module

Listed below are the Wi-Fi networks in range of your Sync Module. Select the Wifi network for Blink to join. (Three bars or more recommended)

- Higg's Boson [signal strength]
- WGR614v9 [signal strength]
- bfhe-cs [signal strength]
- Other... (hidden network)

Sync Module v1.48

Refresh List

9. Locate your Home WiFi network then tap it to continue.

< Add Sync Module

bfhe-cs
[password field]
 Hide Password



10. Enter the password for your home WiFi network to connect.


Add Sync Module

Sync Module added!

Done

11. After about 30 seconds, you'll see the message "Sync Module added!". Tap "Done".

Adding your Cameras



1. Tap to Add a Blink camera.

2. Select which camera to add.

3. Read guide then tap Ready.



4. Enter camera's serial number and hit the continue button.




5. Name and position your camera then tap the snapshot.




6. Once generated, gauge the signal strengths and tap "Done". Repeat the above steps for any additional cameras.

Home Screen

The Home Screen shows you the cameras that you have on your account. From here, you can update their thumbnails, access them using Live View, and more.




Camera Settings



Camera Settings

- 1. Name:** Camera's individual name
- 2. Battery:** Battery indicator
- 3. Temperature:** Current temperature
- 4. Motion Detection:** Enable or disable
- 5. Retrigger Time:** Time between motion clips
- 6. Sensitivity:** Sensitivity of motion detection
- 7. Clip Length:** Length of motion clip
- 8. End Early:** Ends clip if motion stops
- 9. Control:** Camera's LED lighting
- 10. Intensity:** Brightness of LED illuminator
- 11. Audio:** Enable or disable microphone
- 12. Update:** Refresh camera's readings
- 13. Camera to WiFi:** Signal strength to WiFi
- 14. Camera to Sync Module:** Signal strength to your Sync Module
- 15. Delete Camera:** Deletes camera from your account.

System Picker



Switch between multiple systems

Set up a motion detection schedule

Set your Time Zone

Rename your system

Delete your Blink system

Add another Blink system

Help

At Blink, our dedicated support team is ready to assist you using your preferred method if you run into any issues.

Email: support@blinkforhome.com

Web: support.blinkforhome.com

Phone: (781) 332-5465

Thank you for choosing Blink!

