
Pandora



Spare Parts

www.argos-support.co.uk

Help@ClickSpares.co.uk

0370 112 1928

Customer Support

0345 640 2020

argos.co.uk/help/contact-us

Issue 3 - 17/4/25

⚠ Safety and Care Advice

Product Details

Cream 7670275
Brown 7468274

IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.


• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• This product has been constructed to be used in the domestic environment only and not for commercial purposes.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor.



• We do not recommend the use of power drill/drivers for inserting screws as this could damage the unit. Only use hand screwdrivers.

• Parts of the assembly will be easier with 2 people.

• Dispose of all packaging carefully and responsibly.

CARE AND MAINTENANCE

• From time to time check that there are no loose screws, nuts or bolts. If there are please re-tighten.

• This product should not be discarded with household waste . Take to your local authority waste disposal centre.

CLEANING GUIDANCE


• Minor stains and spillages should be removed immediately from cushion fabric, by wiping over lightly with a damp cloth and mild soapy water.

• Light marking can also be removed using this method.


• To remove more stubborn stains or marking, a good quality proprietary domestic fabric cleaner can be used, although it should first be tested on and inconspicuous area of the fabric.

Sainsbury's Supermarkets Ltd and Argos Limited, London EC1M 6HA, UK. Sainsbury's (NI) Ltd and Argos (N.I.) Ltd, Forestside Shopping Centre, Upper Galwally, Belfast, BT8 6FX, UK.


Fittings (Shown to scale)




Parts




1 Top x 1
(1200 x 460 x 65mm)




2 Side panel x 2
(1200 x 390 x 30mm)




3 Base panel x 1
(1135 x 395 x 5mm)



4 End panel (left) x 1
(400 x 390 x 30mm)



5 End panel (Right) x 1
(400 x 390 x 30mm)




6 Support frame x 1
(400 x 350mm)




7 Base support block x 2
(30 x 50 x 60mm)

Tools required




4mm Allen key
(Supplied)


1



A M6x20mm Bolt x 8

C Washer x 8







2

B M6x35mm Bolt x 4

C Washer x 4


Turn Product





Shown Upside Down


3



Secure with Hook and loop fastening


4






Support blocks 7 on underside

5




WARNING!

Avoid finger entrapment when opening and closing hinges!



6



Assembly is complete.