
MEET YOUR ECHO SHOW 15



ALSO INCLUDED:



Alexa Voice Remote



2 AAA batteries




Power adapter and cable wrap

INCLUDED FOR MOUNTING

Mounting on the wall is optional. You can also place your Echo Show 15 in a stand (sold separately).



Wall mount



Wall mount template

Sized to the device
16" × 10" (40.8 × 25.8 cm)



4 screws



4 anchors

Not for use in wood or studs

Note: Included screws and anchors are recommended for drywall, brick, concrete, or tile surfaces. Do not use the anchors if drilling into wood or studs.

TOOLS YOU'LL NEED

Not included in the box:



Electric drill
- *5/16" (8 mm) drill bit*
- *Phillips #2 driver bit*



Level or level app



Hammer



Wall-safe tape

MOUNTING YOUR ECHO SHOW 15 ON THE WALL

1 FIND A LOCATION


- Choose a location near eye level. Consider everyone using the device.
- Ensure the power cable will reach a power outlet.
- WARNING: Do not drill into wiring or piping.


2 LEVEL AND TAPE TEMPLATE TO THE WALL

- Place the template on the wall. Use a level or level app on your phone to level the template.
- Tape the template in place.

3 DRILL HOLES AND INSTALL ANCHORS

- Use an electric drill with a 5/16" (or 8 mm) drill bit. Drill through the 4 holes in the template. Remove the template.
- Hammer the 4 anchors into the holes until they are flat against the wall.





MOUNTING YOUR ECHO SHOW 15 ON THE WALL

4 INSTALL WALL MOUNT


- With the triangle cutout on top, align the wall mount's 4 holes with the installed anchors.
- Drill the screws through the holes and into the anchors until the screws are flat against the mount.


5 PLUG INCLUDED POWER ADAPTER INTO ECHO SHOW 15

- Organize the cable in the mounting cavity with the cable wrap.
- Wait until after mounting your device to plug into a power outlet.

6 SLIDE DEVICE ONTO MOUNT

- Slide your Echo Show 15 down onto the wall mount's hooks. Make sure to connect all 4 hooks.





SET UP YOUR ECHO SHOW 15

1. HAVE YOUR WIFI AND AMAZON PASSWORDS READY

Prepare to connect to your wifi and sign in to your Amazon account.

2. PLUG ECHO SHOW 15 INTO A POWER OUTLET

Use the included power adapter. In about a minute, the display will turn on and Alexa will greet you.

3. FOLLOW THE ONSCREEN SETUP

Log in with an existing Amazon account username and password or create a new account.

4. DOWNLOAD THE AMAZON ALEXA APP

The app helps you get more out of your Echo Show 15. It's where you set up calling and messaging and manage music, lists, settings, and news.


SET UP COMPATIBLE SMART HOME DEVICES

You can easily connect and control compatible devices with the built-in smart home hub.


When ready to get started, open the Alexa app to add your device, or say, "Alexa, discover my devices."



MEET YOUR ALEXA VOICE REMOTE



POWER UP YOUR REMOTE



1. Press and hold your thumb on the arrow to release the latch.
2. While pressing the arrow, slide open the cover.
3. Insert included AAA alkaline batteries.

Note: The remote only pairs with one device at a time and can't control skills and services outside of the Fire TV experience.

PRIVACY AND SUPPORT

PRIVACY CONTROLS

Turn the microphones and camera off by pressing the Microphones/Camera on/off button.

Cover the camera easily with the built-in shutter.

See when Alexa is recording and sending your request to Amazon's secure cloud via a blue indicator light.


MANAGE YOUR VOICE HISTORY

You can view, hear, and delete the voice recordings associated with your account in the Alexa app at any time.

CUSTOMER SUPPORT

For help and troubleshooting, go to Help & Feedback in the Alexa app or visit amazon.com/devicesupport.

You have control over your Alexa experience.
Explore more at amazon.com/alexaprivacy or amazon.ca/alexaprivacy.



Some features may require customization in the Alexa app, a separate subscription, or an additional compatible smart home device. You can find more examples and tips in the Alexa app.

SCAN FOR MORE HELP AND ACCESSIBLE INSTRUCTIONS

Scan the QR code or visit: amazon.com/setup/echoshow15