

MEET YOUR ECHO SHOW 11





Also included: power adaptor

SET UP YOUR ECHO SHOW 11

1. Have your Wi-Fi and Amazon passwords ready

Prepare to connect to your Wi-Fi and sign in to your Amazon account. Create a new account if you don't have one.

2. Plug Echo Show 11 into an electrical socket

Use the included power adaptor. In about a minute, the display will turn on and Alexa will greet you.



3. Scan the QR code on the screen

Using your phone, scan the QR code to open or download the Alexa app. Or continue on the device.

4. Complete setup

Follow the instructions in the Alexa app or on your Echo Show 11 to complete setup.

Set up compatible smart home devices

You can easily connect and control compatible devices with the built-in smart home hub.

To get started, open the Alexa app to add your device, or say, "Alexa, discover my devices."

Some features may require customisation in the Alexa app, a separate subscription or an additional compatible smart home device.

PRIVACY AND SUPPORT

Privacy controls

Disable the microphones and camera by pressing the microphones & camera enable/disable button.

To disable only the camera, visit Device Settings on the device screen or in the Alexa app.

See when Alexa is recording and sending your request to Amazon's secure cloud via a blue indicator light.

Manage your voice history

You can view, hear and delete the voice recordings associated with your account in the Alexa app at any time.

Customer support

For help and troubleshooting, go to Help & Feedback in the Alexa app, or visit amazon.com/devicesupport.



You have control over your Alexa experience

Explore more at amazon.com/alexaprivacy

Scan for more help

amazon.com/setup/echoshow11