
MEET YOUR ECHO DOT MAX



Also included: Power adapter

SET UP YOUR ECHO DOT MAX

1. Download the Alexa app from the app store

Log in with an existing Amazon account username and password or create a new account.
Note: Be sure to turn on your phone's Bluetooth and have your wifi password ready.

2. Plug in your Echo Dot Max

Use the included power adapter. A blue light will flash on the device. In about a minute, Alexa will tell you to complete setup in the app.

3. Complete setup in the app

If you aren't prompted to set up your device after opening the Alexa app, tap the More icon to add your device manually. The app helps you get more out of your Echo Dot Max. It's where you manage smart home devices, music, settings, and more.

PRIVACY AND SUPPORT

Privacy controls

Disable the microphones by pressing the microphones enable/disable button. See when Alexa is recording and sending your request to Amazon's secure cloud via a blue indicator light.

Manage your voice history

You can view, hear, and delete the voice recordings associated with your account in the Alexa app at any time.

Customer support

For help and troubleshooting, go to Help & Feedback in the Alexa app, or visit amazon.com/devicesupport.

You have control over your Alexa experience
Explore more at amazon.com/alexaprivacy or amazon.ca/alexaprivacy



Some features may require customization in the Alexa app, a separate subscription, or an additional compatible smart home device.

Scan for more help

Scan the QR code or visit:
amazon.com/setup/echodotmax