
Star 2+2 Drw. Chest White

Assembly Instructions - Please keep for future reference | 8053011

THE COLLECTION BY ARGOS



Dimensions

Length - 86cm
Depth - 40cm
Height - 73cm
Weight - 26,4kg

Important – Please read these instructions fully before starting assembly

If you need help or have damaged or missing parts, call the **Customer Helpline:**
0045 7668 8055 or e-mail: order@flexa.dk

Issue 1 - 06/10/17

⚠ Safety and Care Advice

Important – Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on pages 2 and 3.

• Remove all fittings from the plastic bags and separate them into their groups.

• During assembly children should be kept away from the product due to possible risk of injury.

• Make sure you have enough space to layout the parts before starting.

•This product is suitable for children in the age range 3 to adult

• Do not stand or put weight on the product, this could cause damage.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor.

• Parts of the assembly will be easier with 2 people.

• Do not use this item if any components are missing or damaged



• We do not recommend the use of power drill/drivers ***for inserting screws***, as this could damage the unit. Only use hand screwdrivers.

• Dispose of all packaging carefully and responsibly.

• Assembly to be carried out by a competent adult only.

Care and maintenance

• Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.

• Regularly check all fastenings to ensure that they properly tightened.


• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

• This product is suitable for children in the age 4-12 years. Maximum load on chest 30 kg. Maximum load in each drawer 7 kg.


Components - Parts

If you have damaged or missing components, call the **Customer Helpline: 0045 7668 8055**


Please check you have all the parts listed below




1 Top x1
(86.0x40.0x1.6cm)
No. 4301-1608601-40




2 Side panel Right x1
(65.4x36.1x1.2cm)
No. 4301-1206541-40




3 Side panel Left x1
(65.4x36.1x1.2cm)
No. 4301-1206542-40




4 Leg x4
(71.4x4.0x2.6cm)
No. 12-02607141-20




5 Plinth Straight x1
(74.8x5.0x1.5cm)
No. 12-01507484-40




6 Cross rail x1
(74.8x6.5x1.5cm)
No. 12-01507482




7 List x1
(74.8x2.5x1.5cm)
No. 12-01507483-20




8 Drawer side Right x4
(35x16.7x1.3cm)
No. 15-01303503




9 Drawer side Left x4
(35x16.7x1.3cm)
No. 15-01303504




10 Drawer front x2
(37.1x18.9x1.6cm)
No. 4301-1603713-40




11 Drawer back x2
(32.5x16.7x1.3cm)
No. 15-01303251




12 Drawer front x2
(74.4x18.9x1.6cm)
No. 4301-1607443-40



13 Drawer back x2
(71.6x16.7x1.3cm)
No. 15-01307161



14 Drawer base x2
(34.8x33.7x0.3cm)
No. 4309-0303482




15 Partition x1
(36.1x21.7x1.6cm)
No. 4301-1603612-40


Components - Parts

If you have damaged or missing components, call the **Customer Helpline: 0045 7668 8055**

Please check you have all the parts listed below



16 Back panel x1
(62.8x77.2x0.3cm)
No. 4309-030628









17 Drawer base x2
(72.8x34.8x0.3cm)
No. 4309-0307281

Components - Fittings

Please check you have all the fittings listed below

Note: The quantities below are the correct amount to complete the assembly. In some cases more fittings may be supplied than are required.


No. 4020-007 **A**  7x34mm for ø5 Minifix bolt x25	No. 3933-15010 **B**  ø15x9.5mm Minifix cam x25	No. 3903-40030 **C**  4.0x30mm Chipboard screw x16
No. 4010-027 **D**  310x27x10mm Drawer slide x8	No. 3940-00009 **E**  ø18/ø6,5x9.0mm Spacer x6	No. 4022-004 **F** 1.6x16mm Nail square x24
	No. 4008-112 **G**  44x23x23 Angle x2	No. 3930-08030 **H**  8x30mm Dowel x24
No. 3901-35035 **i** 3.5x35mm Chipboard screw x19	No. 3912-04009 **J**  ø9.5/M4x9mm Machine screw x8	No. 3907-58008 **K**  ø5.8x8mm Euro screw x12
No. 41-00179 **L**  Overbalance protector x2	No. 3907-42010 **M**  ø4.2x9.5mm Euro screw x8	No. 3907-58019 **N**  ø5.8x19mm Euro screw x10


Tools required

Phillips screwdriver (medium)


Flatblade screwdriver (medium)

Allen key 4mm incl.
No. 4033-004






Small hammer



Ruler/tape measure



Eye protection (when using a hammer or glue)


Assembly Instructions

Step 1

Insert the dowels Ⓗ into the holes in cross rail 6.

It may be necessary to tap the dowels in very gently with a small hammer.


Attach minifix bolts Ⓐ to top panel 1.



Step 2

Attach the side panels 2 and 3 to the legs 4 using screws Ⓒ.

Make sure the top of the side panel is flush with the legs and there are no gaps between the side panel and the edge of the groove in the legs.




Step 3

Insert the dowels Ⓗ into the holes in the partition 15.

Attach the drawer runner Ⓓ to the partition 15 with euro screws Ⓝ.

Be aware of the front edge! Note that the screws must be inserted from different holes in the runners!




Assembly Instructions

Step 4

Attach the second drawer runner D to the partition 15 with euro screws N.

Be aware of the front edge! Note that the drawer screws must be inserted from different holes in the runners!




Step 5

Insert the dowels H to the holes in the side panels 2 and 3.

Attach minifix bolts A to the side panels 2 and 3.

Attach the drawer runners D to the side panels 2 and 3 with euro screws K. Note that the upper runners need to be attached with screws N and have spacers E placed between the side panel and runner.


Be aware of the front edge!



Assembly Instructions

Step 6


Attach the cross rail 6 to the side panels 2 and 3 with the minifix cams B.



Step 7


Attach angles G to the plinth 5 using screws M.

Attach plinth 5 to side panels 2 and 3 using screws M.



Step 8


Attach the partition 15 to the top panel 1 using minifix cams B.



Assembly Instructions

Step 9


Attach the top 1 to the side panels 2 and 3 with the minifix cams B.



Step 10

Fasten the list 7 to the top panel using screws i, placing the screws into the marking holes in top 1.


Don’t overtighten.



Step 11

Attach the back panel 16 with nails F to the back side of the chest.


Nail the back panel 16 to the carcass, ensuring that there are NO GAPS between the top 1 and the back panel 16. Follow the measurements.



Step 12


Measure out the positions for the wall attachment straps. Drill two holes spaced as illustrated with the appropriate size for the wall attachment fitting (see next step).

Pull the two straps through the gaps in top plate 1 .Push the furniture against the wall and secure the strap under the top plate with washer and screw.



Step 12b

Different types of wall fittings. Contact your local DIY or hardware store for the wall plugs and screws.




Step 13

Insert the dowels (H) into the holes in the drawer sides 8 and 9.

Attach the minifix bolts (A) to the drawer front 10 and 12.

Repeat for all drawer sides and drawer fronts.




Assembly Instructions

Step 14

Attach the drawer sides 8 and 9 to the drawer front 10 with the minifix cams B.

Repeat for both drawers.




Step 15

Push the drawer base 14 carefully into the drawer. Note that one edge of the base is slightly narrower (11 mm) than the other, make sure the narrow edge goes in first.

Attach the drawer back 11 to the drawer sides 8 and 9 with the screws i.


Repeat for both drawers.



Step 16

Attach the drawer sides 8 and 9 to the drawer front 12 with the minifix cams B.

Repeat for both drawers.




Step 17

Push the drawer base 17 carefully into the drawer.

Attach the drawer back 13 to the drawer sides 8 and 9 with the screws i.

Repeat for both drawers.




Step 18

Place the assembled drawer between the drawer runners D.
Attach the drawer sides 8 and 9 to the runners using the screws J.

Repeat for all drawers.

Assembly is complete.



If you need help or have damaged or missing parts, call the **Customer Helpline: 0045 7668 8055**
E-mail: order@flexa.dk