
Lido



Spare Parts

www.argos-support.co.uk

Help@ClickSpares.co.uk

0370 112 1928

Customer Support

0345 640 2020

Habitat.co.uk/help/contact-us

Issue 1 -21/Mar/2024

⚠ Safety and Care Advice

Product Details

7068344 - Lido Black Table 2 Chairs
7982066 - Lido Black Ext Table 6 Chairs
8193957 - Lido Black Ext Table 4 Chairs
8087915 - AH LIDO GLASS TABLE 4 GREY CHAIRS
4876821 - Lido White 1+4 Dining Set
5037968 - AH LIDO GLASS TABLE 4 BLACK CHAIRS
8506207 - Lido Grey Ext Table 4 Chairs
8457600 - AH1 LIDO GLASS EXT TABLE & 6 CH GRY
8148823 - AH LIDO GLASS TABLE 2 GREY CHAIRS
9224557 - AH1 LIDO GLASS ROUND TABLE & 4 GRY
7319505_AH LIDO CHAIRS X 2 BLACK
7319512_AH LIDO CHAIRS X 2 GREY

IMPORTANT, RETAIN FOR FUTURE REFERENCE: READ CAREFULLY.


• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• This product has been constructed to be used in the domestic environment only and not for commercial purposes.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor.



• We do not recommend the use of power drill/drivers for inserting screws as this could damage the unit. Only use hand screwdrivers.

• Parts of the assembly will be easier with 2 people.

• Dispose of all packaging carefully and responsibly.

Care and maintenance

• Only clean using a damp cloth and mild detergent. Do not use abrasive cleaners.

• Use a dry cloth to clean the product, furniture polish is not recommended.

• From time to time check that there are no loose screws, nuts or bolts. If there are please re-tighten.

• This product should not be discarded with household waste.Take to your local authority waste disposal centre.

Additional Guidance

• Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts.


• Regularly check and ensure that all bolts and fittings are tightend properly.

• Maximum user weight 110kg.


• This product is compliant BS EN 12520 : 2015

Sainsbury's Supermarkets Ltd and Argos Limited, London EC1N 2HT, UK. Sainsbury's (NI) Ltd and Argos (N.I.) Ltd, Forestside Shopping Centre, Upper Galwally, Belfast, BT8 6FX, UK.


Parts




1 Front leg




2 Left leg



3 Right leg




4 Backrest



5 Seat

Fittings (Shown to scale)

Bag 1




M6 x 12mm Bolt x 8

M6 x 22mm Bolt x 4


Allen key x 1


Tools required




Ruler/tape measure


1



A
M6 x 12mm Bolt x 8
B
M6 x 22mm Bolt x 4
C
Allen key x 1


A
M6 x 12mm Bolt x 4
C
Allen key x 1



3
2
A
A
1
A
A
C
2
A
A
1


2


B
M6 x 22mm Bolt x 4
C
Allen key x 1


C
B
B
2
4
B
B
2
4
B
B
3


3






4

a:



b:



Turn Product

Assembly complete.