We love that you are rocking JLab Audio!
We take pride in our products and fully stand behind them.

JLab DC010 ® | EPIC SPORT EARBUDS

LIMITED TWO YEAR WARRANTY 2

YOUR WARRANTY
All warranty claims are subject to JLab Audio authorization and at our sole discretion. Retain your proof of purchase to ensure warranty coverage.

U.S. BASED CUSTOMER SUPPORT

CONTACT US
Reach out to us at **support@jlabaudio.com** or visit **jlabaudio.com/contact**

FIRST TIME SETUP: BLUETOOTH PAIRING

1 Turn on the Bluetooth in your device settings.

Settings

Bluetooth

2

Press and hold button for **10 seconds**.

Release.

Light will **blink red and blue** to indicate pairing mode.

3 Select "JLab Epic Sport" in your device settings to connect.

Light will **slow blink blue** when Bluetooth is paired.

Settings

Bluetooth

JLab Epic Sport

RECURRING USE
Once JLab Epic Sport has initially paired to your device, the earbuds will auto-connect to your Bluetooth device when powered back ON. (Follow **BUTTON FUNCTIONS** instructions)

BUTTON FUNCTIONS

VOLUME UP: Quick press

TRACK FORWARD:
Press & hold 2 seconds

POWER ON:
Press & hold 3 seconds

POWER OFF:
Press & hold 5 seconds

**PLAY / PAUSE
ANSWER / HANG UP:**
Quick press

BLUETOOTH PAIR:
Press & hold 10 seconds.
(Follow First Time Setup)

**ACTIVATE SIRI (iOS) OR
"OK GOOGLE" (ANDROID):**
Press twice

VOLUME DOWN:
Quick press

TRACK BACKWARD:
Press & hold 2 seconds

EQUALIZER MODES

Quick press both buttons for different EQ settings
(Epic Sport will cycle 3 EQ settings)

**JLab SIGNATURE
(One Beep)**
JLab C3™ signature sound
with amplified bass and vocals

**BALANCED
(Two Beeps)**
Even sound with no
additional enhancements

**BASS BOOST
(Three Beeps)**
Amplified bass
and sub-bass

VOICE PROMPTS

"HELLO" = Power is ON.

"BATTERY FULL" = 100-75%
"BATTERY MEDIUM" = 75-25%
**"LOW BATTERY"** = Less than 25%

"READY TO PAIR"
JLab Epic Sport earbuds are ready to
connect to your Bluetooth device.

"YOU'RE CONNECTED"
JLab Epic Sport is connected to your
Bluetooth device and ready for use.

"GOODBYE" = Power turning OFF.

CHARGING

1 Place the JLab Epic Sport control box in the magnetic
charging station and plug in the USB to a computer
or USB output device to charge.

OR

2 Light will **turn solid red** when charging
and **turn blue** when fully charged.

Charging   Fully Charged

# FITTING

1 EAR TIP

CUSH FIN™

EARBUD

2 Try various
ear tips and
Cush Fins to
find the best fit.

3 Rotate the earbud
into ear canal and
bend the Memory
Wire to desired
position.

CABLE CLIP USE

**1** Attach optional cable holder to tighten or loosen the cable during use.

2 Insert the optional cable clip to the back of the cable holder.

3 Open the cable clip and attach to apparel.

CONNECTION TROUBLESHOOTING

I DO NOT SEE JLAB EPIC SPORT IN MY DEVICE

1 Turn Bluetooth off and then back on in device settings.

Settings

Bluetooth

2 If you still do not see JLab Epic Sport, repeat **FIRST TIME SETUP: BLUETOOTH PAIRING** directions.

Settings

Bluetooth

JLAB EPIC SPORT DOES NOT RECONNECT TO MY DEVICE AFTER POWERING ON

1 In device settings, forget the JLab Epic Sport.

Settings

Bluetooth

JLab Epic Sport ⓘ

2 Turn Bluetooth off then back on in device settings.

Settings

Bluetooth

3 Repeat **FIRST TIME SETUP: BLUETOOTH PAIRING** directions.

Settings

Bluetooth

CONNECTION TROUBLESHOOTING (CONTINUED)

BLUETOOTH IS CONNECTING TO AN UNWANTED DEVICE

Note: The JLab Epic Sport can remember up to 8 devices. It will try to auto-connect to last device used.

1 If you have more than one device that was connected to JLab Epic Sport, turn OFF Bluetooth on unwanted devices and turn ON Bluetooth on chosen device.

Settings

Bluetooth

JLab Epic Sport

Settings

Bluetooth

JLab Epic Sport

2

Press and hold button for **10 seconds**.

Release.

Light will **blink red and blue** to indicate pairing mode.

Light will **slow blink blue** when Bluetooth is paired.

CAUTIONS

• Avoid getting moisture or liquids into the tip of the earbuds or charging port.

• Avoid extreme heat, cold, and humidity.

• Avoid dropping or crushing the earbuds, stressing the cable by rapid pulling or extreme force, or bending the cable at a sharp angle.

• Wax may build up in the earbud tips, lowering the sound quality. Carefully remove the wax with a cotton swab or other small tool to improve the sound quality.

• If you experience discomfort or pain, try lowering the volume or discontinuing use temporarily.

• If you experience regular discomfort while using this product, discontinue use and consult your physician.

• We recommend you treat your earbuds as you would a nice pair of sunglasses and keep them in safe location when not in use.

Shop products | Product alerts | Burn-in your headphones

JLab Audio + Burn-in Tool

Download on the **App Store**

GET IT ON **Google play**