
habitat

Pixie Flush Light

9505623 9478523



Care & Instruction Manual

For household and indoor use only

Please read and retain these instructions for future reference

Important

- For your safety, this product must be installed in accordance with wiring regulations from the Institute of Engineering and Technology (IET) and current local Building Regulations.
- If in any doubt, or where required by the law, consult a competent person who is registered with an electrical self-certification scheme. Further information is available online or from your Local Authority.
- To prevent electrocution, switch offat the mains supply before installing or maintaining this fitting.
- Ensure other persons cannot restore the electricity, supply without your knowledge.
- To avoid damage to concealed wiring during installation, establish the direction of the supply cable before drilling fixing holes.
- Always be sure to use the correct type and wattage of bulbs as indicated on the fitting. Never exceed the wattage stated.
- When changing the bulb, always switch offat the mains and allow the old bulb to cool down before handling. Dispose of used bulbs carefully.
- This fitting is Class I appliance. It should befitted to a lighting supply (with earth) protected by a 5 amp fuse or equivalent breaker. The product must be earthed.
- The luminaire is designed for indoor use only.
- This product contains a light source of energy efficiency class F.
- The light source(s) in this luminaire is replaceable by the end-user, ensure the wattage of the replacement light source does not exceed the wattage indicated on the luminaire.

Before removing the existing fitting, carefully note the position of each set of cables. If there are loop in cables that are not connected to the light, they must be terminated separately and not connected to the fitting.


1. Unscrew the two side screws to remove bracket from the ceiling plate (Fig. 1a)
2. Drill suitable holes into the ceiling, ensuring that they align with the holes in the bracket. Screw the bracket onto the ceiling using suitable screws (Fig. 1b)
3. Each L, N and Earth cables should be fully covered by the small sleeving (provided); then fasten by using the plastic belt (provided) to make sure the small sleeving are fixed well on the cables. (Fig. 2)
4. Ensure the electrical connections are covered with suitable insulation tape.
5. Connect the supply wires to the terminal block in the corresponding L / N / E positions (Fig. 3) (ensure that connections are tight and no loose strands of wire are left out of the connector block.
6. Offer the light fitting up to the ceiling bracket and align the elongated screw holes and replace the screws & serrated washers to secure the fitting. (Fig. 1 a)
7. Install the metal lampshade on the lamp holder.Fit the bulb to the lamp holder. The type and wattage is indicated on the fitting.The wattage indicated must not be exceeded. (Fig. 4)

IMPORTANT: To avoid overheating, do not exceed the maximum wattage as stated on the product.

Maintenance


This luminaire is designed for indoor use only . Do not use polish or abrasive cleaner - use a soft dry cloth to clean the product.

1. Switch off the mains power supply.
2. Before replacing the bulb, allow it to cool down for at least 10 minutes.
3. Never touch the bulb with your fingers directly, cover it with a cloth.
4. Loosen the bulb and remove it from the lamp.
5. Replace a new bulb with same voltage and wattage (Max.6W E27 LED bulb).Products should not be disposed of with household waste. Please recycle where facilities exist. Check with your local authority for recycling advice.




1xMax.6W led candle bulb

(Included in pack)



Sleeving x3 & plastic belt x1

(Included in pack)



Screw & plugs x 2

(Included in pack)

Fig. 1




Fig. 2




Fig. 3







Fig. 4





A Guide to

Wall Mounting & Fixings



IMPORTANT:
When drilling into walls always check that there are no hidden wires or pipes etc. Make sure that the screws and wall plugs being used are suitable for supporting your unit. Consult a qualified tradesperson if you are unsure.


HINTS:

1) General Rule ⚠ Always use a larger screw and wall plug if you are not sure.
2) Ensure you use the recommended drill bit to match the wall plug and hole size.
3) Ensure you drill the hole horizontally, do not force the drill or enlarge the hole.
4) Take extra care when drilling high walls, ceilings and ceramic tiles. Ensure the plug is fitting below the ceramic tile to avoid splitting or cracking.
5) Ensure wall plugs are well fitted and are a tight fit in the drilled hole.

Types Of Walls


You can use one of the following types of wall plug if your walls are made of brick, breeze block, concrete, stone, wood or plasterboard.

No.1 "Standard" Wall Plug
General Wall Materials




These come in various sizes and are made from plastic or sometimes wood fiber.

No.2 "General Purpose" Wall Plug
Aerated / Breeze Block




Generally aerated blocks should not be used to support heavy loads, use a specialist fitting in this case.
For light loads, a General Purpose Plug can be used.

No.3 "Shield Anchor" Wall Plug
Heavy Loads




For use with heavier loads such as TV & HiFi Speakers and Satellite Dishes etc.

No.4 "Cavity Fixing" Wall Plug




For use with plasterboard partitions or hollow wooden doors.

No.5 "Cavity Fixing - Heavy Duty" Wall Plug



For use when fitting or supporting heavy loads such as shelving, wall cabinets, coatracks.

No.6 "Hammer Fixing" Wall Plug



For use with walls stuck with plaster board. The hammer fixing allows it to be fixed to the wall rather than the plaster board. Always check the fixing is secure to the retaining wall.

CARE & MAINTENANCE

⚠ **SAFETY**

Always check the fitting and location to ensure your safety in and around the home.

⚠ **FITTING**

From time to time check the fitting to ensure the wall plugs or screws do not become loose.

Recycling electrical products

You should now recycle your waste electrical goods and in doing so help the environment.This symbol means an electrical product should note be disposed of with normal household waste.Please ensure it is taken to a suitable facility for disposal. Visit www.recycle-more.co.uk,click on “bank locator” and enter your postcode to find your nearest recycling site.



If you require any further assistance, you can contact us on 0345 640 2020 or visit habitat.co.uk
Your statutory rights are not affected.

Made in China for Habitat
Argos Limited, London, EC1N 2HT, UK. Argos (N.I.) Ltd, Forestside Shopping Centre, Upper Galwally, Belfast, BT8 6FX, UK.